

[Manuals.plus](#) /

> [Panasonic](#) /

> Panasonic Compact Cordless Phone with DECT 6.0, 1.6" Amber LCD and Illuminated HS Keypad, Call Block, Caller ID, Multiple Display Languages - 1 Handset - KX-TGB810S (Black/Silver)

Panasonic KX-TGB810s

Panasonic Compact Cordless Phone User Manual

Model: KX-TGB810S

Brand: Panasonic

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Panasonic Compact Cordless Phone, Model KX-TGB810S. Please read this manual thoroughly before using the phone and keep it for future reference.

The Panasonic KX-TGB810S is a compact cordless phone designed for home and small office use. It features DECT 6.0 technology for clear communication, an intuitive backlit LCD display, and essential functions like Caller ID, Call Block, and a phonebook.

2. WHAT'S IN THE BOX

- Handset
- Base Unit
- Charger
- AAA Rechargeable Batteries (x2)
- Telephone Line Cord
- AC Adapter
- User Manual



Panasonic

SMITH, JOHN
1-222-333-4444
12:00 AM 12/31

MENU

REDIAL

MUTE

OK

BACK

INTERCOM

FLASH

TALK
SP-PHONE

CID

OFF

1 &
(

2 A
B
C

3 D
E
F

4 G
H
I

5 J
K
L

6 M
N
O

7 P
Q
R
S

8 T
U
V

9 W
X
Y
Z

*

0 -

P
A
a



Figure 2.1: Panasonic KX-TGB810S Cordless Phone Handset and Base Unit.

3. SETUP GUIDE

3.1. Battery Installation and Charging

1. Open the battery compartment cover on the back of the handset.
2. Insert the two supplied AAA rechargeable batteries, ensuring correct polarity (+/-).
3. Close the battery compartment cover.
4. Place the handset on the base unit. The handset will begin charging.
5. Allow the handset to charge for at least 7 hours before initial use to ensure full battery capacity.

The phone offers an impressive battery life of up to 180 hours in standby mode and 9 hours of talk time on a full charge.

3.2. Connecting the Base Unit

1. Connect the AC adapter to the base unit and plug it into a standard electrical outlet.
2. Connect the telephone line cord to the base unit and plug the other end into your telephone wall jack.

The compact design of the base unit allows it to fit almost anywhere, including small countertops, and it is also wall-mountable for maximum convenience.



Figure 3.1: The KX-TGB810S base unit is wall-mountable.

3.3. Product Overview Video

Your browser does not support the video tag.

Video 3.1: An official product overview video demonstrating the features and compact design of the Panasonic KX-TGB810S Cordless Phone.

4. OPERATING INSTRUCTIONS

4.1. Basic Call Functions

- **Making a Call:** Dial the number and press the **TALK/SP-PHONE** button.
- **Answering a Call:** Press the **TALK/SP-PHONE** button when the phone rings.
- **Ending a Call:** Press the **OFF** button or place the handset back on the base unit.

- **Speakerphone:** Press the **TALK/SP-PHONE** button during a call to activate/deactivate the speakerphone.

4.2. Key Features

- **Caller ID:** See who's calling before you answer.
- **Call Block:** Block unwanted numbers (up to 20 numbers).
- **Phonebook:** Store up to 50 contacts for quick dialing.
- **Redial List:** Access the last 10 dialed numbers.
- **Speed Dial:** Program 2 numbers for one-touch dialing.
- **DECT 6.0 Technology:** Ensures clear sound quality and extended range, even when the handset is away from the base.
- **Line Power Mode:** The phone can function even during temporary power outages.

Clear Sound

DECT 6.0 technology reduces interference

Caller ID

See who's calling before you answer

Menu function

Easy navigation to favorite features

Speakerphone

Enjoy hands-free conversations



Battery Life Indicator

Check that phone is charged

Bright LCD Display

Displays clearly, day or night

Phonebook

Holds up to 50 entries

Illuminated Keypad

Helps with dialing in the dark

Figure 4.1: Detailed features of the handset for easy navigation and use.



Figure 4.2: Overview of the phone's main functionalities.

4.3. Display Languages

The LCD display supports multiple languages: English, Spanish, and French. You can change the display language through the phone's menu settings.



Figure 4.3: The phone offers extended battery life for daily use.

5. MAINTENANCE

To ensure the longevity and optimal performance of your Panasonic cordless phone, follow these maintenance

guidelines:

- **Cleaning:** Wipe the handset and base unit with a soft, dry cloth. Avoid using abrasive cleaners, waxes, or solvents.
- **Battery Care:** Use only the specified rechargeable AAA Ni-MH batteries. Do not use alkaline, manganese, or Ni-Cd batteries. If the phone will not be used for an extended period, remove the batteries.
- **Environment:** Avoid exposing the phone to direct sunlight, excessive moisture, or extreme temperatures. Keep it away from heat sources and devices that generate electrical noise.

6. TROUBLESHOOTING

If you experience issues with your Panasonic KX-TGB810S, try the following common troubleshooting steps:

Problem	Possible Cause / Solution
No dial tone / Cannot make or receive calls	Check if the telephone line cord is securely connected to the base unit and the wall jack. Ensure the AC adapter is plugged in and the base unit has power.
Static or poor sound quality	Move the handset closer to the base unit. Ensure there are no large metal objects or other electronic devices interfering with the signal. DECT 6.0 technology minimizes interference, but extreme conditions can affect it.
Handset does not charge	Ensure the handset is properly seated in the base unit. Clean the charging contacts on both the handset and base unit with a dry cloth. Verify the AC adapter is connected.
Display is blank or unreadable	Ensure batteries are charged. The backlit LCD display should be clear, day or night. If issues persist, try resetting the phone by unplugging the base unit for a few minutes and then plugging it back in.
Messages full (if applicable)	Delete old messages from the answering system to free up space.

For more detailed troubleshooting or complex issues, please refer to the full user manual available as a PDF or contact Panasonic customer support.

7. SPECIFICATIONS

Feature	Specification
Brand	Panasonic
Model Number	KX-TGB810s
Color	Black/Silver

Feature	Specification
Telephone Type	Cordless
Item Weight	12.3 ounces (0.35 Kilograms)
Package Dimensions	7.52 x 4.92 x 2.68 inches
Batteries	2 AAA rechargeable batteries (included)
Phone Talk Time	9 Hours
Standby Time	180 Hours
Answering System Type	Digital (if applicable to specific model variant)
Recording Capacity	18 minutes (if applicable to specific model variant)
Display Languages	English, Spanish, French

Handset Dimensions



Base Charger Dimensions

All values are approximate.

Figure 7.1: Approximate dimensions of the handset and base charger.

8. WARRANTY AND SUPPORT

8.1. Product Warranty

Your Panasonic KX-TGB810S Compact Cordless Phone is covered by a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms, conditions, and duration of coverage. Keep your proof of purchase for warranty claims.

8.2. Customer Support

For further assistance, technical support, or service inquiries, please contact Panasonic customer support. You can find contact information on the Panasonic official website or in the documentation provided with your product.

An electronic version of this user manual is available for download:

[Download User Manual \(PDF\)](#)