

- Manuals.plus /
- > ALLIMITY /
- > ALLIMITY BN59-01330B Remote Control Instruction Manual for Samsung QLED 4K TVs

ALLIMITY BN59-01330B

ALLIMITY BN59-01330B Remote Control Instruction Manual

Model: BN59-01330B

1. PRODUCT OVERVIEW

The ALLIMITY BN59-01330B is a replacement remote control designed for various Samsung QLED and 4K TV models. It offers full functionality comparable to the original remote, providing a seamless user experience.





Image 1: Front view of the ALLIMITY BN59-01330B remote control, showing all buttons.

Compatible TV Models:

This remote control is compatible with a wide range of Samsung QLED and 4K TV models. A non-exhaustive list includes:

- Samsung QLED 4K TV Q60, Q60T, Q65T, Q70T, Q80T series
- Samsung 4K TV TU8005, TU8079, TU8509, TU8502, TU8072 series
- Specific models: 49Q80T, 75Q80T, 75Q900T, 75Q950TS, 75TU8000, 82TU8000, 85Q70T, GQ43Q60T, GQ50Q60T, GQ50Q60TGUXZG, GQ55Q60, GQ55Q60T, GQ55Q60TGUXZG, GQ58Q60T, GQ65Q60, GQ65Q60T, GQ65Q60TGU, GQ65Q60TGUXZG, GQ75Q60, GQ75Q60T, GU43TU8509UXZG, GU50TU8079UXZG, GU50TU8509, GU50TU8509U, GU55TU7079U, QE43Q60, UE43RU7400, UE43RU7405, UE43RU7409, UE43TU8005KXXC, UE43TU8070UXZT, UE43TU8072UXXH, UE43TU8502UXXH, UE49RU8000, UE49RU8009, UE50RU7400, UE50RU7405, UE50RU7409, UE50TU8075U, UE50TU8505U, UE55RU7400, UE55RU7405, UE55RU7406, UE55RU7409, UE55RU8000, UE55RU8002, UE55RU8009, UE55TU8005, UE55TU8005K, UE55TU8075U, UE55TU8305K, UE55TU8502UXXH, UE55TU8505U, UE55TU8507UXXU, UE65RU7400, UE65RU7405, UE65RU7409, UE65RU8000, UE65RU8002, UE65RU8005, UE65RU8009, UE65TU8000WXXN, UE65TU8002KXXH, UE65TU8005K, UE65TU8005KXXC, UE65TU8070UXZG, UE65TU8072UXXH, UE65TU8305K, UE65TU8305KXXC, UE65TU8502UXXH, UE65TU8505U, UE75TU8005K,

UE75TU8005KXXC, UE75TU8070UXZG, UE75TU8072UXXH, UE82RU8000, UE82RU8005, UE82RU8009, UE82TU8005K, UE82TU8005KXXC, UE82TU8072UXXH, UE82TU8075UXXC.

2. SETUP AND INSTALLATION

The ALLIMITY BN59-01330B remote control is designed for immediate use without complex setup procedures.

1. Battery Installation:

Locate the battery compartment on the back of the remote control. Insert two appropriate alkaline batteries (typically AAA, though not specified in product data) according to the polarity indicators (+ and -) inside the compartment. Close the battery cover securely.

2. Initial Use:

No programming or pairing is required. Once batteries are installed, the remote control is ready to operate your compatible Samsung TV immediately.

3. OPERATING INSTRUCTIONS

This section details the primary functions of the buttons on your ALLIMITY BN59-01330B remote control.



Image 2: The remote control highlighting the voice control button.

- **Power Button (⏻):** Located at the top, this button turns your TV on or off.
- **Voice Control Button (🗣️):** Activates the voice assistant function on your compatible TV. Press and hold to issue voice commands.
- **123 Button:** Accesses the on-screen numeric keypad for direct channel input or other numerical entries.
- **Source/Input Button (📺):** Switches between different input sources (e.g., HDMI 1, HDMI 2, TV).
- **Navigation Pad (Up, Down, Left, Right, Enter):** Used to navigate menus, select items, and confirm choices.
- **Back Button (⏮️):** Returns to the previous screen or menu.
- **Home Button (🏠):** Accesses the TV's Smart Hub or main home screen.
- **Play/Pause/Fast Forward/Rewind Buttons:** Controls media playback.
- **Volume Up/Down (+ / -):** Adjusts the TV volume.
- **Channel Up/Down (▲ / ▼):** Changes TV channels.
- **Dedicated App Buttons (NETFLIX, Prime Video, Rakuten TV):** Provides direct access to these streaming services.

4. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Avoid using liquid cleaners or abrasive materials, as these can damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store in a cool, dry place.

5. TROUBLESHOOTING

- **Remote Not Responding:**
 - Ensure batteries are correctly installed with the correct polarity.
 - Replace old batteries with new ones.
 - Check for any obstructions between the remote control and the TV's infrared receiver.
 - Confirm the remote is pointed directly at the TV.
- **Intermittent Connectivity:**

Some users have reported that the remote may experience brief, intermittent disconnections during initial use, which typically resolve themselves within a few seconds. If this persists, try replacing the batteries.
- **Limited Range:**

The remote control has a maximum effective range of approximately 10 meters (33 feet). Ensure you are within this range and that there are no significant obstacles.

6. SPECIFICATIONS

Brand	ALLIMITY
Model Number	BN59-01330B

Color	Black
Connectivity Technology	Infrared
Special Feature	Universal (for compatible Samsung TVs)
Number of Buttons	25
Controller Type	Button Control
Maximum Range	10 Meters

7. WARRANTY AND SUPPORT

Information regarding specific warranty terms or direct support contacts for the ALLIMITY BN59-01330B remote control is not available in the provided product data. Please refer to the retailer or manufacturer's website for further details on warranty coverage and customer support options.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B092QNGWYW>

More documents and user manuals: <https://manuals.plus/>