Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY GA903WJSA

ALLIMITY GA903WJSA Replacement Remote Control Instruction Manual

For Sharp Aquos TVs

Introduction

This manual provides instructions for the ALLIMITY GA903WJSA replacement remote control. It is designed to function as a direct replacement for various Sharp Aquos TV models, offering comprehensive control without the need for complex setup procedures.

Product Overview

The ALLIMITY GA903WJSA remote control is a black, infrared-based device featuring a standard layout of buttons for TV operation. It includes a numeric keypad, channel and volume controls, navigation buttons, and dedicated function keys.



Image 1: Angled view of the ALLIMITY GA903WJSA remote control, showcasing its ergonomic design and button layout.





Image 2: Front view of the ALLIMITY GA903WJSA remote control, highlighting the full array of buttons including the numeric pad, navigation, and special function keys.

Setup

The ALLIMITY GA903WJSA remote control is designed for immediate use with compatible Sharp Aquos TV models. No programming or pairing is required.

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover open.
3. Insert two new alkaline batteries (AAA, not included) according to the polarity indicators (+ and -) inside the compartment.
4. Close the battery cover securely.

Once batteries are installed, the remote is ready for operation.

Operating Instructions

This remote control replicates the full functionality of your original Sharp Aquos TV remote. Point the remote directly at your television's infrared receiver for optimal performance.

Key Functions:

- **TV Power:** Turns the television on or off.
- **Source:** Cycles through available input sources (e.g., HDMI, AV).
- **ATV/DTV/SAT/RADIO:** Selects specific input modes or tuners.
- **Numeric Keypad (0-9):** Directly enters channel numbers.
- **CH +/- (P+/-):** Changes television channels up or down.
- **VOL +/- (V+/-):** Adjusts the volume level.
- **Mute:** Mutes or unmutes the television audio.
- **Menu:** Accesses the TV's main menu.
- **OK** / **Navigation Arrows:** Confirms selections and navigates through menus.
- **EPG:** Displays the Electronic Program Guide.
- **Playback Controls (Play, Pause, Stop, Rewind, Fast Forward, REC, REC-STOP, USB REC, Time Shift):** Controls media playback functions, including recording if supported by your TV.
- **3D:** Activates or deactivates 3D mode if your TV supports it.
- **NETFLIX:** Direct access button for the Netflix application.
- **Colored Buttons (Red, Green, Yellow, Blue):** Used for specific functions within TV menus or applications, as indicated on-screen.
- **ECO:** Activates or deactivates energy-saving modes.
- **AV MODE:** Cycles through various audio/video modes.

Compatible Models

The ALLIMITY GA903WJSA remote control is compatible with a wide range of Sharp Aquos TV models, including but not limited to:

- LC-40LE824E
- LC-40LE730
- LC-46LE731E
- LC-40LE924E
- LC-46LX814E
- LC-46LE730E
- LC-46LU824E
- LC-60LE925E

- LC-46LE824E
- LC-40LE731E
- LC-40LX814E
- LC-60LE635E
- LC-40LE732E
- LC-46LE925E
- LC-39LE750E
- LC-39LE751E
- LC-39LE752E
- LC-40LE730NET
- LC-50LE750E
- LC-50LE751E
- LC-50LE752E
- LC-52LE833E
- LC-60LE751E
- LC-60LE752E
- LC-40LE830E
- LC-40LE830RU
- LC-40LE831E
- LC-40LE831S
- LC-46LE830E
- LC-46LE830RU
- LC-46LE831E
- LC-46LE831S
- LC-46LE925RU
- LC-60LE925RU
- LC-46LE814R
- LC-46LE824R
- LC-60LE740E
- LC-70LE740E
- LC-40LE814E
- LC-40LE814R
- LC-40LE824R
- LC-46LE814E

Troubleshooting

If the remote control is not functioning as expected, please follow these basic troubleshooting steps:

- **Check Batteries:** Ensure that the batteries are inserted correctly with the correct polarity and are not depleted. Replace with fresh alkaline batteries if necessary.
- **Line of Sight:** Make sure there is a clear line of sight between the remote control and the TV's infrared receiver. Obstructions can block the signal.
- **Remote Distance:** Operate the remote within its effective range (up to 10 meters).
- **TV Compatibility:** Verify that your TV model is listed in the compatible models section.

Specifications

Brand	ALLIMITY
Model Name	GA903WJSA
Connectivity Technology	Infrared
Special Feature	Universal (Replacement)
Compatible Devices	Sharp Aquos TVs (various models)
Color	Black
Maximum Range	10 Meters
Number of Buttons	12 (Main functional buttons, excluding numeric keypad)
Controller Type	Remote Control

Warranty and Support

Specific warranty information for the ALLIMITY GA903WJSA remote control is not available in the provided product data. For any support inquiries, warranty claims, or further assistance, please contact the seller directly through your purchase platform.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B092QP2S3H

More documents and user manuals: **https://manuals.plus/**