

Motorola SJD01

Motorola Ready For Adjustable Dock SJD01 User Manual

Model: SJD01

INTRODUCTION

This manual provides instructions for the proper setup, operation, and maintenance of your Motorola Ready For Adjustable Dock (Model SJD01). This multimedia USB-C stand is designed to enhance your smartphone experience by enabling productivity, video calls, and gaming on larger displays.

PRODUCT OVERVIEW

The Motorola Ready For Adjustable Dock (SJD01) is a versatile accessory that extends the capabilities of compatible USB-C smartphones. It features an adjustable design, magnetic cradle, pass-through charging, and an integrated cooling fan to optimize performance during intensive use.

Key Features:

- **Ready For (Smart Connect) Compatibility:** Amplifies smartphone capabilities for desktop mode, TV display, video calls, and gaming.
- **Internal Cooling Fan:** Integrated thermal management system with a quiet MAGLev fan to prevent throttling during heavy use.
- **USB-C Display Port Compatibility:** Works with various USB-C devices including Motorola Edge series, Samsung Galaxy S series, and iPhone 15/15 Pro/Pro Max.
- **Adjustable Design:** Magnetic cradle allows rotation to portrait or landscape, with tilt and pan options. Tripod mounting supported.
- **Secure Mounting:** Retractable arms lock into place, accommodating various phone sizes and cases.
- **Pass-Through Charging:** Supports charging while connected to an external display.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Motorola Ready For Adjustable Dock (SJD01)
- Magnetic Cradle
- Adjustable Angle Stand

- *Note: USB-C cable for display connection is not included.*

SETUP INSTRUCTIONS

1. **Assemble the Dock:** Attach the magnetic cradle to the adjustable stand. Ensure it clicks securely into place.
2. **Connect to Power (Optional):** For pass-through charging, connect a USB-C power adapter (not included) to the USB-C port on the back of the dock.
3. **Connect to Display:**
 - Ensure you are using a video-enabled USB-C to HDMI or USB-C to USB-C cable (not included).
 - Connect the dock's rear USB-C port to your TV or monitor's HDMI input or compatible USB-C display.
 - *Ensure your display has an HDMI port or a USB-C video-in port.*
4. **Place Your Smartphone:** Gently place your compatible USB-C smartphone into the magnetic cradle. The retractable arms will secure the device.
5. **Adjust Viewing Angle:** Tilt and pan the cradle to achieve your desired viewing angle. The cradle can also rotate between portrait and landscape orientations.





Image: Motorola Ready For Adjustable Dock with a smartphone securely mounted in portrait orientation.

Secure Mounting



Flexible USB-C connector accommodates most cases and phone sizes. Retractable arms lock into place to secure most phones and release with the push of a button.

Image: Side view of the Motorola Ready For Adjustable Dock highlighting the retractable arms and the USB-C connector for phone attachment.

OPERATING INSTRUCTIONS

1. Ready For (Smart Connect) Activation:

Once your compatible smartphone is connected to the dock and an external display, the Ready For interface should automatically launch on your phone and display. If it does not, check your phone's settings for "Ready For" or "Smart Connect" options.

Your browser does not support the video tag.

Video: Demonstrates how to connect a Motorola Edge+ to an external display using the Ready For dock and activate the Ready For

experience.

2. Mobile Desktop Mode:

Select "Mobile desktop" from the Ready For menu. Your phone's interface will transform into a desktop-like environment on the external display, allowing you to open multiple applications, manage files, and multitask efficiently. Your phone can function as a touchpad or an on-screen keyboard, or you can connect a Bluetooth keyboard and mouse for a traditional desktop experience.

3. Video Calls:

Choose "Video chat" to move your video calls to the larger screen. The dock allows for optimized camera positioning. You can flip your phone to use the high-resolution rear camera for improved video quality. Smart software tracks movement to keep participants in frame.




Image: A group video call displayed on a large television screen, demonstrating enhanced video conferencing.

4. Gaming:

Select "Game" to play mobile games on your external display. Connect a Bluetooth controller for a console-like gaming experience. The integrated cooling fan helps maintain optimal phone performance during extended gaming sessions.



Image: A person playing a racing game on a large external monitor, using a Bluetooth controller connected to a smartphone in the dock.

5. TV Mode:

Choose "TV" to stream videos and movies from your phone to the connected display. Enjoy your mobile content on a larger screen without buffering, leveraging your phone's network capabilities.

Your browser does not support the video tag.

Video: Overview of the Motorola Ready For Multimedia Dock features, including connecting to external displays, pass-through charging, and adjustable viewing angles.

MAINTENANCE AND CARE

- **Cleaning:** Use a soft, dry cloth to clean the dock. Avoid abrasive cleaners or solvents.
- **Storage:** Store the dock in a cool, dry place when not in use.
- **Handling:** Handle the dock with care to prevent damage to the USB-C connector and adjustable mechanisms.
- **Cooling Fan:** Ensure the cooling fan vents on the back of the dock are not obstructed to allow for proper airflow.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No display on external monitor.	Incorrect cable, loose connection, incompatible phone/display, display input not selected.	<ul style="list-style-type: none">◦ Ensure you are using a video-enabled USB-C to HDMI or USB-C to USB-C cable.◦ Check all cable connections are secure.◦ Verify your phone and display are compatible with the Ready For platform.◦ Select the correct input source on your TV/monitor.
Phone not charging.	No power adapter connected, faulty cable, phone not seated correctly.	<ul style="list-style-type: none">◦ Connect a USB-C power adapter to the dock's rear USB-C port.◦ Ensure the phone is properly seated on the dock's USB-C connector.◦ Try a different USB-C cable and power adapter.
Cooling fan not operating.	Phone not generating enough heat, fan malfunction.	<ul style="list-style-type: none">◦ The fan activates automatically when the phone's temperature rises during intensive use.◦ Ensure vents are clear. If issues persist, contact support.
Phone feels loose in the cradle.	Retractable arms not fully engaged.	<ul style="list-style-type: none">◦ Press the release button and allow the arms to retract, then re-seat the phone firmly.

SPECIFICATIONS

Feature	Detail
Model Number	SJD01
Brand	Motorola
Connector Type	USB Type C
Compatible Devices	Motorola Edge+ (2022/2023), Motorola Edge (2024), Moto G100, iPhone 15, iPhone 15 Pro, iPhone 15 Pro Max, Samsung Galaxy S23, S22, S21 (DisplayPort compatible USB-C devices)
Special Features	Adjustable, Magnetic Cradle, Pass Through Charging, Ready For, Internal Cooling Fan
Color	Black
Input Voltage	5 Volts (DC)
Output Current	2 Amps

Feature	Detail
---------	--------

Output Voltage	5 Volts
Power Source	External Power
Mounting Type	Tabletop Mount
Item Weight	11.1 Ounces
Material	Plastic

WARRANTY AND SUPPORT

The Motorola Ready For Adjustable Dock (SJD01) comes with a**2-Year Manufacturer Warranty**. For warranty claims, technical support, or further assistance, please contact Salom America Company, the manufacturer, or visit the official Motorola support website.

Manufacturer: Salom America Company

For the latest support information and FAQs, please refer to the official Motorola website or your product's dedicated support page.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B092RL6YNN>

More documents and user manuals: <https://manuals.plus/>