

[Manuals.plus](#) /

> [vidaXL](#) /

> vidaXL 7 Piece Outdoor Dining Set User Manual

## vidaXL met kussen

# vidaXL 7 Piece Outdoor Dining Set User Manual

Model: met kussen (ASIN: B092VB6WY9)

## IMPORTANT SAFETY INFORMATION

---

To ensure the longevity and safe use of your vidaXL 7 Piece Outdoor Dining Set, please observe the following safety guidelines:

- **Weather Protection:** It is highly recommended to use a protective cover for the dining set during periods of rain, snow, or frost. This will safeguard the materials and extend the product's lifespan.
- **Stable Placement:** Always place the dining set on a flat, stable surface to prevent tipping or instability.
- **Weight Limits:** Do not exceed the recommended weight limits for the chairs and table. Refer to the specifications section for details.
- **Assembly:** Ensure all components are securely fastened according to the assembly instructions before use. Regularly check and tighten all bolts and screws.

## PRODUCT OVERVIEW

---

The vidaXL 7 Piece Outdoor Dining Set is designed for comfortable outdoor lounging and dining. It features a durable PE rattan construction, a sturdy powder-coated steel frame, and solid acacia wood legs for enhanced stability and a stylish appearance.



Figure 1: The complete vidaXL 7 Piece Outdoor Dining Set, featuring a light gray poly rattan finish, black cushions, and a brown acacia wood tabletop.

## Key Features:

- **Comfortable Seating:** Thickly padded cushions provide a comfortable space for lounging and dining. Cushion covers are removable and washable for easy cleaning.
- **Easy Maintenance:** Constructed with lightweight and low-maintenance round PE rattan, making it suitable for outdoor use and simple to clean with a damp cloth.
- **Solid Acacia Wood Legs:** Chairs feature solid acacia wood legs, ensuring sturdiness and stability.
- **Durable Construction:** Made of PE rattan and powder-coated steel for durability and easy maintenance.

## SETUP AND ASSEMBLY

---

This section provides general guidelines for setting up your dining set. For detailed, step-by-step assembly instructions, please refer to the separate assembly manual included in your product packaging.

1. **Unpacking:** Carefully unpack all components from the packaging. Lay them out on a clean, soft surface to prevent scratches. Verify that all parts listed in the assembly manual are present.
2. **Chair Assembly:**



Figure 2: Individual chair structure before cushion placement.

Attach the legs to the chair frames using the provided hardware. Ensure all screws are tightened securely but do not overtighten to avoid damaging the material. Repeat for all six chairs.

3. **Table Assembly:** Assemble the table frame and attach the tabletop. Ensure all connections are firm and stable.
4. **Cushion Placement:** Once the chairs are assembled, place the seat and back cushions onto each chair. The cushion covers are removable for washing.
5. **Final Check:** Before first use, double-check all connections on both the table and chairs to ensure they are secure and stable.



Figure 3: Chair dimensions for proper placement and space planning.

## OPERATING INSTRUCTIONS

---

The vidaXL 7 Piece Outdoor Dining Set is designed for straightforward use in outdoor environments. No complex operation is required.

- **Placement:** Position the dining set in your desired outdoor area, ensuring it is on a level and stable surface.
- **Seating:** The chairs are designed for comfortable individual seating. Ensure proper posture when sitting.
- **Table Use:** The table provides a stable surface for dining, drinks, or other items. Avoid placing excessively hot items directly on the acacia wood tabletop without protection.

- **Movement:** While the set is lightweight for its size, always lift and move components rather than dragging them to prevent damage to the legs or frame.

## MAINTENANCE AND CARE

Proper maintenance will help preserve the appearance and extend the life of your outdoor dining set.

- **General Cleaning:** Wipe the PE rattan and steel frame with a damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water and drying thoroughly.
- **Cushion Care:** The cushion covers are removable and washable. Follow the care instructions on the cushion labels, typically machine wash cold on a gentle cycle and air dry. Do not bleach or tumble dry.
- **Acacia Wood Care:** The acacia wood tabletop and chair legs should be regularly cleaned with a damp cloth. To maintain the wood's appearance and protect it from weathering, it is recommended to treat the wood with a suitable outdoor wood oil or sealant periodically, especially if exposed to direct sunlight and rain.
- **Weather Protection:** As noted in the safety section, always use a protective cover during adverse weather conditions (rain, snow, frost) or when the set is not in use for extended periods. Store cushions indoors during heavy rain or winter months.
- **Inspection:** Periodically inspect all bolts and connections to ensure they remain tight. Tighten as necessary.

## TROUBLESHOOTING

This section addresses common issues you might encounter with your dining set.

Problem	Possible Cause	Solution
Set feels wobbly or unstable.	Loose connections; uneven ground.	Check and tighten all bolts and screws. Move the set to a level surface.
Rattan appears dull or dirty.	Accumulation of dirt or environmental residue.	Clean with a damp cloth and mild soap solution. Rinse thoroughly and dry.
Acacia wood looks dry or faded.	Exposure to sun and elements without treatment.	Clean the wood and apply a suitable outdoor wood oil or sealant.
Cushions are stained.	Spills or dirt.	Remove cushion covers and wash according to care label instructions.

## SPECIFICATIONS

Detailed specifications for the vidaXL 7 Piece Outdoor Dining Set:

**Brand:** vidaXL

**Model Number:** met kussen

**ASIN:** B092VB6WY9

**Set Size:** 7 Piece (1 table, 6 chairs)

**Color:** Light Gray and Brown (Light Gray Poly Rattan, Black Cushions, Brown Acacia Wood)

**Material:** Polyethylene (PE Rattan), Powder-Coated Steel, Solid Acacia Wood

**Product Dimensions (Overall):** Approximately 24.8 x 24.41 x 36.22 inches (L x W x H) -*Note: This dimension seems to be for a single chair based on image. Table dimensions not explicitly provided in specs.*

**Chair Dimensions (Approximate):**

- Height: 36.2 inches (92 cm)
- Depth: 25.6 inches (65 cm)
- Width: 24.4 inches (62 cm)

**Item Weight:** Approximately 112.9 pounds (total set weight)

**Product Care Instructions:** Wipe with Damp Cloth

**Special Feature:** Quick Release Button (*Note: This feature is listed but not clearly applicable to a dining set. It might be a generic spec.*)

## WARRANTY AND SUPPORT

---

For information regarding warranty coverage, returns, or customer support, please refer to the purchase documentation or contact vidaXL directly.

- **Returns:** This product typically offers 30-day easy returns. Please check your specific purchase terms.
- **Protection Plans:** Extended protection plans may be available for purchase. Refer to your retailer for details.
- **Manufacturer Contact:** For direct support, visit the official vidaXL website or refer to the contact information provided with your product.

You can also visit the [vidaXL Store on Amazon](#) for more information and support resources.

© 2024 vidaXL. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.