



[Manuals.plus](#) /

› [PowerA MOGA](#) /

› PowerA MOGA XP5-A Plus Bluetooth Controller User Manual for Android and Windows 10

PowerA MOGA XP5-A Plus

PowerA MOGA XP5-A Plus Bluetooth Controller User Manual

Model: XP5-A Plus

[Layout](#) [Setup](#) [Operating](#) [Introduction](#) [Maintenance](#) [Package Contents](#) [Troubleshooting](#) [Controller Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

This manual provides instructions for the PowerA MOGA XP5-A Plus Bluetooth Controller. This controller is designed for use with Android mobile devices and Windows 10 PCs, offering a versatile gaming experience. Please read this manual thoroughly before using the product to ensure proper setup and operation.



Image: A user playing a racing game on a television using the PowerA MOGA XP5-A Plus Bluetooth Controller. The controller is held in both hands, and the user is seated comfortably.

2. PACKAGE CONTENTS

Ensure all items are present in your package:

- PowerA MOGA XP5-A Plus Bluetooth Controller
- Detachable Phone Clip
- USB-C to USB-A Cable (for charging and wired play)
- USB-C to USB-C Cable (for charging and wired play)
- User Manual (this document)

3. CONTROLLER LAYOUT

Familiarize yourself with the buttons and features of your MOGA XP5-A Plus controller.



Image: Top-down view of the PowerA MOGA XP5-A Plus controller. The phone clip is folded back, showing the dual analog sticks, D-pad, ABXY buttons, Menu, Select, Start buttons, and LED indicators.

- **Left Analog Stick / L3 Button:** For movement and camera control. Press down for L3.
- **Right Analog Stick / R3 Button:** For camera control and aiming. Press down for R3.
- **D-Pad:** Directional input for menus and specific game actions.
- **ABXY Buttons:** Standard action buttons.
- **Menu Button:** Access in-game menus or system functions.
- **Select Button:** Often used for secondary functions or menu navigation.
- **Start Button:** Often used to pause games or confirm selections.
- **Shoulder Buttons (LB, RB):** Top-mounted buttons for various actions.
- **Triggers (LT, RT):** Analog triggers for precise input, often used for acceleration or firing.
- **MOGA Button:** Power on/off and Bluetooth pairing.
- **LED Indicators:** Show connection status, battery level, and charging status.
- **USB-C Port:** For charging the controller and wired connection.
- **USB-A Port (Power Bank):** For charging your mobile device.



Image: Rear view of the PowerA MOGA XP5-A Plus controller with the phone clip extended. The image highlights the USB-C port for controller charging and the USB-A port for charging a mobile device.

4. SETUP

4.1 Charging the Controller

Before first use, fully charge the controller. Connect the included USB-C cable to the controller's USB-C port and the other end to a USB power source (e.g., wall adapter, PC USB port). The LED indicators will show charging status and turn off when fully charged.

4.2 Pairing with Android Devices

1. Ensure the controller is fully charged.
2. Press and hold the **MOGA Button** for 3 seconds until the LED indicators begin to flash, indicating pairing mode.
3. On your Android device, go to **Settings > Connected devices > Bluetooth**.
4. Enable Bluetooth and scan for new devices.
5. Select "MOGA XP5-A Plus" from the list of available devices.
6. Once paired, the LED indicators on the controller will become solid.

4.3 Pairing with Windows 10 PCs

1. Ensure the controller is fully charged.
2. Press and hold the **MOGA Button** for 3 seconds until the LED indicators begin to flash, indicating pairing mode.
3. On your Windows 10 PC, go to **Settings > Devices > Bluetooth & other devices**
4. Ensure Bluetooth is turned On. Click "Add Bluetooth or other device" and select "Bluetooth".
5. Select "MOGA XP5-A Plus" from the list of available devices.
6. Once paired, the LED indicators on the controller will become solid.

Note: For wired play on Windows 10, simply connect the controller to your PC using a USB-C to USB-A cable. The controller should be automatically recognized.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- **To Power On:** Press the **MOGA Button** once. The controller will attempt to connect to the last paired device.
- **To Power Off:** Press and hold the **MOGA Button** for 5 seconds until the LED indicators turn off. The controller will also power off automatically after a period of inactivity.

5.2 Using the Detachable Phone Clip

The included phone clip allows you to securely attach your Android smartphone directly to the controller for a portable gaming setup.

1. To attach, align the clip with the slot on the top of the controller and push firmly until it clicks into place.
2. Extend the phone holder arms and carefully place your smartphone into the clip, ensuring it is secure.
3. Adjust the angle for optimal viewing.
4. To remove, gently pull the clip upwards from the controller.



Image: A user playing a game on a smartphone that is securely mounted to the PowerA MOGA XP5-A Plus controller using the detachable phone clip. The user is seated on a couch.



Image: Side view of the PowerA MOGA XP5-A Plus controller with its phone clip fully extended, ready to hold a smartphone. The controller's ergonomic design is visible.

5.3 Using the Integrated Power Bank

The MOGA XP5-A Plus features an integrated 3000 mAh power bank to charge your mobile device while gaming.

1. Connect your mobile device's charging cable to the USB-A port on the back of the controller.
2. The controller will begin charging your device.
3. *Note: Using the power bank will reduce the controller's battery life.*



Image: The PowerA MOGA XP5-A Plus controller connected via a USB cable to a smartphone, indicating the controller's ability to charge the phone. The phone screen shows a charging icon.

5.4 Customizable Controls

The XP5-A Plus allows for button remapping. Refer to the official PowerA MOGA app (if available for your device) or specific game settings for detailed instructions on customizing button layouts and mapping for your preferred gaming experience.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the controller. Do not use harsh chemicals or abrasive materials.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the controller frequently. Charge it regularly, even if not in use for extended periods.

7. TROUBLESHOOTING

7.1 Controller Not Connecting/Pairing

- Ensure the controller is fully charged.
- Make sure Bluetooth is enabled on your device.
- Ensure the controller is in pairing mode (LEDs flashing).
- Forget the device from your Bluetooth settings and attempt to pair again.
- Try restarting both the controller and your device.

- Ensure no other Bluetooth devices are interfering.

7.2 Buttons/Sticks Not Responding

- Verify the controller is properly connected to your device.
- Test the controller with a different game or application to rule out software issues.
- Ensure the controller's firmware is up to date (check PowerA's official website for tools).
- If using a renewed product, check for physical damage.

7.3 Charging Issues

- Ensure the charging cable is securely connected to both the controller and the power source.
- Try a different USB-C cable and/or a different USB power source.
- Check the charging port on the controller for any debris.

7.4 Lag or Input Delay

- Ensure your device is not running too many background applications.
- Move closer to your device to reduce potential Bluetooth interference.
- Some games may have inherent input lag; test with different titles.
- For Windows 10, consider using a wired connection if lag persists.

8. SPECIFICATIONS

Model	MOGA XP5-A Plus
Connectivity	Bluetooth, USB-C (wired)
Compatibility	Android, Windows 10
Battery Life	Up to 10 hours (controller only)
Integrated Power Bank	3000 mAh (via USB-A port)
Dimensions	7.68 x 8.27 x 36.81 inches
Weight	1.2 pounds
Manufacturer	POWER A

9. WARRANTY AND SUPPORT

This PowerA MOGA XP5-A Plus Bluetooth Controller (Renewed) comes with a 90-day limited warranty. For warranty claims or technical support, please refer to the Amazon Renewed Guarantee or contact PowerA customer service directly through their official website. Keep your proof of purchase for warranty purposes.

For further assistance, visit the official PowerA support website or the Amazon Renewed support page.

