

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Denon DJ](#) /
- › [Denon DJ LC6000 PRIME USB DJ Sub-Layer Controller Instruction Manual](#)

Denon DJ LC6000

Denon DJ LC6000 PRIME USB DJ Sub-Layer Controller Instruction Manual

Model: LC6000

INTRODUCTION

The Denon DJ LC6000 PRIME is a versatile DJ controller designed to expand creative possibilities for both standalone and laptop-based DJ workflows. It provides professional hardware control for the second dual-layer audio output of Engine OS powered DJ Media Players, such as the SC6000 and SC5000 series. Additionally, it functions as a dedicated DJ controller for compatible DJ applications, offering a club-style layout and control.



Image: The Denon DJ LC6000 PRIME controller, showcasing its jog wheel, performance pads, and various controls.

ENGINEERED TO EXPAND YOUR CREATIVITY



INHERITS THE SAME DNA FROM THE ULTIMATE CLUB EXPERIENCE **SC6000 PRIME**

Image: A DJ setup with two Denon DJ media players, demonstrating how the LC6000 PRIME can expand control by managing secondary layers.


SETUP INSTRUCTIONS

Follow these steps to set up your Denon DJ LC6000 PRIME controller:

1. **Unpacking:** Carefully remove the LC6000 PRIME from its packaging. Ensure all components are present, including the unit itself and any included cables.
2. **Placement:** Position the LC6000 PRIME on a stable, flat surface. Ensure adequate ventilation around the unit.
3. **Power Connection:** The LC6000 PRIME is USB powered. Connect the provided USB cable from the LC6000 PRIME to an available USB port on your computer or a compatible Denon DJ media player (e.g., SC6000, SC5000 series).
4. **Software Installation (for computer use):** If using the LC6000 PRIME with DJ software on a computer (e.g., Serato DJ Pro, Virtual DJ, Algoriddim djay Pro AI), ensure the latest version of your chosen software is installed and updated. Drivers may be automatically installed upon USB connection; refer to your operating system's device manager if issues arise.
5. **Connecting to Denon DJ Media Players:** For sub-layer control with Denon DJ SC series media

players, connect the LC6000 PRIME via USB to the media player. This enables physical control over the second audio layer of the media player.

ELEVATE YOUR DJ SOFTWARE TO MAINSTAGE STATUS



DJ CONTROLLER

FOR COMPATIBLE APPLICATIONS INCLUDING:



Image: The Denon DJ LC6000 PRIME integrated into a DJ setup with a laptop and mixer, demonstrating its use with DJ software.




Image: Visual representation of the LC6000 PRIME's compatibility with popular DJ software applications.

OPERATING INSTRUCTIONS

The LC6000 PRIME offers a comprehensive set of controls for precise DJ performance. Familiarize yourself with the key components:

Jog Wheel and Display

COMPLETE COMMAND OF YOUR PERFORMANCE



Image: A detailed view of the LC6000 PRIME's 8.5-inch jog wheel, highlighting its central HD display and tension adjust feature.

- **8.5" Capacitive Touch Jog Wheel:** Use this large jog wheel for scratching, nudging, and precise track manipulation.
- **Tension Adjust:** A dedicated knob allows you to adjust the resistance of the jog wheel to your preference.
- **HD Central Display:** This color display shows essential information such as track artwork, custom DJ logos, play head position, and other performance data.

Performance Controls

PERFORMANCE ESSENTIALS

1 TRACK SEARCH TOUCH STRIP

2 DEDICATED LOOP CONTROL

3 DEDICATED NAVIGATION CONTROL

4 100MM DUAL-PRECISION PITCH FADER

5 PITCH BEND BUTTONS

6 USB POWERED, PLUG & PLAY

7 8 MULTI-FUNCTION PERFORMANCE PADS



Image: A diagram labeling key performance features of the LC6000 PRIME, including the track search strip, loop controls, navigation, pitch fader, pitch bend buttons, and performance pads.

- **Track Search Touch Strip:** Quickly navigate through tracks.
- **Dedicated Loop Control:** Buttons for Auto Loop, Manual Loop In/Out, and Loop On/Off provide precise control over looping sections.
- **Dedicated Navigation Control:** Use the browse knob and load buttons to navigate your music library and load tracks.
- **100mm Dual-Precision Pitch Fader:** Adjust track tempo with high accuracy.
- **Pitch Bend Buttons:** Temporarily adjust the track's tempo for beatmatching.
- **8 Multi-Function Performance Pads:** These robust pads offer various modes for creative performance:
 - **Hot Cue:** Jump to predefined points in your track.
 - **Loop:** Trigger saved loops.
 - **Roll:** Create momentary loop rolls.
 - **Slicer:** Chop and re-arrange sections of your track on the fly.

Dual-Layer Control


The LC6000 PRIME is designed to control the second layer of compatible Denon DJ media players (e.g., SC6000, SC5000 series). This allows you to control two tracks from a single media player using the LC6000 PRIME for the second layer, effectively creating a two-deck setup with one media player and one controller.



LC6000 PRIME

PERFORMANCE EXPANSION CONTROLLER

Image: The LC6000 PRIME integrated with a Denon DJ Prime 4, demonstrating its capability to provide dedicated sub-layer control for enhanced performance.



DJ Control Evolved

Pair the LC6000 with a 4-channel DJ controller for hands on control of all your playback decks!

Image: An expanded DJ setup featuring multiple LC6000 PRIME units paired with a 4-channel controller, illustrating advanced control possibilities.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Denon DJ LC6000 PRIME:

- **Cleaning:** Use a soft, dry cloth to wipe down the unit. For stubborn dirt, a slightly damp cloth can be used, followed by a dry cloth. Avoid abrasive cleaners, solvents, or waxes.
- **Dust Protection:** When not in use, cover the unit with a dust cover to prevent dust and debris from accumulating on controls and internal components.
- **Storage:** Store the unit in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Management:** Ensure all cables are neatly organized and not under strain to prevent damage to connectors and ports.

TROUBLESHOOTING

If you encounter issues with your LC6000 PRIME, refer to the following common troubleshooting steps:

- **Unit Not Powering On:**
 - Ensure the USB cable is securely connected to both the LC6000 PRIME and a powered USB port on your computer or media player.
 - Try a different USB port or cable.
 - If connecting to a computer, ensure the computer is powered on and not in sleep mode.
- **Software Not Recognizing LC6000 PRIME:**
 - Verify that your DJ software is updated to the latest version and supports the LC6000 PRIME.
 - Restart your DJ software and/or your computer.
 - Check your computer's device manager (Windows) or System Information (macOS) to confirm the LC6000 PRIME is detected.
 - Ensure no other applications are interfering with the USB connection.
- **Controls Not Responding:**
 - Confirm the LC6000 PRIME is properly connected and recognized by your software or media player.
 - Check for any firmware updates for the LC6000 PRIME on the Denon DJ website.
 - If using with a media player, ensure the correct layer is selected for control.
- **Missing Components (e.g., lifters/feet):**
 - If any essential components, such as rubber feet or lifters, are missing upon unboxing, contact Denon DJ customer support or your retailer immediately for assistance.

For further assistance, refer to the official Denon DJ support resources.

SPECIFICATIONS

Feature	Detail
Model Number	LC6000
Item Weight	11.53 pounds (approx. 5.23 kg)
Product Dimensions (L x W x H)	14.16 x 12.6 x 4.44 inches (approx. 35.97 x 32.00 x 11.28 cm)
Jog Wheel	8.5-inch capacitive touch with HD central display
Pitch Fader	100mm dual-precision
Performance Pads	8 multi-function (Hot Cue, Loop, Roll, Slicer)
Connectivity	USB (Plug & Play, USB Powered)
Compatibility	Engine OS Media Players (SC6000, SC5000 series), Serato DJ Pro, Virtual DJ, Algoriddim djay Pro AI

WARRANTY AND SUPPORT

For detailed warranty information, product registration, and technical support, please visit the official Denon DJ website. You can find resources such as FAQs, software downloads, and contact information for customer service.





Official Denon DJ Website: www.denondj.com


Always ensure you are using the latest firmware and software versions for optimal performance and compatibility.

© 2025 Denon DJ. All rights reserved.

Related Documents - LC6000

	Denon DJ MCX8000 Quickstart Guide: Setup and Features Get started with your Denon DJ MCX8000 DJ controller. This quickstart guide covers setup, features, connections, and essential operations for professional DJ performance.
---	--


	Denon DJ LC6000 PRIME User Guide: Features, Setup, and Operation Comprehensive user guide for the Denon DJ LC6000 PRIME layer controller, covering features, setup instructions, connection diagrams, and operational details for DJs. Learn about performance controls, syncing, and pad modes.
	Denon DJ PRIME 4+ Standalone DJ Controller - Advanced Features and Specifications Explore the Denon DJ PRIME 4+, the world's most advanced 4-deck standalone DJ controller. Discover its features, including Wi-Fi music streaming, advanced FX, integrated lighting control, and standalone Stems integration. View technical specifications and connectivity options.
	Denon DJ SC6000 PRIME User Guide Explore the Denon DJ SC6000 PRIME professional DJ media player with this comprehensive user guide. Learn about its advanced features, setup, operation, and connectivity options for optimal DJ performances.
	Denon DJ DS1 Serato DVS Interface User Guide User guide for the Denon DJ DS1 Serato DVS Interface, covering features, setup, and technical specifications. Includes multilingual support information.
	Denon DJ SC6000 PRIME User Guide Comprehensive user guide for the Denon DJ SC6000 PRIME, detailing its features, setup, operation, and controls for professional DJ performances.



[\[pdf\]](#) User Manual Specifications Documentation Guide Warranty

LC6000 PRIME User Guide Denon DJ inMusic 1 mag 2021 — 825152 01U imagescdn junco co uk manual
User Guide Gua del usuario Guide d utilisation Guida per l uso Benutzerhandbuch
Appendix English 2 10 Espaol 11 19 Franais 20 28 Italiano 29 37 Deutsch 38 46
English 47 User Guide English Introduction Thank you for purchasing the **LC6000**
PRIME. At Denon DJ, we know h...


lang:en **score:61** filesize: 7.12 M page_count: 48 document date: 2020-09-10



[\[pdf\]](#) User Manual Specifications Documentation Guide Warranty

LC6000 PRIME User Guide Denon DJ Download Bedienungsanleitung Manual DE EN FR IT ES » Online
kopen in de Recordcase Shop recordcase media 43 32 4a |||
IDEI IC I I ID_J LCZSOOO IEEEEEE User Guide Gua del usuario Guide d utilisation
Guida per l uso Benutzerhandbuch Appendix English 2 10 Espaol 11 19 Franais 20 28
Italiano 29 37 Deutsch 38 46 English 47 User Guide English Introduction Thank you
for purchasing the LC...


lang:en **score:57** filesize: 7.12 M page_count: 48 document date: 2021-12-02



[\[pdf\]](#) User Manual Specifications Documentation Guide Warranty

LC6000 PRIME User Guide Denon DJ 1 4 Downloads für Equipment de v1 denon dj 2023 03 |||
IDEI I I I ID_J LCZSOOO IEEIEEEE User Guide Gua del usuario Guide d utilisation
Guida per l uso Ben ... tsch 43 52 English 54 2 User Guide English Introduction Thank
you for purchasing the **LC6000** PRIME. At Denon DJ, we know how serious music is
to you. That s why we design our equipment w...

lang:en **score:54** filesize: 8.09 M page_count: 56 document date: 2023-03-06



[\[pdf\]](#) User Manual Specifications Documentation Guide Warranty

LC6000 PRIME User Guide Denon DJ home httpd data media 1 c3 zzounds


148d0a3ce7a8decf98abc94dfb71f934 |||

User Guide Gua del usuario Guide d utilisation Guida per l uso Benutzerhandbuch

Appendix English 3 12 Espao 13 22 Franais 23 32 Italiano 33 42 Deutsch 43 52

English 54 2 User Guide English Introduction Thank you for purchasing the **LC6000** PRIME. At Denon DJ, we kn...

lang:en **score:53** filesize: 7.95 M page_count: 56 document date: 2021-12-30



[Denon DJ LC6000 PRIME User Guide: Features, Setup, and Operation](#)

Comprehensive user guide for the Denon DJ LC6000 PRIME layer controller, covering features, setup instructions, connection diagrams, and operational details for DJs. Learn about performance controls, syncing, and pad modes.

lang:en **score:52** filesize: 7.13 M page_count: 48 document date: 2021-04-27




[\[pdf\]](#) Guide

User Guide Denon DJ LC6000 PRIME Performance Expansion Controller Product Overview Summary

US proacousticsusa media wysiwyg |||

PERFORMANCE EXPANSION CONTROLLER Dedicated sub-layer control for SC6000, SC6000M, SC5000, SC5000M ... **OUR CREATIVITY** Inheriting the same DNA from the ultimate club experience SC6000 PRIME, the Denon DJ **LC6000 PRIME** is the world s most versatile DJ controller. Bringing professional club style layout, d...

lang:en **score:51** filesize: 169.92 K page_count: 2 document date: 2021-03-18




[\[pdf\]](#) User Manual Guide

PRIME 4 2 GO SC LIVE User Guide Denon DJ MANUALDenon Live Dj Controllerdenon dj sc live series manualmetroaudiosystems gr manuals denon manual |||

User Guide English Manual Version v2.3.3 Table of Contents Introduction

..... d then press the Deck 3 or Deck 4 buttons to switch between four-deck and two-deck operation. If an **LC6000** PRIME unit is connected to Rear USB Ports 3 and/or 4, the respective Deck button s will be d...

lang:fr **score:43** filesize: 18.32 M page_count: 88 document date: 2022-10-21




[\[pdf\]](#) User Manual Guide

PRIME 4 2 GO SC LIVE User Guide Denon DJ Prime Thomann Switzerland 568912 user guide v310 images static thomann de pics atg atgdata document manual |||

User Guide English Manual Version v3.1.0 Table of Contents Introduction

..... d then press the Deck 3 or Deck 4 buttons to switch between four-deck and two-deck operation. If an **LC6000** PRIME unit is connected to Rear USB Ports 3 and/or 4, the respective Deck button s will be d...

lang:fr **score:42** filesize: 19.63 M page_count: 97 document date: 2023-05-30



[\[pdf\]](#) User Manual Instructions Guide

User Guide PRIME 4 2 GO SC LIVE Denon DJ manual EN DENON ePRODANCE cz 17 ott 2024 — To check eligibility and access the available content please register your product by following instructions below Prime SClive en v4 1 0 eprodance user documents related files cdn inmusicbrands denondj pgplus |||

User Guide English Manual Version v4.1.0 Table of Contents

Introduction..... d then press the Deck 3 or Deck 4 buttons to switch between four-deck and two-deck operation. If an **LC6000** PRIME unit is connected to Rear USB Ports 3 and/or 4, the respective Deck button s will be d...

lang:de **score:40** filesize: 17.88 M page_count: 106 document date: 2024-09-17

DENON DJ

PRIME 4
PRIME 4+
PRIME 2
PRIME GO
PRIME GO+
SC LIVE 4
SC LIVE 2

User Guide
English

Manual Version v4.3.0

[\[pdf\]](#) User Manual Guide

User Guide PRIME 4 2 GO SC LIVE Denon DJ Prime White United States 590282 prime go sc live user guide v4 3 0 fast images static thomann de pics atg atgdata document manual |||

User Guide English Manual Version v4.3.0 Table of Contents

Introduction..... d then press the Deck 3 or Deck 4 buttons to switch between four-deck and two-deck operation. If an **LC6000** PRIME unit is connected to Rear USB Ports 3 and/or 4, the respective Deck button s will be d...

lang:de **score:39** filesize: 17.9 M page_count: 107 document date: 2025-03-18

DENON DJ

PRIME 4
PRIME 4+
PRIME 2
PRIME GO
SC LIVE 4
SC LIVE 2

User Guide
English

Manual Version v3.1.0

[Denon DJ PRIME Series User Guide: PRIME 4, PRIME 4+, PRIME 2, PRIME GO, SC LIVE 4, SC LIVE 2](#)

Comprehensive user guide for Denon DJ's PRIME series digital DJ controllers, including PRIME 4, PRIME 4+, PRIME 2, PRIME GO, SC LIVE 4, and SC LIVE 2. Covers features, operation, setup, and technical specifications.

lang:fr **score:38** filesize: 7.1 M page_count: 97 document date: 2023-06-26

DENON DJ

PRIME 4
PRIME 2
PRIME GO
SC LIVE 4
SC LIVE 2

User Guide
English

Manual Version v2.3.3


[\[pdf\]](#) User Manual Documentation Guide

PRIME 4 2 GO SC LIVE User Guide Denon DJ Download Software manuals and documentation DENON AYTONOMO ΣΥΣΤΗΜΑ Controllers DJShop v2 3 cdn inmusicbrands denondj djshop gr Attachment DownloadFile Id 15644 |||

User Guide English Manual Version v2.3.3 Table of Contents Introduction

..... d then press the Deck 3 or Deck 4 buttons to switch between four-deck and two-deck operation. If an **LC6000** PRIME unit is connected to Rear USB Ports 3 and/or 4, the respective Deck button s will be d...

lang:fr **score:37** filesize: 18.32 M page_count: 88 document date: 2022-10-21




[\[pdf\]](#) User Manual Guide

PRIME 4 2 GO User Guide Denon DJ home httpd data media 6 c3 zzounds
6051fff8da518fc4b2e1b1a7761e7c1a |||

User Guide English Manual Version v2.1.0 Table of Contents Introduction

..... d then press the Deck 3 or Deck 4 buttons to switch between four-deck and two-deck operation. If an **LC6000** PRIME unit is connected to Rear USB Ports 3 and/or 4, the respective Deck button s will be d...

lang:fr **score:35** filesize: 16.42 M page_count: 67 document date: 2021-12-16



[\[pdf\]](#) User Manual Guide

PRIME 4 2 GO SC LIVE User Guide Denon DJ EN Downloads für Equipment de v2 0 denon dj 2023 03
|||

IDEI IC I I ID_J I=IQII /IE 4I=I II /IE E I=I II /IE EC EC LIVE fil EC LIVE E User Guide English ... d then press the Deck 3 or Deck 4 buttons to switch between four-deck and two-deck operation. If an **LC6000** PRIME unit is connected to Rear USB Ports 3 and/or 4, the respective Deck button s will be d...

lang:fr **score:35** filesize: 18.67 M page_count: 89 document date: 2023-03-06




[\[pdf\]](#) Guide Accessories


Denon DJ LC6000 Prime Full Compass Systems Connect your Serato hardware as per normal into an available USB port on computer 2 the to via cable or hub 60899-LC6000PRIMEQuickStartGuide fullcompass common files

Denon DJ **LC6000** Prime Quick-Start Guide 1 Setup Installation, Firmware and Setup The Denon DJ **LC6000** Prime is a class compliant Serato Official Accessory , for Mac Windows. Each Denon DJ **LC6000** Prime media player used with Serato DJ Pro in Internal mode, requires a USB cable, a spare USB port, ...


lang:en **score:34** filesize: 8.93 M page_count: 8 document date: 2021-04-27




[\[pdf\]](#) User Manual Guide
PRIME 4 2 GO SC LIVE User Guide Denon DJ SCLIVE2UserGuide soundpro content product documents
|||
User Guide English Manual Version v2.4.0 Table of Contents Introduction
..... d then press the Deck 3 or Deck 4 buttons to switch between four-deck and two-deck operation. If an **LC6000** PRIME unit is connected to Rear USB Ports 3 and/or 4, the respective Deck button s will be d...
lang:fr **score:34** filesize: 18.68 M page_count: 89 document date: 2022-11-23



[\[pdf\]](#) User Manual Guide
PRIME 4 2 GO SC LIVE User Guide Denon DJ Download Prime Deck Standalone Controller For Computer Free Performances user manual at Juno Records junoco.uk 951248 01U ||| ||| User Guide English Manual Version v3.1.0 Table of Contents Introduction . 5 Support 5 Product Registration .5 Devices File Analysis 6 Configuration . 6 Features 7 PRIME 4 / PRIME 4 7 Top Panel 7 Front Panel 12 Rear Panel 12 PRIME 2 14 Top P
User Guide English Manual Version v3.1.0 Table of Contents Introduction
..... d then press the Deck 3 or Deck 4 buttons to switch between four-deck and two-deck operation. If an **LC6000** PRIME unit is connected to Rear USB Ports 3 and/or 4, the respective Deck button s will be d...
lang:fr **score:34** filesize: 19.64 M page_count: 97 document date: 2023-06-20



[\[pdf\]](#) User Manual Guide
User Guide PRIME 4 2 GO SC LIVE Denon DJ Console Tutto in uno DENON Live
4313100008684d1a6b70787promusicbari it products images 313100008684d1a6b70787 MANUALDenon White ControllerConsole 44701321 sc live white manualmetroaudiosystems gr manuals 4701321 manualpromusicbari MANUALMANUALDenon ControllerDenon manual4701321 manualdjmania 313100008684d1a6b70787metroaudiosystems manual 4Console Prime manual306020408684d1aa648fddmetroaudiosystems 306020408684d1aa648fdd ||| ||| User Guide English Manual Version v4.3.0 Table of Contents Introduction 4 Operation . 33 Support 4 Product Registration . 4 Configuration . 4 Devices File Analysis 5 Features . 6 PRIME 4 / PRIME 4 6 Top Panel 6 Front Panel . 11 Rear Panel . ||| User Guide English Manual Version v4.3.0 Table of Contents Introduction 4 Operation . 33 Support 4 Product Registration . 4 Configuration . 4 Devices File Analysis 5 Features . 6 PRIME 4 / PRIME 4 6 Top Panel 6 Front Panel . 11 Rear Panel . ||| User Guide English Manual Version v4.3.0 Table of Contents Introduction 4 Operation . 33 Support 4 Product Registration . 4 Configuration . 4 Devices File Analysis 5 Features . 6 PRIME 4 / PRIME 4 6 Top Panel 6 Front Panel . 11 Rear Panel . ||| User Guide English Manual Version v4.3.0 Table of Contents Introduction 4 Operation . 33 Support 4 Product Registration . 4 Configuration . 4 Devices File Analysis 5 Features . 6 PRIME 4 / PRIME 4 6 Top Panel 6 Front Panel . 11 Rear Panel .
User Guide English Manual Version v4.3.0 Table of Contents
Introduction..... d then press the Deck 3 or Deck 4 buttons to switch between four-deck and two-deck operation. If an **LC6000** PRIME unit is connected to Rear USB Ports 3 and/or 4, the respective Deck button s will be d...
lang:de **score:32** filesize: 17.9 M page_count: 107 document date: 2025-03-18




[\[pdf\]](#)

Pavel Janeček PRODANCE Uživatelský manuál CZ DENON DJ LC6000 Prime ePRODANCE cz Denon eprodance user documents related files PRIME navody |||

LC6000 Prime Nvod k obsluze vod Vlastnosti: Kontrolr pro pehrvace Denon ady Prime 8,5-palcov robustn kovov tal s nastavenm mechanickho odporu HD displej na stedu tale 8 multifunkcnch Pad tlactek pro rychl spoustn funkc 100 mm pitch fader USB napjen Kompatibiln se software Virtual DJ Pro a Alg...

lang:hr **score:31** filesize: 680.61 K page_count: 11 document date: 2021-10-08




[\[pdf\]](#) User Manual Guide

PRIME 4 2 GO SC LIVE User Guide Denon DJ Rear USB Ports 3 Connect standard drives to these ports When a conventional length e g beats 8 etc when you v1bax shop nl products 9000 0112 9635 prime go sc live user guide v3 1 |||

User Guide English Manual Version v3.1.0 Table of Contents Introduction d then press the Deck 3 or Deck 4 buttons to switch between four-deck and two-deck operation. If an **LC6000** PRIME unit is connected to Rear USB Ports 3 and/or 4, the respective Deck button s will be d...

lang:fr **score:31** filesize: 19.63 M page_count: 97 document date: 2023-05-30




[\[pdf\]](#) User Manual Guide

PRIME 4 2 GO SC LIVE User Guide Denon DJ Handbuch 10 54 MBDenon Live System Musikhaus280519 mcdn korn eu documents product 280519 m |||

User Guide English Manual Version v3.1.0 Table of Contents Introduction d then press the Deck 3 or Deck 4 buttons to switch between four-deck and two-deck operation. If an **LC6000** PRIME unit is connected to Rear USB Ports 3 and/or 4, the respective Deck button s will be d...

lang:fr **score:31** filesize: 10.54 M page_count: 97 document date: 2023-11-28



[Denon DJ PRIME 4, PRIME 4+, PRIME 2, PRIME GO, SC LIVE 4, SC LIVE 2 User Guide](#)

Comprehensive user guide for Denon DJ's PRIME 4, PRIME 4+, PRIME 2, PRIME GO, SC LIVE 4, and SC LIVE 2 DJ controllers. Learn about features, operation, settings, and technical specifications.

lang:fr score:29 filesize: 5.63 M page_count: 97 document date: 0000-00-00

[\[pdf\] User Manual Instructions Guide](#)

User Guide PRIME 4 2 GO SC LIVE Denon DJ Note Bluetooth audio may transmit with a small amount of latency Particularly if you are using both wired and wireless output at the same time 90635

PRIME4PRIME4PRIME2PRIMEGOPRIMEGOSCLIVE4SCLIVE2UserGuidev410fullcompass common files 90635 PRIME4PRIME4PRIME2PRIMEGOPRIMEGOSCLIVE4SCLIVE2UserGuidev410 srsItd

AfmBOorwMNVYZaNHQ 2Gs5km1m6aB8QgFuC5twS7UQoaQuiZDrpa8d0V time To check eligibility access available content please register your product by following instructions belowfullcompass 2Gs5km1m6aB8QgFuC5twS7UQoaQuiZDrpa8d0Vfullcompass AfmBOord9 QodRi hMh6HFXe6E iZWadzy7BULMvWH6FJVWwq512tNI belowTap Source icon to show list sources then tap select When Main Out is selected as assignment will be fullcompass

iZWadzy7BULMvWH6FJVWwq512tNIfullcompass AfmBOopH

4Oz31WoybJINOq9NvMNLX9TKn550WsB7hmvWSj4pALtNEHT be 21 Sweep FX Buttons Press one these buttons enable or disable an effect that can control knobs Only can v1fullcompass

4Oz31WoybJINOq9NvMNLX9TKn550WsB7hmvWSj4pALtNEHTfullcompass AfmBOoqg 8PtiWyt5B17Wb giBteao8w6wdU BN7H6GQAdy4tjqS9DFN Mode d emploiNote can Denon Prime Go Algam

Webstorev1f0ba481dba97afd1e0e62c82a4cc557fb822b77e v4fullcompass

BN7H6GQAdy4tjqS9DFNalgam akeneo prod s3 eu west 3 amazonaws public products f b

f0ba481dba97afd1e0e62c82a4cc557fb822b77e v4 1 ||| ||| User Guide English Manual Version v4.1.0

Table of Contents Introduction 4 Operation . 33 Support 4 Product Registration . 4 Configuration . 4 Devices File Analysis 5 Features . 6 PRIME 4 / PRIME 4 6 Top Panel 6 Front Panel . 11 Rear Panel . |||

User Guide English Manual Version v4.1.0 Table of Contents Introduction 4 Operation . 33 Support 4 Product Registration . 4 Configuration . 4 Devices File Analysis 5 Features . 6 PRIME 4 / PRIME 4 6 Top

Panel 6 Front Panel . 11 Rear Panel . ||| User Guide English Manual Version v4.1.0 Table of Contents

Introduction 4 Operation . 33 Support 4 Product Registration . 4 Configuration . 4 Devices File Analysis 5 Features . 6 PRIME 4 / PRIME 4 6 Top Panel 6 Front Panel . 11 Rear Panel . ||| User Guide English


Manual Version v4.1.0 Table of Contents Introduction 4 Operation . 33 Support 4 Product Registration . 4 Configuration . 4 Devices File Analysis 5 Features . 6 PRIME 4 / PRIME 4 6 Top Panel 6 Front Panel . 11


Rear Panel .

User Guide English Manual Version v4.1.0 Table of Contents

Introduction..... d then press the Deck 3 or Deck 4 buttons to switch between four-deck and two-deck operation. If an **LC6000** PRIME unit is connected to Rear USB Ports 3 and/or 4, the respective Deck button s will be d...

lang:de score:29 filesize: 17.88 M page_count: 106 document date: 2024-09-17






[\[pdf\]](#) Specifications

LC6000 PRIME MIDI Specification v1 0 Denon DJ Midi Spezifikationen 1 Downloads für Equipment de
denon dj 2023 03 |||

IDEI IC I I ID_J LGSCDCJCJ mama MIDI Specification 1 v1.0 Scope This document describes the format of messages between the **LC6000 PRIME** and the PC/Mac Host. Inbound Send Messages **LC6000 PRIME** Control Send Control Ch. Play/Pause Cue Track Skip Previous Track Skip Next Beat Jump Back ...

lang:en **score:28** filesize: 187.95 K page_count: 9 document date: 2023-03-06



[\[pdf\]](#) User Manual Guide

User Guide At Denon DJ we know how serious music is to you That s why design PRIME 4 2 SC LIVE Press and hold Key Lock Sync on the C13M2m uVHL m media amazon images I |||

User Guide English Manual Version v4.3.0 Table of Contents

Introduction..... d then press the Deck 3 or Deck 4 buttons to switch between four-deck and two-deck operation. If an **LC6000 PRIME** unit is connected to Rear USB Ports 3 and/or 4, the respective Deck button s will be d...

lang:de **score:28** filesize: 5.45 M page_count: 107 document date: 0000-00-00




[\[pdf\]](#)

Herunterladen LC6000 Prime DJ Controller Denon PROKLANG GbR Product Overview Summary DE
shop proklang de WebRoot Sage Shops ProklangErfurt Webshop 608F D5FC 07C1 1482 117F 0A0C
05BA CD89 |||

PERFORMANCE EXPANSION CONTROLLER Dedizierte Sub-Layer Kontrolle fr
SC6000, SC6000M, SC5000, SC5000 ... n Track-Suche ber Touch-Strip USB-
betrieben, Plug Play ERWEITERTE DEINE KREATIVITT Der Denon DJ **LC6000 PRIME** ist der vielseitigste DJ-Controller der Welt und basiert auf der gleichen DNA wie das u...

lang:de **score:27** filesize: 170.7 K page_count: 2 document date: 2021-03-18



Machine Translated by Google

[\[pdf\]](#) User Manual

RANE FOUR560326 rane four product overview summaryimages thomann de pics atg atgdata document manual 560326 summary |||

ADVANCED FOUR-CHANNEL STEMS DJ CONTROLLER The world s most advanced Serato Stems DJ controller with ... decks, and the FOUR also supports external modular decks like the RANE TWELVE MKII and the Denon DJ **LC6000** for a full physical 4-deck mixing experience. FOCUS ON YOUR PERFORMANCE, NOT YOUR LAPTOP The ...

lang:en **score:24** filesize: 135.2 K page_count: 4 document date: 2023-02-03

DENON DJ

PRIME 4
PRIME 2
PRIME GO
SC LIVE 4
SC LIVE 2

Guida utente
Inglese

Manuale Versione v2.3.3

Machine Translated by Google

[\[pdf\]](#)

Manuale utente Denon DJ SC LIVE 4 Console mixer a canali streaming da Amazon Music Wi Fi casse compatibile con Serato Virtual it Strumenti Musicali B1bOExmfl9L m media amazon images I |||

Machine Translated by Google Guida utente Inglese Manuale Versione v2.3.3

Machine Translated by Go ... ti Deck 3 o Deck 4 per passare dal funzionamento a quattro banchi a quello a due banchi. Se un unit **LC6000** PRIME collegata alle porte USB posteriori 3 e/o 4, i rispettivi pulsanti del deck saranno di...

lang:it **score:24** filesize: 3.11 M page_count: 88 document date: 2023-05-15

DENON DJ

PRIME 4
PRIME 4+
PRIME 2
PRIME GO
SC LIVE 4
SC LIVE 2

Mode d'emploi
Anglais

Version manuelle v3.1.0

[\[pdf\]](#) Guide

Mode d emploi 26 feb 2024 — Merci avoir acheté votre matériel EngineOS Chez Denon DJ nous savons à quel point la musique est importante pour vous C pourquoi PRIME 4 2 GO SC LIVE User Guide FRANS bekafun fr attachment 50675693 80194336 Live Deck Standalone System with WiFi for Amazon Music Streaming |||

Machine Translated by Google Mode d emploi Anglais Version manuelle v3.1.0

Machine Translated by G ... outons Deck 3 ou Deck 4 pour basculer entre le fonctionnement quatre et deux platines. Si une unit **LC6000** PRIME est connecte aux ports USB arrire 3 et/ou 4, le s bouton s Deck correspondant s sero...

lang:fr **score:23** filesize: 8.11 M page_count: 77 document date: 2023-11-21

lang:nl score:18 filesize: 203.95 K page count: 5 document date: 0000-00-00

[illegible]

[\[pdf\]](#)

Decksaver Dreadbox Hades Erebus Dirigent Decksaver product list 202309 dirigent jp decksaver products wpdmdl 100417 refresh 6510c43a57d241695597626 |||

DECKSAVER <https://dirigent.jp/decksaver/> CDJ DJ Denon DJ Rane Reloop Stanton
Vestax Denon DJ ... C-XDJ1000 DS-PC-XDJ700 DS-PCFP-CDJ2000NEXUS DS-
PCFP-CDJ2000NXS2 DSLE-PC-AFXAMX DSLE-PC-XONEK2 DS-PC-**LC6000** DS-
PC-MC4000 DS-PC-MC6000MK2 DS-PC-MC7000 DS-PC-MCX8000 DS-PC-
PRIME4 DS-PC-PRIMEGO DS-PC-SCLI...

lang:nl score:18 filesize: 202.13 K page_count: 5 document date: 0000-00-00

[illegible][Decksaver Product Catalog - Protective Covers for DJ and Music Production Gear](#)

Explore the comprehensive Decksaver product catalog featuring protective covers for a wide range of DJ equipment, controllers, synthesizers, drum machines, samplers, and audio interfaces. Find the perfect cover for your gear from brands like Pioneer DJ, Denon DJ, Rane, Native Instruments, and more.

lang:i-klinton **score:18** filesize: 201.04 K page_count: 5 document date: 2023-05-18

[illegible]

[\[pdf\]](#)

Decksaver 2024 7 Native Instruments Traktor X1 MK3 Dirigent Decksaver product
list 202407 dirigent jp decksaver products wpdmdl 100417 refresh 66eb98c1463201726716097 |||

DECKSAVER <https://dirigent.jp/decksaver/> Denon DJ Rane Reloop Stanton Vestax
DS-PC-VL12 DS-P ... -XDJ700 DS-PCFP-CDJ2000NEXUS DS-PCFP-
CDJ2000NXS2 DSLE-PC-AFXAMX DSLE-PC-XONEK2 DS-PC-OMNISDUO DS-
PC-**LC6000** DS-PC-MC4000 DS-PC-MC6000MK2 DS-PC-MC7000 DS-PC-
MCX8000 DS-PC-PRIME4 DS-PC-PRIMEGO DS-PC-SCLI...

lang:nl score:18 filesize: 215.73 K page_count: 5 document date: 2024-07-12

