

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Nutrimill](#) /

› [NutriMill Smart Blend Personal Portable Blender Instruction Manual](#)

### Nutrimill Smart Blend

# NutriMill Smart Blend Personal Portable Blender Instruction Manual

Model: Smart Blend

## INTRODUCTION

The NutriMill Smart Blend Personal Portable Blender is designed for convenience and versatility, allowing you to prepare a variety of beverages and foods on the go. This manual provides essential information for the safe and efficient use, maintenance, and troubleshooting of your Smart Blend blender.



Image: The NutriMill Smart Blend Personal Portable Blender (clear cup) and its accompanying thermos (black).

## IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using the NutriMill Smart Blend blender. Failure to follow these safety guidelines may result in injury or damage to the appliance.

- **Sharp Blades:** The blender contains sharp blades. Handle with extreme care, especially during assembly, disassembly, and cleaning.
- **Electrical Safety:** Do not immerse the motor base in water or other liquids. Ensure the charging port is dry before connecting the magnetic USB charging cable.
- **Children:** Keep the appliance out of reach of children. This appliance is not intended for use by children.
- **Hot Liquids:** Do not blend hot liquids. Allow ingredients to cool before blending to prevent pressure buildup and potential injury.

- **Overfilling:** Do not exceed the maximum fill line (300ml capacity) to prevent leaks and ensure proper blending.
- **Foreign Objects:** Ensure no foreign objects are in the blending cup before operation.
- **Damage:** Do not operate the blender if the cord, plug, or any part of the appliance is damaged. Contact customer support for assistance.
- **Charging:** Use only the provided magnetic USB charging cable.

## PACKAGE CONTENTS

---

Upon opening your NutriMill Smart Blend package, verify that all the following components are present:

- Blender Motor Base with Blades
- Mixing Cup (300ml capacity)
- Cup Lid (with flip top)
- Thermos
- Tea Filter
- Coffee Filter
- Magnetic USB Charging Cable



Image: All included parts of the NutriMill Smart Blend system, including the blender base, cups, and filters.

## SETUP

### Initial Charging

1. Before first use, fully charge the blender motor base. Connect the magnetic USB charging cable to the charging port on the motor base.
2. Connect the other end of the USB cable to a compatible USB power adapter (not included) or a computer USB port.
3. The charging indicator light will illuminate. Charging typically takes 3-5 hours.
4. Once fully charged, disconnect the charging cable.

## Assembly

1. Ensure the blender motor base is clean and dry.
2. Add your desired ingredients to the mixing cup. Do not exceed the 300ml capacity.
3. Carefully align the blender motor base with the mixing cup and twist clockwise until securely fastened. Ensure a tight seal to prevent leaks.
4. Alternatively, for tea or coffee, attach the appropriate filter to the cup lid, then secure the lid to the mixing cup or thermos.

## OPERATING INSTRUCTIONS

---

### Blending Smoothies and Shakes

1. Prepare your ingredients and place them into the mixing cup. For best results, cut larger fruits and vegetables into smaller pieces.
2. Securely attach the blender motor base to the mixing cup.
3. Invert the blender so the motor base is at the top. This allows gravity to assist in blending.
4. Press the power button on the motor base to start blending. The blender operates at 18000 RPM.
5. Blend for short intervals, typically up to 40 seconds per cycle. The blender has a safety shut-off time of  $\leq$  40 seconds. If ingredients are not fully blended, shake the cup gently and restart.
6. Once blending is complete, turn the blender upright, detach the motor base, and replace it with the cup lid for on-the-go consumption.



Image: Close-up of the blender's motor base, showing the sharp stainless steel blades.

## Grinding Coffee Beans

1. Place a small amount of coffee beans into the mixing cup. Do not overfill.
2. Securely attach the blender motor base.
3. Invert the blender and press the power button to grind. Use short pulses to achieve desired consistency.
4. After grinding, detach the motor base. You can then use the coffee filter with the cup lid for brewing.



Image: The coffee filter component, designed for brewing freshly ground coffee.

## Making Tea

1. Place loose leaf tea or tea bags into the tea filter.
2. Attach the tea filter to the cup lid.
3. Fill the mixing cup or thermos with hot water (ensure water is not boiling to avoid damage).
4. Securely attach the lid with the tea filter to the cup.
5. Allow the tea to steep for the desired time, then remove the lid and filter.



Image: The tea filter component, used for steeping loose leaf tea.

## MAINTENANCE AND CLEANING

---

Regular cleaning ensures the longevity and hygienic operation of your NutriMill Smart Blend blender.

- **Motor Base:** Wipe the motor base with a damp cloth. **Do not immerse the motor base in water or any other liquid.**
- **Mixing Cup, Lid, Filters:** These components are generally safe for hand washing with warm, soapy water. Rinse thoroughly and allow to air dry.
- **Blades:** Exercise extreme caution when cleaning the blades. Use a brush to remove any food residue.

- **Storage:** Store the blender and its components in a clean, dry place when not in use.

## TROUBLESHOOTING

If you encounter issues with your NutriMill Smart Blend blender, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not turn on.	Battery is low or depleted. Motor base not securely attached.	Charge the blender for 3-5 hours. Ensure the motor base is twisted tightly onto the cup.
Blender stops during operation.	Safety shut-off activated (max 40 seconds). Overloaded with ingredients. Ingredients are too large or frozen solid.	Restart the blender. Reduce the amount of ingredients. Cut ingredients into smaller pieces or add more liquid.
Blender is leaking.	Lid or motor base not securely fastened. Gasket is improperly seated or damaged. Overfilled cup.	Ensure all components are tightly sealed. Check the gasket for proper placement and damage. Replace if necessary. Do not exceed the 300ml capacity.
Ingredients are not blending smoothly (e.g., protein powder).	Insufficient liquid. Ingredients stuck to the sides. Motor power insufficient for dense ingredients.	Add more liquid. Shake the blender gently during operation or pulse. Ensure ingredients are suitable for a personal portable blender.

## SPECIFICATIONS

- **Model:** Smart Blend
- **Capacity:** 300 Milliliters
- **Rated Power:** 90W
- **RPM:** 18000r/min
- **Battery Type:** Lithium-ion
- **Battery Capacity:** 200mAh
- **Charging Time:** 3-5 hours
- **Safety Shut-Off Time:** ≤ 40 seconds
- **Power Source:** Battery Powered (USB Rechargeable)
- **Special Features:** Lightweight, Portable
- **Included Components:** Blender, Cup Lid, Tea Filter, Coffee Filter, Mixing Cup, Thermos, Magnetic USB Charging Cable

## WARRANTY INFORMATION

The NutriMill Smart Blend Personal Portable Blender comes with a **1-Year Limited Warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from misuse, accident, alteration, or unauthorized repair. Please retain your proof of purchase for warranty claims.

## CUSTOMER SUPPORT

For further assistance, troubleshooting, or warranty inquiries, please contact NutriMill customer support. You can find more information and contact details by visiting the official NutriMill store:

[Visit the NutriMill Store](#)

© 2023 NutriMill. All rights reserved.

## Related Documents - Smart Blend

	<p><a href="#">NutriMill Classic Quick Start Guide: Operation and Care</a></p> <p>A comprehensive quick start guide for the NutriMill Classic grain mill, covering setup, operation, cleaning, and texture control for optimal flour milling. Includes support information.</p>
	<p><a href="#">Tefal Blend Up BL19H4 User Manual and Safety Guide</a></p> <p>Comprehensive guide for the Tefal Blend Up BL19H4 personal blender, covering safe operation, usage instructions, maintenance, and troubleshooting.</p>
	<p><a href="#">Wonderchef Nutri-blend CKM Complete Kitchen Machine User Manual</a></p> <p>Comprehensive user manual for the Wonderchef Nutri-blend CKM Complete Kitchen Machine. Includes important safety guards, parts diagram, operating instructions for blending, grinding, juicing, and chopping, cleaning and maintenance guidelines, and detailed specifications.</p>



### [Breville Blend Active Personal Blender: User Manual, Features, Recipes & Safety](#)

Comprehensive guide to the Breville Blend Active Personal Blender (models VBL246, VBL248, VBL249), covering product features, safety instructions, usage, delicious recipes, cleaning, storage, troubleshooting, and electrical safety information.



### [Breville Blend Active FAQ - Troubleshooting and Usage Guide](#)

Frequently Asked Questions for the Breville Blend Active personal blender, covering topics like spare parts, blending times, ice crushing, BPA safety, overheating, dishwasher compatibility, and blending hot foods.



### [Gourmia Digital Blender User Manual GPB3125](#)

User manual for the Gourmia Digital Blender, model GPB3125. Includes important safeguards, assembly instructions, operating procedures, cleaning and maintenance tips, and warranty information.

## Documents - Nutrimill – Smart Blend



### [\[pdf\] User Manual](#)

SMART BLEND nutrimill 2 Congratulations On your new Smart Blend™ portable drink set Please read through this entire manual before first use and keep for future reference So that you may enjoy NutriMill® product years to come Blend User Manual 2021 web 10 |||

**SMART BLEND™ USER MANUAL** 1 Congratulations On your new **Smart Blend™** portable drink set. Please read through this entire manual before first use and keep for future reference. So that you may enjoy your new NutriMill product for years to come.

**2 IMPORTANT SAFEGUARDS** 1. Before using the NutriMi...


lang:en score:43 filesize: 6.93 M page\_count: 12 document date: 2021-10-07



[\[pdf\]](#) Accessories Catalog

WHEAT GRINDER NUTRIMILL GRAIN MILL HS4 3 10AMP 120 60HZ2017 catalog 2410029zznlrcdn ckitchen img brands caafeb63 633b 483d ae85 94bb0629541a 2017 2410029zznlr 60HZWHEAT 2410029zznlr2017 2410029zznlrkitchen viewer html url https cdn Product Catalog 2017WHEAT dl 1ckitchen |||

Product Catalog 2017 TABLE OF CONTENTS BOSCH KITCHEN MACHINES Universal Plus Kitchen Mixer..... Blenders Juicers 2017 26 BOSCH Kitchen Machines NutriMill bamix L EQUIP Pensofal RPM **SMART BLEND** Item: 306200 Watts: 500 The RPM Smart blend s custom build has more power, runs coole... lang:de **score:23** filesize: 2.57 M page\_count: 32 document date: 2017-03-16



[\[pdf\]](#) Accessories Catalog

Making Memories from Scratch NET Includes 3 discs reversible fine coarse grating shredding thick thin slicing and French fry disc Magimix Fluted Disc food 75996291 75f4 4696 b0ac 8131a1cee6b5 housewares blob core windows net exhdif original |||

Product Catalog 2018 Making Memories from Scratch TABLE OF CONTENTS Bosch Kitchen Machines Univer ... use only on deep trays Item: 306260 Mesh Inserts 2pk Product Catalog 2018 31 Blenders RPM **SMART BLEND** Item: 306200 Watts: 1,400 The RPM Smart blend s custom build has more power, runs cool... lang:en **score:18** filesize: 3.2 M page\_count: 36 document date: 2018-03-05