

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [FIIL](#) /

› [FIIL CC2 True Wireless Earbuds User Manual](#)

FIIL CC2

FIIL CC2 True Wireless Earbuds User Manual

Model: CC2 | Brand: FIIL

1. INTRODUCTION

This manual provides comprehensive instructions for the operation and maintenance of your FIIL CC2 True Wireless Earbuds. Designed for seamless audio experience, these earbuds feature Bluetooth 5.2 connectivity, active noise cancellation, and a durable sweatproof and waterproof design, compatible with both iPhone and Android devices.

2. WHAT'S IN THE BOX

- FIIL CC2 True Wireless Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- User Manual



Image: The complete package contents of the FIIL CC2 earbuds, showing the earbuds, their charging case, a USB-C charging cable, and the instruction manual.

3. SETUP

3.1 Charging the Earbuds and Case

Before first use, fully charge your FIIL CC2 earbuds and charging case. Connect the provided USB-C cable to the charging port on the case and to a compatible USB power source. The indicator lights on the case will show the charging status. A full charge provides up to 6 hours of listening time for the earbuds and an additional 32 hours with the charging case. A quick 5-minute charge can provide up to 1 hour of listening time.

32-Hour Playtime

5 Minutes Charge = 1 Hour Songs



32 Hours
Charging Box



5 Hours
Earphones



Image: An illustration demonstrating the 32-hour total playtime with the charging case and 5 hours for the earbuds on a single charge, highlighting quick charge capability.

3.2 Pairing with Your Device

The FIIL CC2 earbuds feature one-step automatic pairing. Simply remove the earbuds from the charging case, and they will automatically enter pairing mode. On your device (smartphone, tablet, etc.), enable Bluetooth, search for "FIIL CC2" in the list of available devices, and select it to connect. Once paired, the earbuds will automatically connect to your device when removed from the case.

One-Second Automatic Pairing



Image: A visual representation of the FIIL CC2 earbuds automatically pairing via Bluetooth 5.2 to a smartphone, showing the "FIIL CC2" device name in the Bluetooth settings.

4. OPERATING INSTRUCTIONS

4.1 Touch Controls

The FIIL CC2 earbuds are equipped with touch-sensitive controls for easy management of your audio and calls. Specific touch gestures can be customized via the FIIL+ App. By default, common controls include:

- **Double Tap:** Play/Pause music, Answer/End call.
- **Hold 2s:** Activate Voice Assistant, Reject Call.

For advanced controls like volume adjustment and track switching, enable "Full Control Mode" within the FIIL+ App.

4.2 FIIL+ App Usage

Enhance your experience by downloading the FIIL+ App, available for both iOS and Android. The app provides access to additional features and customization options:

- **15 Types of EQ Sound Modes:** Tailor your audio experience with various equalizer presets.
- **3 Low Latency Modes:** Optimize for gaming, video, or music to reduce audio delay.

- **Touch Sensitivity Control:** Adjust the responsiveness of the touch controls.
- **Easy or Full Control Mode:** Switch between simplified and advanced touch control schemes.
- **Battery Level Display:** Monitor the battery status of each earbud and the charging case.
- **Firmware OTA:** Receive over-the-air firmware updates for improved performance.

SUPPORT FIIL+ APP



15 Types of
EQ Sound Modes



3 Low
Latency Modes



Touch Sensitivity
Control



Easy or Full
Mode Choice



Image: A smartphone screen displaying the FIIL+ App interface, illustrating various sound modes, low latency options, and touch control settings for the FIIL CC2 earbuds.

Latest Bluetooth 5.2

Pick up and connect immediately.
Get more stable connection and less power use.



Image: The FIIL+ App interface on a smartphone, showcasing the power display for the earbuds and case, along with options for 15 EQ sound modes and 3 low latency modes.

5. FEATURES

- **Bluetooth 5.2:** Provides a stable and efficient wireless connection with lower power consumption.
- **Active Noise Cancellation (ENC):** Environmental Noise Cancellation technology reduces ambient noise for clearer calls and immersive audio.
- **Waterproof & Sweatproof:** Designed to withstand splashes of water and sweat, making them suitable for workouts and outdoor activities.
- **Long Battery Life:** Up to 6 hours of playtime on a single charge, extended to 32 hours with the portable charging case.
- **13.1mm Dynamic Drivers:** Deliver high-quality stereo sound for an immersive audio experience.
- **Magnetic Design:** Earbuds securely fit into the charging case.

Noise Cancelling

ENC Noise Cancellation



Image: A visual representation of the FIIL CC2 earbuds' Environmental Noise Cancelling (ENC) feature, showing its effectiveness in different noisy environments.

Sweatproof & Waterproof



Image: The FIIL CC2 earbuds and their charging case are depicted with water droplets, illustrating their sweatproof and waterproof design.

6. SPECIFICATIONS

Feature	Detail
Brand	FIIL
Model Name	CC2
Connectivity Technology	Wireless (Bluetooth 5.2)
Wireless Communication Technology	Bluetooth
Noise Control	Active Noise Cancellation (ENC)
Battery Life (Earbuds)	6 Hours
Battery Life (with Case)	32 Hours
Quick Charge	5 minutes charge for 1 hour playtime

Water Resistance Level	Waterproof
Audio Driver Size	13.1 Millimeters
Material	Metal
Control Method	App, Touch Control
Compatible Devices	Cellphones, Laptops, Desktops, Tablets
Item Weight	2.11 Ounces
Product Dimensions	3.94 x 3.94 x 3.94 inches

7. MAINTENANCE

To ensure the longevity and optimal performance of your FIIL CC2 earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly wipe the earbuds and charging case with a soft, dry, lint-free cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the earbuds in their charging case when not in use to protect them from dust and damage.
- **Avoid Extreme Conditions:** Do not expose the earbuds or case to extreme temperatures, high humidity, or direct sunlight for extended periods.
- **Water Exposure:** While waterproof, ensure the earbuds are completely dry before placing them back into the charging case to prevent damage to the charging contacts.

8. TROUBLESHOOTING

If you encounter any issues with your FIIL CC2 earbuds, try the following troubleshooting steps:

- **No Sound/Connection Issues:**
 - Ensure earbuds are charged.
 - Turn off and on Bluetooth on your device.
 - Forget "FIIL CC2" from your device's Bluetooth list and re-pair.
 - Restart your device.
- **App Not Connecting:**
 - Ensure earbuds are connected via Bluetooth to your phone first.
 - Restart the FIIL+ App.
 - Check for app updates.
- **Earbuds Falling Out During Activity:**
 - Ensure earbuds are properly seated in your ears. These are open-ear style earbuds and may not be suitable for high-impact activities without additional ear-securing accessories.

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included in your product packaging or visit the official FIIL website. The manufacturer is FIIL Jiangxi Feier Technology Co., Ltd.

10. OFFICIAL PRODUCT VIDEOS

Below are official product videos from the seller demonstrating key features and usage of the FIIL CC2 earbuds.

FIIL True Wireless Earbuds! They work GREAT!!!

Your browser does not support the video tag.

Video: A detailed review and demonstration of the FIIL CC2 True Wireless Earbuds, highlighting their features and performance.

CD-Quality FIIL CC2 Bluetooth Earbuds

Your browser does not support the video tag.

Video: An unboxing and overview of the FIIL CC2 Bluetooth Earbuds, showcasing their design, included accessories, and key functionalities.