

[Manuals.plus](#) /

› [Bestol](#) /

› Bestol AR-RY12 Remote Control User Manual for Fujitsu Air Conditioners

## Bestol AR-RY12

# Bestol AR-RY12 Remote Control User Manual for Fujitsu Air Conditioners

## 1. INTRODUCTION

This manual provides comprehensive instructions for the operation and maintenance of your Bestol AR-RY12 remote control, designed for use with various Fujitsu Air Conditioner models. Please read this manual thoroughly before using the remote control to ensure proper function and longevity.

Compatible Fujitsu Air Conditioner models include AR-RY3, AR-RY4, AR-RY6, AR-RY5, AR-RY11, AR-RY12, AR-RY1, AR-RY2, AR-RY7, AR-RY8, and AR-RY13.

## 2. SAFETY INFORMATION

- Do not mix old and new batteries.
- Do not mix different types of batteries (e.g., alkaline and rechargeable).
- Insert batteries with correct polarity (+ and -) as indicated in the battery compartment.
- Remove batteries if the remote control will not be used for an extended period to prevent leakage.
- Keep the remote control away from direct sunlight, heat sources, and moisture.
- Do not drop or subject the remote control to strong impacts.

## 3. PRODUCT OVERVIEW

The Bestol AR-RY12 remote control features a clear LCD display and ergonomically arranged buttons for intuitive operation of your Fujitsu air conditioner. Below is an illustration of the remote control's front panel and its key components.



**Figure 1:** Front view of the Bestol AR-RY12 remote control. It features a digital display at the top, showing temperature, clock, and operational status. Below the display are various control buttons, including power, mode selection, temperature adjustment, fan speed, and timer functions.

### Key Buttons and Functions:

- **START/STOP:** Powers the air conditioner on or off.
- **MASTER CONTROL:** Selects the operating mode (e.g., Auto, Cool, Dry, Fan, Heat).
- **FAN CONTROL:** Adjusts the fan speed.
- **SET TEMP. (Up/Down Arrows):** Increases or decreases the desired temperature.
- **AIR CLEAN:** Activates the air purification function (if available on your AC model).

- **COIL DRY:** Initiates the coil dry function to prevent mold growth.
- **SLEEP:** Activates sleep mode for comfortable nighttime operation.
- **SWING:** Controls the louver swing direction.
- **TIMER MODE:** Sets or cancels timer operations.
- **CLOCK ADJUST:** Adjusts the current time displayed on the remote.
- **TEST RUN:** For service or diagnostic purposes.
- **RESET:** Resets the remote control settings.

## 4. SETUP: BATTERY INSTALLATION

---

The remote control requires two AAA batteries (not included). Follow these steps to install them correctly:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the tab and lift to open it.
3. Insert two AAA batteries, ensuring that the positive (+) and negative (-) ends align with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



**Figure 2:** Back view of the remote control showing the battery compartment. The compartment specifies the use of AAA/R03/LR03x2 batteries and provides clear instructions for correct polarity alignment.

**Important Note:** The remote control displays temperature in Celsius only. There is no option to switch to Fahrenheit.

## 5. OPERATING INSTRUCTIONS

### 5.1 Power On/Off

- Press the **START/STOP** button once to turn the air conditioner on.
- Press the **START/STOP** button again to turn the air conditioner off.

## 5.2 Mode Selection

- Press the **MASTER CONTROL** button repeatedly to cycle through available operating modes: AUTO, COOL, DRY, FAN, HEAT (modes may vary depending on your AC unit).
- The selected mode will be displayed on the remote's LCD screen.

## 5.3 Temperature Adjustment

- Use the **SET TEMP.** up arrow button to increase the desired temperature.
- Use the **SET TEMP.** down arrow button to decrease the desired temperature.
- The temperature is displayed in Celsius.

## 5.4 Fan Speed Control

- Press the **FAN CONTROL** button to adjust the fan speed.
- Repeated presses will cycle through different fan speed settings (e.g., Low, Medium, High, Auto).

## 5.5 Timer Functions

- Press **TIMER MODE** to initiate timer settings.
- Use the **+** and **-** buttons to adjust the timer duration or time.
- Refer to your air conditioner's main manual for specific timer programming details.

## 5.6 Clock Adjustment

- Press the **CLOCK ADJUST** button.
- Use the **+** and **-** buttons (or similar temperature adjustment buttons) to set the correct time.
- Press **CLOCK ADJUST** again to confirm.

## 5.7 Special Functions

- **AIR CLEAN:** Activates the air purification feature.
- **COIL DRY:** Helps dry the indoor unit's coil to prevent mold and odors.
- **SLEEP:** Adjusts temperature and fan speed automatically for comfortable sleep.
- **SWING:** Controls the vertical movement of the air conditioner's louvers.
- **TEST RUN:** This button is typically for service technicians. Avoid pressing it during normal operation.
- **RESET:** Pressing this button (often a small recessed button requiring a pointed object) will reset the remote control to its default settings.

## 6. TROUBLESHOOTING

- **Remote not responding:**
  - Check if batteries are inserted correctly with proper polarity.
  - Replace old batteries with new AAA batteries.
  - Ensure there is a clear line of sight between the remote control and the air conditioner's receiver.
  - Make sure the remote control is within the effective operating range.
- **Display is dim or blank:**
  - Replace batteries.
- **Air conditioner not responding to commands:**
  - Verify that the air conditioner unit is powered on.

- Ensure the remote control is compatible with your specific Fujitsu air conditioner model.
- Try resetting the remote control (if a reset button is available).

## 7. SPECIFICATIONS

| Feature                 | Detail                                                                                                               |
|-------------------------|----------------------------------------------------------------------------------------------------------------------|
| Model Number            | AR-RY12                                                                                                              |
| Brand                   | Bestol                                                                                                               |
| Compatible Devices      | Fujitsu Air Conditioners (AR-RY3, AR-RY4, AR-RY6, AR-RY5, AR-RY11, AR-RY12, AR-RY1, AR-RY2, AR-RY7, AR-RY8, AR-RY13) |
| Connectivity Technology | Infrared                                                                                                             |
| Power Source            | 2 x AAA Batteries (not included)                                                                                     |
| Item Weight             | Approximately 2.57 ounces (72.86 grams)                                                                              |
| Package Dimensions      | 7.05 x 2.6 x 0.79 inches (17.9 x 6.6 x 2 cm)                                                                         |
| Special Feature         | Ergonomic design                                                                                                     |

## 8. WARRANTY AND SUPPORT

This product is typically covered by a standard manufacturer's warranty. For specific warranty details, returns, or technical support, please refer to the purchase documentation or contact the seller directly through the platform where the product was acquired.

Ensure you have your purchase details, including the order number and date of purchase, ready when contacting support.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

#### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B092ZFY27K>

More documents and user manuals: <https://manuals.plus/>