

[manuals.plus](#) /› [Mellerware](#) /› [Mellerware Brizy Bright Ceiling Fan User Manual](#)**Mellerware ES9440110L**

# Mellerware Brizy Bright Ceiling Fan User Manual

Model: ES9440110L

## 1. INTRODUCTION AND SAFETY INFORMATION

Thank you for choosing the Mellerware Brizy Bright Ceiling Fan. This manual provides essential information for the safe installation, operation, and maintenance of your new ceiling fan. Please read this manual thoroughly before installation and keep it for future reference.

### Important Safety Instructions:

- Always disconnect power at the main circuit breaker before installation, cleaning, or maintenance.
- Installation must be performed by a qualified electrician in accordance with all local and national electrical codes.
- Ensure the mounting structure can support the weight of the fan (approximately 6.65 kg).
- Do not insert objects into the path of the rotating blades.
- Keep children away from the fan during operation.
- This fan is designed for indoor use only.

## 2. PRODUCT OVERVIEW

The Mellerware Brizy Bright is a modern ceiling fan with an integrated LED light, designed to provide efficient air circulation and illumination. It features a silent DC motor, 6 speed settings, a timer, and a convenient remote control. Its reversible function allows for year-round use, cooling in summer and distributing heat in winter.



Figure 2.1: Mellerware Brizy Bright Ceiling Fan (Dark Wood model).

# POTENTE Y SILENCIOSO



POTENCIA  
**30W**

VELOCIDADES  
**6**

MOTOR  
**DC**

Figure 2.2: The Brizy Bright fan seamlessly integrated into a room setting.

## 3. SETUP AND INSTALLATION

Before beginning installation, ensure all components are present and undamaged. Refer to the included hardware kit for specific fasteners.

### Pre-installation Checklist:

- Verify that the ceiling junction box is securely mounted and rated for fan support.
- Ensure adequate clearance from walls and other obstructions (minimum 30 cm from blade tip to wall).
- Confirm power supply is off at the circuit breaker.

### Installation Steps:

1. **Mounting Bracket Installation:** Secure the mounting bracket to the ceiling junction box using the provided screws.
2. **Wiring Connections:** Connect the fan's electrical wires to the household wiring according to the wiring

diagram provided in the separate installation guide. Ensure all connections are secure and insulated.

3. **Motor Assembly Attachment:** Carefully lift the fan motor assembly and hang it onto the mounting bracket hook.
4. **Blade Attachment:** Attach the three ultra-light wooden blades to the motor housing using the designated screws. Ensure they are firmly secured.
5. **Light Kit Installation:** Connect the LED light kit wiring to the fan's light wiring and secure the light kit to the bottom of the fan motor assembly.
6. **Canopy Installation:** Slide the canopy up to the ceiling and secure it to the mounting bracket, covering all wiring.



Figure 3.1: Detail of the fan's quality materials: ultralight wooden blades and aluminum body.

## 4. OPERATING INSTRUCTIONS

Your Mellerware Brizy Bright fan is operated via the included remote control. Ensure the remote has working batteries.

## Remote Control Functions:



Figure 4.1: The remote control for the Brizy Bright fan.

- **Power Button:** Turns the fan and light on/off.
- **Fan Speed (1-6):** Adjusts the fan speed from 1 (lowest) to 6 (highest).
- **Light Control:** Toggles the light on/off.
- **Light Temperature Adjustment:** Cycles through warm, neutral, and cold light temperatures.
- **Light Dimming:** Adjusts the intensity of the LED light.
- **Timer (2H, 4H, 8H):** Sets the fan to turn off automatically after 2, 4, or 8 hours.
- **Breeze Mode:** Activates a gentle, varying airflow to simulate a natural breeze.
- **Night Mode:** Operates the fan at a very low, quiet speed, ideal for sleeping.

## Summer/Winter Function:

The fan features a reversible motor for year-round comfort. This function is typically controlled via a switch on the fan's motor housing or the remote control (refer to specific remote instructions if applicable).

- **Summer Function (Counter-clockwise rotation):** Blades generate a downward airflow, creating a cooling breeze.
- **Winter Function (Clockwise rotation):** Blades create an upward airflow, circulating warm air accumulated near the ceiling throughout the room.

## UTILIZA TODO EL AÑO SUS DOS FUNCIONES




Figure 4.2: Illustration of the fan's dual summer and winter functions.



Figure 4.3: Adjustable LED light temperatures: Cold, Neutral, and Warm.

## 5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

### Cleaning:

- Always turn off the power at the circuit breaker before cleaning.
- Use a soft, damp cloth to wipe down the fan blades and motor housing.
- Do not use abrasive cleaners or solvents, as they may damage the finish.
- Periodically check and tighten all screws on the fan blades and mounting hardware.

### General Care:

- No lubrication is required for the DC motor.
- Ensure the fan is balanced to prevent wobbling. If wobbling occurs, check blade alignment and tightness.

## 6. TROUBLESHOOTING

If you experience issues with your Mellerware Brizy Bright fan, consult the following table for common problems and solutions.

Problem	Possible Cause	Solution
Fan does not start	No power supply Loose wire connections Remote control battery dead	Check circuit breaker Verify all wiring connections are secure Replace remote control batteries
Light does not work	Loose wire connection LED module failure	Check light kit wiring Contact customer support for replacement
Fan wobbles	Loose blade screws Unbalanced blades Loose mounting bracket	Tighten all blade screws Check blade balance and use balancing kit if necessary Ensure mounting bracket is securely fastened
Remote control not responding	Dead batteries Remote not paired Obstruction between remote and receiver	Replace batteries Refer to pairing instructions in separate guide Ensure clear line of sight to fan receiver
Excessive noise	Loose screws Motor housing rubbing Blade imbalance	Check and tighten all screws Ensure no parts are touching Balance blades

## 7. SPECIFICATIONS

Detailed technical specifications for the Mellerware Brizy Bright Ceiling Fan.

Feature	Specification
Brand	Mellerware
Model Number	ES9440110L
Color	Dark Wood
Product Dimensions	2.54 x 2.54 x 2.54 cm (Fan body); 132 cm (Diameter)
Power / Wattage	45 W (Fan), 30 W (Motor)
Voltage	230 Volts (AC)
Material	Wood (Blades), Aluminum (Body)
Number of Blades	3
Number of Speeds	6

Feature	Specification
Special Features	Quiet DC Motor, Integrated LED Light (Adjustable Temperature), Remote Control, Timer, Summer/Winter Function, Breeze Mode, Night Mode
Item Weight	6.65 Kilograms
Recommended Room Size	Up to 20 m <sup>2</sup>



Figure 7.1: Key performance specifications of the fan.



**MOTOR  
ULTRASILENCIOSO**

Figure 7.2: The fan features an ultra-silent DC motor for quiet operation.

## 8. WARRANTY AND SUPPORT


Mellerware products are manufactured to high-quality standards. For information regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your product or visit the official Mellerware website.

### **Customer Support:**

If you require technical assistance, have questions about your product, or need to report a defect, please contact Mellerware customer support. Contact details can typically be found on the product packaging, the official Mellerware website, or your purchase receipt.

Please have your model number (ES9440110L) and purchase date ready when contacting support.

## Related Documents - ES9440110L

	<p><a href="#">Mellerware Executiv Bravissimo II Pro Steam Station User Manual</a></p> <ul style="list-style-type: none"><li>Comprehensive user manual for the Mellerware Executiv Bravissimo II Pro Steam Station (Model 23810), detailing operation, safety warnings, maintenance, and troubleshooting.</li></ul>
	<p><a href="#">Mellerware Sauty! Frying Pan: User Guide and Safety Information</a></p> <p>Comprehensive user guide for the Mellerware Sauty frying pan, including essential safety warnings, care instructions, and warranty details. Available in multiple languages.</p>
	<p><a href="#">Mellerware Mixo Hand Mixer 26450 User Manual and Warranty Information</a></p> <p>Comprehensive user manual and warranty details for the Mellerware Mixo Hand Mixer (Model 26450), including safety instructions, operating procedures, cleaning, and troubleshooting. Covers extended warranty registration.</p>
	<p><a href="#">Mellerware Crunchy! Plus Air Fryer User Manual</a></p> <p>User manual for the Mellerware Crunchy! Plus Air Fryer. Includes safety instructions, operating guide, cleaning, and troubleshooting tips for healthy hot air cooking.</p>
	<p><a href="#">Mellerware Egg Master 350W Egg Boiler (Model 27006A) - User Manual and Warranty</a></p> <p>Comprehensive user manual and warranty information for the Mellerware Egg Master 350W Egg Boiler (Model 27006A). Learn how to use, clean, and register your appliance.</p>
	<p><a href="#">Mellerware Orion II Steam Iron - User Manual and Warranty Information</a></p> <p>Comprehensive guide to the Mellerware Orion II Steam Iron, covering warranty registration, usage instructions, safety precautions, cleaning, and maintenance. Includes details on the 3-year warranty program and product operation.</p>