

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Ceihoit](#) /

> [Ceihoit Super Mini DVD Player User Manual](#)

Ceihoit Ceihoit Super Mini (B092ZPZVNQ)

Ceihoit Super Mini DVD Player User Manual

Model: Ceihoit Super Mini (B092ZPZVNQ)

INTRODUCTION

Thank you for purchasing the Ceihoit Super Mini DVD Player. This compact and versatile device is designed to provide high-quality audio and video playback from various disc formats and USB devices. Please read this manual carefully before using the product to ensure proper operation and to maximize your viewing and listening experience.

SAFETY INFORMATION

- Do not expose the player to rain or moisture to prevent fire or electric shock.
- Do not block any ventilation openings. Ensure adequate space around the player for proper airflow.
- Use only the power supply specified by the manufacturer. The player requires a 5V 1.5A/2A power source. Do not use a PC's USB interface as the power source.
- Avoid placing the player on unstable surfaces.
- Do not open the casing. Refer all servicing to qualified service personnel.
- Keep the player away from direct sunlight, heat sources, and strong magnetic fields.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- Ceihoit Super Mini DVD Player
- Remote Control
- HDMI Cable
- AV Cable
- Micro USB Power Cable (Note: Power adapter is not included and must be 5V 1.5A/2A)

PACKAGE LIST

Mini DVD Player



Remote Control

Power Cable



Power Adapter



HDMI Cable



AV Cable



Figure 1: Included Package Contents

This image displays the complete set of items you should find in your Ceihoit Super Mini DVD Player package, including the player unit, its remote control, and all necessary connection cables for audio, video, and power.

PRODUCT OVERVIEW

The Ceihoit Super Mini DVD Player features a compact design for easy portability and integration into any entertainment setup. Below are key components and their functions.



Figure 2: Front and Rear Panel Layout

This image provides a detailed view of the DVD player's top surface, revealing the disc tray, control buttons, and the USB port. It also illustrates the various cables that come with the player, highlighting its connectivity options.

Compact Design

The player's dimensions are approximately 6 x 5.4 x 1.1 inches, and it weighs only 0.7 lbs, making it highly portable and space-saving.

PORTABLE COMPACT DESIGN

Except for home entertainment, you can also take it out for a great trip with your family



Figure 3: Compact Dimensions

This visual demonstrates the small footprint of the DVD player, showing its precise measurements and how it fits discreetly into a home entertainment environment or can be easily transported for travel.

SETUP

Powering the Device

The Ceihoit Super Mini DVD Player does not have a built-in battery and requires external power. It can be powered via a wall charger, power bank, or car charger using the included Micro USB power cable. Ensure your power source provides 5V at 1.5A to 2A for optimal performance.

POWERING ON ANYWHERE ANYTIME



Car charger



Wall Charger
(Adapter Included)



Power Bank



Figure 4: Multiple Power Supply Methods

This illustration highlights the versatile power options for the DVD player, demonstrating how it can be powered using a car charger, a standard wall adapter, or a portable power bank, offering flexibility for various usage scenarios.

Connecting to a TV

The player supports both HDMI and AV (RCA) output for connecting to your television or display.

HDMI Connection (Recommended for 1080P Upscaling)

1. Connect one end of the HDMI cable to the HDMI OUT port on the DVD player.
2. Connect the other end of the HDMI cable to an available HDMI IN port on your TV.
3. Select the corresponding HDMI input on your TV using its remote control.

HDMI CONNECTION

Enjoy movies and TV shows in your home providing an authentic cinematic experience.



Figure 5: HDMI Connection for Enhanced Visuals

This image illustrates the simple process of connecting the DVD player to a television using an HDMI cable, emphasizing the benefit of 1080P upscaling for a clearer picture quality compared to a general image.

AV (RCA) Connection

1. Connect the AV cable's yellow plug to the Video IN port on your TV, and the red and white plugs to the Audio R and L IN ports, respectively.
2. Connect the single 3.5mm jack end of the AV cable to the AV OUT port on the DVD player.
3. Select the corresponding AV input on your TV.

OPERATING INSTRUCTIONS

Disc Playback

The Ceihoit Super Mini DVD Player is region-free and supports a wide range of disc formats, including CD, DVD, DVD-R/+R, DVD-/+RW, CD-R/-RW, VCD, and SVCD.

1. Open the disc tray cover.
2. Place a compatible disc onto the spindle with the label side facing up.
3. Close the disc tray cover. The player will automatically begin reading the disc.
4. Use the remote control to navigate menus and control playback (Play, Pause, Stop, Skip, etc.).

ALL REGION FREE DVD PLAYER

Notes: This is not Blu-ray DVD Player



CPRM, CD, DVD, MP3, VCD
SVCD, DVD-R/+ RDVD-+RW
CD-R/-RW



AVI, DIVX, MPG
MPEG4, VOB

Figure 6: Region-Free Disc Compatibility

This graphic illustrates the player's ability to play discs from any region and lists the various disc formats it supports, ensuring broad compatibility for your media collection.

USB Input Playback

The player features a built-in USB 2.0 port for playing audio and video files directly from a USB stick (up to 16GB). Supported file formats include AVI, DIVX, MPG, MPEG4, and VOB for video, and MP3 for audio. JPEG/JPG for pictures. Note: USB 3.0 and MP4 files are not supported via USB.

1. Insert your USB 2.0 flash drive into the USB port on the player.
2. The player should automatically detect the USB drive and display its contents.

3. Use the remote control to browse and select your desired files for playback.



Figure 7: USB Input for Digital Media

This image demonstrates the convenience of the USB input, allowing users to play various digital media files directly from a USB flash drive, including pictures, music, and videos.

Built-in Speaker

The player includes a built-in speaker, allowing for direct audio playback without needing external speakers or a TV. This is ideal for personal use or in situations where external audio is not available.

PORTABLE DVD PLAYER WITH BUILT-IN SPEAKER

Enjoy crystal clear sound directly via the player whether you are at home or go outside



Figure 8: Built-in Speaker Functionality

This image illustrates the practical use of the built-in speaker, showing how the player can provide audio directly, making it suitable for various settings, including casual gatherings or personal listening.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the player. Do not use liquid cleaners or aerosol sprays. For the disc lens, use a specialized DVD lens cleaner disc.
- **Disc Care:** Handle discs by their edges. Keep them clean and free of scratches. Store discs in their cases when not in use.
- **Storage:** When not in use for extended periods, disconnect the power cable and store the player in a cool, dry place away from direct sunlight.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Player does not power on.	No power, insufficient power supply.	Ensure the Micro USB power cable is securely connected. Verify the power source provides 5V 1.5A/2A. Try a different power outlet or power source.
No picture on TV.	Incorrect input selected on TV, loose cable connection, faulty cable.	Check if the TV input is set to the correct HDMI or AV channel. Ensure HDMI/AV cables are securely connected to both the player and TV. Try a different cable.
No sound.	TV volume muted, incorrect audio settings, loose AV audio cables.	Increase TV volume. If using AV, ensure red and white audio cables are connected correctly. Check player's volume settings.
Disc does not play or spins continuously.	Disc is dirty, scratched, or incompatible format.	Clean the disc with a soft cloth. Try a different disc. Ensure the disc format is supported (not Blu-ray).
USB playback not working.	USB drive not detected, unsupported file format, USB drive too large.	Ensure USB drive is formatted correctly (FAT32). Check if files are in supported formats (AVI, DIVX, MPG, MPEG4, VOB, MP3, JPG). Use a USB 2.0 drive up to 16GB.

SPECIFICATIONS

Feature	Detail
Brand	Ceihoit
Model Name	Ceihoit Super Mini
ASIN	B092ZPZVNQ
Product Dimensions	6 x 5.4 x 1.1 inches
Item Weight	0.7 lbs
Color	Black
Media Type (Disc)	CD, CD-R, CD-RW, DVD, DVD-R, DVD-RW, DVD+R, DVD+RW, VCD, SVCD (Region Free)
Media Type (USB)	AVI, DIVX, MPG, MPEG4, VOB (Video); MP3 (Audio); JPG (Picture)
USB Support	USB 2.0 Flash Drive up to 16GB (Does not support USB 3.0 or MP4 files)
Resolution	1080P Upscaling (via HDMI)
Connector Type	HDMI, RCA, USB
Audio Output Mode	Surround/Stereo
Special Features	Compact, Portable, Built-in Speaker, Region Free
Power Requirement	5V 1.5A/2A (Micro USB cable included, adapter not included)

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your purchase or contact Ceihoit customer service directly. You can often find contact details on the manufacturer's official website or through the retailer where the product was purchased.

For inquiries regarding power adapters or other specific issues, you may contact the seller via message as mentioned in the product description.