

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ZEISS](#) /

› [ZEISS Terra ED 10x25 Binoculars and Cleaning Kit Bundle Instruction Manual](#)

ZEISS Terra ED 10x25

ZEISS Terra ED 10x25 Binoculars and Cleaning Kit Bundle Instruction Manual

Model: Terra ED 10x25

INTRODUCTION

This manual provides instructions for the proper use and maintenance of your ZEISS Terra ED 10x25 Compact Pocket Binoculars and the included ZEISS Spray and Microfiber Lens Care Kit. Please read these instructions carefully before using the products to ensure optimal performance and longevity.



Image: ZEISS Terra ED 10x25 Binoculars (front view).

ZEISS TERRA ED 10x25 BINOCULARS

1. Setup and Initial Adjustment

Before first use, adjust the binoculars to your individual eye distance and vision.

1. Adjusting Interpupillary Distance: Hold the binoculars with both hands and bend them at the hinge until you see a single, circular field of view. This adjusts the distance between the eyepieces to match your eyes.

2. Adjusting Diopter:

- Close your right eye.
- Look through the left eyepiece at a distant object.
- Rotate the central focusing wheel until the object appears sharp.
- Close your left eye.
- Look through the right eyepiece.
- Rotate the diopter adjustment ring (usually on the right eyepiece) until the object appears sharp.

- Now, with both eyes open, the image should be clear. Use only the central focusing wheel for subsequent focusing.



Image: Top view of binoculars showing focus wheel and diopter adjustment area.

2. Operating the Binoculars

The ZEISS Terra ED 10x25 binoculars are designed for clear observation across various distances.

- **Focusing:** Once the diopter is set, use the central focusing wheel to bring objects into sharp focus. The binoculars offer a wide field of view and a close focus distance of approximately 6.2 feet (1.9 meters), allowing for observation of nearby subjects as well as distant ones.
- **Eyecups:** Extend the eyecups for use without eyeglasses. Retract them if you wear eyeglasses to ensure a full field of view.



Image: Angled view of the ZEISS Terra ED 10x25 Binoculars.

3. Maintenance and Care for Binoculars

To ensure the longevity and performance of your binoculars:

- Keep the objective and ocular lenses clean. Use the provided ZEISS cleaning kit for best results.
- Store the binoculars in their protective case when not in use to prevent dust and scratches.
- Avoid exposing the binoculars to extreme temperatures or direct sunlight for extended periods.
- The housing is robust and designed to protect the internal optics. Avoid dropping or subjecting the binoculars to severe impacts.



Image: ZEISS Terra ED 10x25 Binoculars with protective case.

ZEISS SPRAY AND MICROFIBER LENS CARE KIT

The included cleaning kit is designed for safe and effective cleaning of all premium optics, including your binoculars.

1. Cleaning Instructions

- 1. Remove Loose Dust:** Gently blow any loose dust or particles off the lens surface. Avoid wiping dry lenses, as this can cause scratches.
- 2. Apply Spray:** Spray a small amount of the ZEISS lens cleaning solution onto the microfiber cloth. Do not spray directly onto the lens surface.
- 3. Wipe Lenses:** Gently wipe the lens surface with the damp microfiber cloth in a circular motion, starting from the center and moving outwards.
- 4. Dry:** Use a clean, dry part of the microfiber cloth to gently buff the lens until it is clear and streak-free.

Important: Always use the provided microfiber cloth or a similar high-quality, lint-free cloth. Avoid using paper towels, tissues, or clothing, as these can scratch lens coatings.



Image: ZEISS Lens Cleaning Kit components.

TROUBLESHOOTING

- **Blurry Image:**

- Ensure the central focusing wheel is adjusted correctly for the object's distance.
- Verify the diopter setting is correct for your eyes (refer to Setup section).
- Check if lenses are clean and free from smudges or dust.

- **Double Image or Eye Strain:**

- Adjust the interpupillary distance until you see a single, merged image.

- **Limited Field of View:**

- If wearing eyeglasses, ensure the eyecups are fully retracted.

SPECIFICATIONS

Magnification	10x
Objective Lens Diameter	25 mm
Close Focus	6.2 feet (1.9 meters)
Special Feature	Lightweight, Compact
Product Dimensions	10.4 x 8.3 x 6.6 inches (approximate package dimensions)
Item Weight	1.94 pounds (approximate package weight)
Manufacturer	Carl Zeiss Optical Inc

Note: Specifications are subject to change without notice.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official ZEISS website or contact your local ZEISS distributor. Keep your proof of purchase for warranty claims.

Official ZEISS Website: www.zeiss.com

© 2026 ZEISS. All rights reserved.

This manual is for informational purposes only. ZEISS is a registered trademark.