



Manuals.plus /

› Easytry123 /

› Easytry123 Replacement Remote Control User Manual for Pioneer Air Conditioners

**Easytry123 WYS012AMFI22RL, WYS018GMFI22RL, WYS024GMFI22RL, WYS012GMFI19RL, WYS012GMFI22RL, WYS030GMFI17RL**

# Easytry123 Replacement Remote Control User Manual for Pioneer Air Conditioners

Compatible with various Pioneer Room Window Air Conditioner models

---

## 1. INTRODUCTION

---

This document serves as the user manual for the Easytry123 replacement remote control, designed for specific Pioneer Room Window Air Conditioner models. This remote control is a direct replacement and does not require any programming. It is constructed from durable ABS plastic.

Please verify the compatibility with your air conditioner model before use. This remote control is not universal.

## 2. COMPATIBLE MODELS

---

This replacement remote control is compatible with the following Pioneer Room Window Air Conditioner models:

- WYS012AMFI22RL
- WYS018GMFI22RL
- WYS024GMFI22RL
- WYS012GMFI19RL
- WYS012GMFI22RL
- WYS030GMFI17RL

## 3. PRODUCT FEATURES

---

- Infrared (IR) replacement remote control.
- No setup or programming required; ready to use after battery installation.
- Ergonomic design for comfortable handling.
- Button control interface.

## 4. SETUP: BATTERY INSTALLATION

---

The remote control requires two (2) AAA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 1: Back of the remote control with the battery compartment.

**Note:** Remove batteries if the remote control will not be used for an extended period to prevent leakage and damage.

## 5. OPERATING INSTRUCTIONS

---

Point the remote control directly at the air conditioner's receiver. Ensure there are no obstructions between the remote and the unit. The remote control features various buttons for different functions:



Figure 2: Front of the remote control with button layout.

- **ON/OFF:** Powers the air conditioner on or off.
- **Mode:** Cycles through operating modes such as Cool, Heat, Fan, Dry, and Auto.
- **Fan:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **+ / - (Temperature Adjustment):** Increases or decreases the set temperature.
- **Sleep:** Activates the sleep mode, which adjusts temperature for comfortable sleep and energy saving.
- **Timer:** Sets a timer for the air conditioner to turn on or off automatically.
- **LED:** Controls the display light on the air conditioner unit.
- **Follow Me:** Activates a function where the remote control acts as a temperature sensor, allowing the air conditioner to adjust temperature based on the remote's location.
- **Short Cut:** Recalls your preferred operating settings with a single press.
- **Self Clean:** Initiates a self-cleaning cycle for the indoor unit.
- **Turbo:** Activates maximum cooling or heating capacity for rapid temperature change.

## 6. MAINTENANCE

- **Battery Replacement:** Replace batteries when the remote's range decreases or the display becomes dim. Always replace both batteries simultaneously with new AAA batteries.
- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.

## 7. TROUBLESHOOTING

---

- **Remote not responding:**
  - Check if batteries are inserted correctly with correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
  - Confirm the remote is pointed directly at the air conditioner.
- **Limited range:**
  - Replace batteries.
  - Ensure the remote is within the effective operating distance of the air conditioner.

## 8. SPECIFICATIONS

---

<b>Brand</b>	Easytry123
<b>Compatible Devices</b>	Pioneer Room Window Air Conditioners
<b>Connectivity Technology</b>	Infrared (IR)
<b>Controller Type</b>	Button Control
<b>Power Source</b>	2 x AAA Batteries (not included)
<b>Material</b>	ABS Plastic

## 9. WARRANTY AND SUPPORT

---

No specific warranty information is provided with this replacement remote control. For any issues, questions, or support inquiries, please contact the seller directly through your purchase platform.

Please retain your purchase receipt for any potential support needs.