



Manuals.plus /

› Easytry123 /

› User Manual for Easytry123 Replacement Air Conditioner Remote Control

Easytry123 RG67V/BGEF, RG66A/BGEF, RG66A1(B2)/BGEF, RG66A1/BGEF

User Manual: Easytry123 Replacement Air Conditioner Remote Control

Models: RG67V/BGEF, RG66A/BGEF, RG66A1(B2)/BGEF, RG66A1/BGEF

INTRODUCTION

This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your Easytry123 replacement remote control for various Carrier, Media, Inventor, and Kaisai room window air conditioner models. Please read this manual thoroughly before using the remote control to ensure optimal performance and longevity.

SETUP

Battery Installation

The remote control requires two (2) AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Back view of the remote control, showing the open battery compartment ready for AAA battery insertion. Note the polarity markings inside.

Initial Check

After installing batteries, point the remote control towards your air conditioner and press the **ON/OFF** button. The air conditioner should respond. If not, verify battery polarity and ensure the remote has a clear line of sight to the air conditioner's receiver.

OPERATING INSTRUCTIONS

This section details the functions of each button on your remote control.



Image: Front view of the remote control, displaying the LCD screen and all control buttons for various functions.

ON/OFF: Press to turn the air conditioner on or off.

Mode: Cycles through available operating modes: Auto, Cool, Dry, Fan, Heat (if supported by your AC unit).

+/- (Temperature Adjustment): Increases or decreases the set temperature.

Fan: Adjusts the fan speed (Auto, Low, Medium, High).

Swing (Up/Down Arrows): Controls the vertical airflow direction of the air conditioner.

Timer: Sets the timer for automatic on/off operations. Press once to set auto-on timer, twice for auto-off timer. Use +/- to adjust time.

Sleep: Activates sleep mode, which adjusts temperature gradually for comfortable sleep and energy saving.

Follow Me: Activates the "Follow Me" function, where the remote acts as a thermostat, sensing the temperature at its location and adjusting the AC accordingly.

Self Clean: Initiates a self-cleaning cycle for the indoor unit (if supported by your AC unit). This helps prevent mold and bacteria buildup.

LED: Turns the display light on the indoor unit on or off.

Shortcut: Recalls your preferred operating settings with a single press. To set, adjust settings as desired, then press and hold the Shortcut button until the unit beeps.

Turbo: Activates rapid cooling or heating to reach the desired temperature quickly.

MAINTENANCE

Cleaning the Remote Control

To maintain the remote control's appearance and functionality:

- Wipe the surface with a soft, dry cloth.
- Do not use liquid cleaners, abrasive cleaners, or chemical sprays, as these can damage the remote.

Battery Replacement and Storage

Replace batteries when the remote's display becomes dim or its range decreases. If the remote control will not be used for an extended period (e.g., over a month), remove the batteries to prevent leakage and potential damage to the remote.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote not responding to AC unit.	<ul style="list-style-type: none">• Dead or low batteries.• Incorrect battery polarity.• Obstruction between remote and AC unit.• Remote out of range.	<ul style="list-style-type: none">• Replace batteries with new AAA batteries.• Check battery orientation (+/-).• Remove any objects blocking the signal path.• Move closer to the AC unit.
Remote display is dim or blank.	<ul style="list-style-type: none">• Low batteries.• Remote malfunction.	<ul style="list-style-type: none">• Replace batteries.• If problem persists with new batteries, contact seller for support.
AC unit responds intermittently.	<ul style="list-style-type: none">• Weak batteries.• Interference from other electronic devices.	<ul style="list-style-type: none">• Replace batteries.• Ensure no strong light sources (e.g., direct sunlight) or other infrared devices are interfering.

SPECIFICATIONS

Product Type: Replacement Air Conditioner Remote Control

Brand: Easytry123

Compatible Models: Carrier RG67V/BGEF, Media RG66A/BGEF, Inventor RG66A1(B2)/BGEF, Kaisai RG66A1/BGEF, and other compatible models as listed in product description.

Power Supply: 2 x AAA Batteries (not included)

Connectivity: Infrared (IR)

Control Type: Button Control

WARRANTY AND SUPPORT

This product is a replacement remote control. For specific warranty terms and conditions, please refer to the purchase documentation or contact the seller, Easytry123, directly through the platform where the purchase was made. Support for this replacement remote control is typically provided by the seller.

For further assistance or inquiries, please reach out to the seller, Easytry123, via their contact information provided on the product listing or your order details.

