

[manuals.plus](#) /› [Easytry123](#) /› **Remote Control for Arctic King 17317000A52666 WPPD14CR9N WPPD08CW0N WPPD10CW0N AKPQ12CR4 WPPD14HW9N & Perfect AIRE RG57H4/BGEFU1 RG57H4B/BGEFU1 Window Air Conditioner**

Easytry123 17317000A52666

User Manual: Replacement Remote Control

Brand: Easytry123**Compatible Models:** Arctic King 17317000A52666, WPPD14CR9N, WPPD08CW0N, WPPD10CW0N, AKPQ12CR4, WPPD14HW9N & Perfect AIRE RG57H4/BGEFU1, RG57H4B/BGEFU1 Window Air Conditioners

1. INTRODUCTION

This manual provides essential information for the setup, operation, and maintenance of your Easytry123 replacement remote control. This remote is designed to be compatible with various Arctic King and Perfect AIRE window air conditioner models, as listed above.

Please note that as a replacement item, this remote control may not support all functions present on your original air conditioner remote. Its primary purpose is to provide core control over your compatible air conditioning unit.



Figure 1: Front view of the Easytry123 Replacement Remote Control.

2. SETUP

2.1 Battery Installation

The remote control requires two (2) AAA batteries for operation. Batteries are not included with the remote and must be purchased separately.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Once batteries are installed, the remote is ready for use. No complex pairing or programming is typically required for infrared (IR) remote controls.

3. OPERATING INSTRUCTIONS

Point the remote control directly at the infrared receiver on your air conditioning unit. Ensure there are no obstructions between the remote and the unit.



Figure 2: Angled view of the remote control highlighting button layout.

3.1 Button Functions

Button Name	Function
ON/OFF	Powers the air conditioner on or off.
MODE	Cycles through operating modes (e.g., Cool, Fan, Dry, Heat - depending on AC unit).
FAN	Adjusts fan speed (e.g., Low, Medium, High, Auto).
TEMP ▲ / ▼	Increases or decreases the set temperature.
TIMER ON	Sets a timer for the air conditioner to turn on.
TIMER OFF	Sets a timer for the air conditioner to turn off.

Button Name	Function
SLEEP	Activates or deactivates sleep mode, which often adjusts temperature and fan speed for comfort during sleep.
SWING	Controls the louver swing function for air direction.
LED	Turns the display light on the air conditioner unit on or off.
SHORT CUT	Activates a pre-set or favorite operating mode/setting.

Note: Not all buttons or functions may be supported by every compatible air conditioner model. Refer to your air conditioner's original manual for specific feature compatibility.

4. MAINTENANCE

4.1 Battery Replacement

Replace batteries when the remote's range decreases or if the air conditioner does not respond to commands. Always replace both batteries simultaneously with new AAA batteries.

4.2 Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

4.3 Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the remote.

5. TROUBLESHOOTING

- **Remote not responding:**

- Check if the batteries are inserted correctly with the correct polarity.
- Replace old batteries with new ones.
- Ensure there is a clear line of sight between the remote's IR emitter and the air conditioner's receiver. Remove any obstructions.
- Confirm the remote is pointed directly at the air conditioner.

- **Certain functions do not work:**

- As a replacement remote, some advanced or specific functions of your original air conditioner remote may not be supported. This is normal for universal or replacement remotes.
- Refer to your air conditioner's original manual to confirm if the function is supported by your unit.

6. SPECIFICATIONS

Brand	Easytry123
Compatible Devices	Arctic King and Perfect AIRE Window Air Conditioners

Connectivity Technology	Infrared (IR)
Power Source	2 x AAA Batteries (not included)
Special Feature	Ergonomic design
Color	Random (as supplied by manufacturer)
Manufacturer	Easytry123
Country of Origin	China
First Available Date	April 21, 2021

7. WARRANTY AND SUPPORT

Specific warranty information for this replacement remote control is not provided in this manual. For details regarding warranty coverage, returns, or technical support, please refer to the seller or the point of purchase. For issues related to your air conditioning unit's functionality, please consult the original manufacturer's manual or contact their customer support.

Easytry123 Replacement Remote Control Manual

Information accurate as of publication date. Subject to change without notice.