

[Manuals.plus](#) /

› [MAXEVER](#) /

› MAXEVER Quick-Fill Electric Air Pump User Manual

MAXEVER 8201

MAXEVER Quick-Fill Electric Air Pump User Manual

Model: 8201

INTRODUCTION

Welcome to the user manual for your MAXEVER Quick-Fill Electric Air Pump. This portable inflator and deflator is designed for quick and efficient inflation and deflation of various inflatable items such as air mattresses, pool floats, toys, and more. Please read this manual carefully before use to ensure safe and optimal operation and to maximize the lifespan of your product.

IMPORTANT SAFETY INFORMATION

- **WARNING:** Do not use this pump for high-pressure inflatable products such as vehicle tires, balloons, or sports balls (e.g., basketballs). This pump is designed for low-pressure, high-volume inflatables.
- Do not operate the pump for more than 20 minutes continuously to avoid overheating. Allow it to cool down for at least 15-20 minutes before further use.
- Do not use both the inflation and deflation vents simultaneously.
- Keep this pump under supervision when children are using it. It is not a toy.
- Ensure the power source matches the pump's requirements (AC 110V-120V). Do not use with incompatible voltage.
- Keep the pump away from water, moisture, and flammable materials. Do not operate in wet conditions.
- Do not block the air vents during operation, as this can lead to overheating and damage to the motor.
- Always unplug the pump from the power outlet when not in use or before cleaning.

PACKAGE CONTENTS

- 1 x MAXEVER Quick-Fill Electric Air Pump
- 3 x Universal Nozzles (small, medium, large)
- 1 x Instruction Manual (this document)

PRODUCT OVERVIEW

The MAXEVER Electric Air Pump is compact and lightweight, designed for ease of use. It features dedicated ports for inflation and deflation, along with a simple on/off switch.



Figure 1: MAXEVER Quick-Fill Electric Air Pump with included nozzles.



Figure 2: Key components and dimensions of the electric air pump.

Components

- **Power Switch:** Simple On/Off toggle for operation.
- **Inflating Vent:** The air outlet used for inflating items.
- **Deflating Vent:** The air inlet used for deflating items.
- **Power Cable:** Integrated cord for connecting to an AC 110V-120V electrical outlet.
- **Nozzles:** Three different sizes (small, medium, large) are provided to ensure compatibility with a wide range of valve types.

3 NOZZLES FIT MOST INFLATABLES



SMALL NOZZLE

INFLATABLE TOYS
SWIMRINGS, BABY SWIM
RINGS, ETC.



MEDIUM NOZZLE

INFLATABLE POOLS
SLEEPING PADS, ETC.



LARGE NOZZLE

AIR MATTRESSES
INFLATABLE HOUSES
BOATS, ETC.



Figure 4: Nozzle types and their recommended uses.

SETUP

1. Unpack all components from the packaging and ensure all parts listed in the 'Package Contents' section are present.
2. Identify the appropriate nozzle size for the inflation or deflation valve of your inflatable item.
3. Ensure the pump's power switch is in the "Off" (O) position before plugging it into a power outlet.

OPERATING INSTRUCTIONS

Inflation

1. Select the correct nozzle that fits snugly into the inflation valve of your item. A tight seal is crucial for efficient inflation.
2. Attach the selected nozzle firmly to the **Inflating Vent** (air outlet) of the pump.
3. Insert the nozzle firmly into the inflatable item's valve.
4. Plug the power cord into a standard AC 110V-120V electrical outlet.
5. Flip the power switch to the "On" (I) position to begin inflation.
6. Once the item is inflated to the desired firmness, switch the pump to "Off" (O) and remove the nozzle.
7. Unplug the pump from the power outlet.



Figure 5: Inflating an air mattress with the pump.

Deflation

1. Select the appropriate nozzle for the deflation valve of your item.
2. Attach the selected nozzle firmly to the **Deflating Vent** (air inlet) of the pump.
3. Insert the nozzle firmly into the inflatable item's valve.

4. Plug the power cord into a standard AC 110V-120V electrical outlet.
5. Flip the power switch to the "On" (I) position to begin deflation.
6. Once the item is deflated, switch the pump to "Off" (O) and remove the nozzle.
7. Unplug the pump from the power outlet.



Figure 6: Using the pump for pool inflatables.

MAINTENANCE

- **Cleaning:** Wipe the exterior of the pump with a dry or slightly damp cloth. Do not use abrasive cleaners, solvents, or immerse the pump in water.
- **Storage:** Store the pump and its accessories in a cool, dry place, away from direct sunlight and extreme temperatures. Keep out of reach of children and pets.

- **Cord Care:** Do not wrap the power cord tightly around the pump. Store it loosely to prevent damage to the cord or internal wiring.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Pump does not turn on.	Not plugged in; Power outlet issue; Power switch off.	Ensure pump is securely plugged into a working outlet; Test outlet with another device; Flip power switch to "On" (I).
Low airflow or slow inflation/deflation.	Incorrect nozzle size; Nozzle not securely attached; Air vents blocked.	Use the appropriate nozzle for a tight seal; Ensure nozzle is firmly attached to the pump and the inflatable's valve; Check and clear any obstructions from the air vents.
Pump overheats or stops working.	Continuous operation for too long (exceeding 20 minutes).	Turn off the pump immediately and allow it to cool down for at least 15-20 minutes before resuming use. Adhere to the 20-minute continuous operation limit.
Item not inflating/deflating completely.	Nozzle not sealed properly; Inflatable item's valve issue.	Ensure a tight seal between the nozzle and the inflatable's valve; Check the inflatable item's valve for any damage or leaks.

SPECIFICATIONS

Feature	Detail
Model Name	8201
Power Source	Corded Electric (AC 110V-120V)
Air Flow Capacity	400 LPM (Liters Per Minute)
Maximum Pressure	4000 Pascal (0.58 PSI)
Noise Rating	Under 85 dB
Dimensions (L x W x H)	3.15" x 2.36" x 2.95"
Item Weight	14.4 ounces (approx. 1 Lb)

Feature	Detail
Material	Acrylonitrile Butadiene Styrene (ABS)
Included Components	Pump, 3 Nozzles, Instruction Book

WARRANTY AND SUPPORT

This MAXEVER Electric Air Pump comes with a **1 Year Product Warranty** against quality defects from the date of purchase.

For any questions, technical support, or warranty claims, please contact MAXEVER customer service. We are committed to providing excellent support.

You can typically find contact information by visiting the seller's page on the platform where you purchased the product. Look for "Sold by MaxeverDirect" and then the "Ask a question" button to reach our support team.



Figure 7: Example of how to contact seller support.

Our team is available to assist you with any product-related inquiries.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0933FZWRF>

More documents and user manuals: <https://manuals.plus/>