

[Manuals.plus](#) /

› [Apple](#) /

› Apple TV Siri Remote (2nd Generation) User Manual

Apple MJFM3LL/A

Apple TV Siri Remote (2nd Generation) User Manual

Model: MJFM3LL/A

INTRODUCTION

The Apple TV Siri Remote (2nd Generation) provides precise control for your Apple TV 4K and Apple TV HD. This manual outlines the setup, operation, maintenance, and troubleshooting for your remote.





Image: Front view of the Apple TV Siri Remote (2nd Generation), showcasing the clickpad, menu, TV, play/pause, mute, and volume buttons, along with the power button at the top right and Siri button on the side.

SETUP

Pairing the Remote

To pair your Siri Remote (2nd Generation) with your Apple TV:

1. Ensure your Apple TV is powered on and within close proximity to the remote.
2. Press and hold the **Back** button (left arrow icon) and the **Volume Up** button (plus icon) simultaneously for approximately 2 seconds.
3. The Apple TV will detect and pair with the new remote. Any previously paired remotes may unpair automatically.

Charging the Remote

The Siri Remote (2nd Generation) includes a built-in rechargeable Lithium Ion battery. To recharge the remote,

connect a Lightning cable to the Lightning port located on the bottom edge of the remote.

OPERATING INSTRUCTIONS

Basic Navigation

The remote features a touch-enabled clickpad for navigation. You can interact with your Apple TV in the following ways:

- **Clickpad:** Press the center of the clickpad to select items.
- **Swiping:** Swipe your thumb across the clickpad surface to navigate through titles, menus, and playlists.
- **Circular Gesture:** Use a circular gesture on the outer ring of the clickpad to quickly scrub through video content, finding specific scenes.
- **Directional Buttons:** The outer ring of the clickpad also functions as directional buttons (up, down, left, right) for precise navigation.



Image: The Apple TV Siri Remote (2nd Generation) held in a hand, demonstrating its ergonomic design and button layout for user interaction.

Siri Voice Control

To use Siri, press and hold the **Siri button** (microphone icon) located on the right side of the remote. Speak your

command or search query, then release the button. Siri can help you find content, control playback, and more.


Power Control

The remote includes a dedicated **Power button** (circle with a line) located in the upper right corner. Press this button to turn your Apple TV on or off, or to put it to sleep.

MAINTENANCE

Charging

Regularly charge your Siri Remote using a Lightning cable to ensure uninterrupted use. A full charge provides extended battery life.






Image: Back view of the Apple TV Siri Remote (2nd Generation), featuring the Apple logo, highlighting the sleek design and aluminum finish.

TROUBLESHOOTING

Remote Not Responding

- **Recharge the Remote:** Connect the remote to a power source using a Lightning cable to ensure it has sufficient battery.
- **Re-pair the Remote:** If the remote becomes unresponsive, attempt to re-pair it by holding the **Back** button and **Volume Up** button for 2 seconds while near your Apple TV.
- **Check for Obstructions:** Ensure there are no physical obstructions between the remote and the Apple TV.

Siri Voice Input Issues

If Siri voice input is inconsistent or captures input but then erases it, ensure you are holding the Siri button throughout your command and releasing it only after you have finished speaking. Verify your Apple TV's software is up to date.

SPECIFICATIONS

Model Number	MJFM3LL/A
Brand	Apple
Product Dimensions	0.36 x 1.4 x 5.4 inches
Item Weight	2.2 ounces
Batteries	1 Lithium Ion battery (included, rechargeable)

Special Features	Ergonomic, Rechargeable, Voice Search
Color	Silver
Max Supported Devices	1
Compatible Devices	Apple TV 4K (3rd generation), Apple TV 4K (2nd generation), Apple TV 4K (1st generation), and Apple TV HD

WARRANTY AND SUPPORT

For detailed warranty information and technical support, please refer to the official Apple website or contact Apple customer service directly. This document does not contain specific warranty terms or support contact details.