

[Manuals.plus](#) /

› [Tek Styz](#) /

› PRO Bluetooth 5.3 IPX7 Speaker User Manual

Tek Styz TS-1950

PRO Bluetooth 5.3 IPX7 Speaker User Manual

Model: TS-1950

INTRODUCTION

This manual provides detailed instructions for the proper use, setup, operation, and maintenance of your PRO Bluetooth 5.3 IPX7 Speaker. Please read this manual thoroughly before using the product to ensure optimal performance and longevity. Keep this manual for future reference.

PRODUCT OVERVIEW

Key Features

- **Bluetooth 5.3 Connectivity:** Ensures stable and fast wireless connection up to 33 feet.
- **IPX7 Waterproof Rating:** Provides protection against water immersion up to 1 meter for 30 minutes, suitable for outdoor and wet environments.
- **Extended Playtime:** Up to 13 hours of continuous audio playback on a single charge.
- **Built-in Microphone:** Allows for hands-free calling.
- **Hi-Fi Digital Sound:** Delivers clear and immersive audio quality with 8D stereo surround effect.
- **True Wireless Stereo (TWS) Support:** Pair two speakers together for enhanced stereo sound.
- **Multi-functional Playback:** Supports Bluetooth, USB, TF/SD card, FM radio, and line input modes.
- **Durable Design:** Shock-resistant and drop-proof construction.

What's Included

- PRO Bluetooth IPX7 TWS Speaker (Model TS-1950)
- MicroUSB Charging Cable
- User Manual (this document)

Note: A charger block/adaptor is not included. It is recommended to use a standard USB charger (e.g., from a mobile phone) for charging.

Product Views



Figure 1: The PRO Bluetooth Speaker showcasing its IPX7 waterproof capability with water splashing over it.




Figure 2: Overview of the speaker's durability features including IPX7 waterproofing, dust, drop, and shock resistance, along with its 33-foot Bluetooth range, illustrated in a beach setting.



Figure 3: The speaker's versatility is highlighted by its use in different environments, from beach relaxation to social gatherings.



Figure 4: The speaker's integrated microphone enables hands-free calling, allowing users to answer calls directly through the device.



Figure 5: An internal view demonstrating the speaker's components, including the 5W subwoofer and premium microphone, which contribute to its Hi-Fi sound quality and HD calling capabilities.



Figure 6: The speaker's control panel and ports, illustrating its multi-functional playback options including FM Radio, TF/SD Card, Bluetooth, USB, and MicroUSB charging, along with clearly labeled control buttons.



Figure 7: Demonstrates the speaker's water resistance and highlights key features such as Bluetooth connectivity, extended playtime, and TWS capability.



Figure 8: The Dual/Stereo Function (TWS) allows two speakers to be paired for a 360-degree surround sound experience, compatible with various Bluetooth-enabled devices.

SETUP

Charging the Speaker

1. Locate the MicroUSB charging port on the speaker (refer to Figure 6).

2. Connect the provided MicroUSB charging cable to the speaker.
3. Connect the other end of the USB cable to a standard USB power adapter (not included) or a computer's USB port.
4. The charging indicator light will illuminate during charging and turn off when fully charged. A full charge provides up to 13 hours of playtime.

Powering On/Off

- **To Power On:** Press and hold the "ON/OFF" button (refer to Figure 6) for approximately 3 seconds until you hear an audible prompt.
- **To Power Off:** Press and hold the "ON/OFF" button for approximately 3 seconds until you hear an audible prompt.

Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing LED light and an audible prompt). If not, press the "MODE" button to switch to Bluetooth mode.
2. On your device (e.g., smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "TS-1950" or similar name from the list of found devices.
4. Once paired, the speaker will provide an audible confirmation, and the LED light will stop flashing.

True Wireless Stereo (TWS) Pairing

To achieve a stereo sound experience, you can pair two TS-1950 speakers together:

1. Ensure both speakers are powered off.
2. Power on both speakers simultaneously. They will automatically enter TWS pairing mode.
3. Wait for a few seconds; the speakers will automatically connect to each other. You will hear an audible confirmation once TWS pairing is successful.
4. Once TWS paired, connect your device to one of the speakers via Bluetooth as described in the "Bluetooth Pairing" section. The audio will now play through both speakers in stereo.

OPERATING INSTRUCTIONS

Button Functions (Refer to Figure 6)

- **ON/OFF Button:** Press and hold to power on/off.
- **MODE Button:** Short press to switch between playback modes (Bluetooth, TF/SD Card, USB, FM Radio, Line Input).
- **V+ Button:** Short press to increase volume. Long press for next track.
- **V- Button:** Short press to decrease volume. Long press for previous track.
- **Pause/Play Button:** Short press to play or pause audio.

Hands-Free Calling

- When connected to your smartphone via Bluetooth, incoming calls will be routed through the speaker.
- **Answer Call:** Short press the Pause/Play button.
- **End Call:** Short press the Pause/Play button during a call.
- **Reject Call:** Long press the Pause/Play button.

Playback Modes

- **Bluetooth Mode:** Default mode after powering on. Connect your device as described in the "Bluetooth Pairing"

section.

- **TF/SD Card Mode:** Insert a TF/SD card with audio files into the designated slot. The speaker will automatically switch to TF/SD card mode and begin playback.
- **USB Mode:** Insert a USB flash drive with audio files into the USB port. The speaker will automatically switch to USB mode and begin playback.
- **FM Radio Mode:** Press the MODE button until you hear the FM radio prompt. Use the V+ and V- buttons to scan for stations.
- **Line Input Mode:** Connect an external audio device using a 3.5mm audio cable (not included) to the speaker's AUX input. The speaker will switch to Line Input mode.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use abrasive cleaners or solvents.
- **Water Resistance:** The speaker is IPX7 waterproof, meaning it can withstand immersion in water up to 1 meter for 30 minutes. It is suitable for daily life waterproof scenarios like rain or splashes. Do not intentionally submerge the speaker for extended periods or in depths greater than specified. Ensure the charging port cover is securely closed before exposure to water.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker for at least 30 minutes.
No sound.	Volume too low; Speaker not paired; Incorrect mode.	Increase volume on speaker and device; Ensure speaker is paired; Press MODE button to select correct input.
Cannot pair with Bluetooth device.	Speaker not in pairing mode; Device Bluetooth off; Too far from speaker.	Ensure speaker is in pairing mode (flashing LED); Turn on Bluetooth on your device; Move device closer to speaker (within 33ft/10m).
TWS pairing fails.	Speakers not powered on simultaneously; Too far apart.	Ensure both speakers are powered on at the same time; Place speakers close to each other during TWS pairing.
Poor FM radio reception.	Weak signal.	Move the speaker to a location with better signal reception.

SPECIFICATIONS

Feature	Detail
Model Name	TS-1950
Brand	Tek Styz

Speaker Type	Bluetooth Portable Speaker
Connectivity Technology	Bluetooth 5.3, Wireless up to 33ft
Wireless Communication Technology	Bluetooth
Special Features	Lightweight, Digital IC Chip, Heavy Duty, Tangle Free Cord, Water Resistant (IPX7), Built-in Microphone, TWS Support
Recommended Uses	Indoor/Outdoor, Pool, Travel
Unit Count	1.0 Count
Surround Sound Channel Configuration	2.0
Color	BLUE
Battery Life	Up to 13 hours (as per product description), 18 Hours (as per specifications) - <i>Note: Actual battery life may vary based on usage.</i>
Product Dimensions (L x W x H)	1.6"D x 4.1"W x 3.7"H
Item Weight	7 Ounces
Impedance	4 Ohm
Power Source	Battery Powered (1 Lithium Ion battery included)
Connectivity Protocol	USB-C (Note: Product description mentions MicroUSB, included cable is MicroUSB. MicroUSB is likely the correct charging port type.)
Speaker Maximum Output Power	7 Watts
Frequency Response	48000 KHz
Mounting Type	Tabletop Mount
Material	Stainless Steel, Plastic
UPC	647010001674

Note: Specifications are subject to change without notice.

WARRANTY AND SUPPORT

This product is covered by a manufacturer's warranty. For detailed warranty information, please refer to the warranty card included with your product or contact Tek Styz customer support.

For technical support, troubleshooting assistance, or warranty claims, please contact Tek Styz customer service through their official website or the contact information provided with your purchase.

Manufacturer: Tek Styz

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0936FSR8Q>

More documents and user manuals: <https://manuals.plus/>