Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine Replacement Remote Control for Pioneer AV Receivers

User Manual

Replacement Remote Control for Pioneer AV Receivers

Brand: JustFine

Introduction

This manual provides essential information for the setup, operation, and maintenance of your new JustFine replacement remote control. This high-quality remote is pre-programmed and designed to be compatible with various Pioneer Car Audio System CD DVD RDS AV Receivers, including models such as AVHX3700BHS, AVH-200BT, AVHP3400BH, AVH-291BT, AVHX3500BHS, AVH-X391BHS, AVHX4700BS, AVH-X6800DVD, AVHP4450BT, and AVH-X4800BS. Please read this manual thoroughly to ensure optimal performance and longevity of your remote control.

Product Overview

The JustFine replacement remote control is an infrared (IR) device designed for seamless control of your compatible Pioneer AV receiver. It features a user-friendly layout with clearly labeled buttons for various functions.





Figure 1: Front view of the remote control, displaying its button layout.

Key features include:

- **Pre-Programmed:** Ready to use with compatible Pioneer AV receivers right out of the box.
- **Infrared (IR) Technology:** Ensures reliable communication with your device.
- **Ergonomic Design:** Comfortable to hold and easy to operate.

Setup

Battery Installation

Your remote control requires two (2) AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) ends align with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Figure 2: Battery compartment on the back of the remote control.

Note: Always replace both batteries at the same time. Do not mix old and new batteries, or different types of batteries. Remove batteries if the remote will not be used for an extended period.

Operating Instructions

Once batteries are installed, the remote is ready for use with your compatible Pioneer AV receiver. Point the remote directly at the infrared sensor on your receiver. Ensure there are no obstructions between the remote and the receiver.

Button Functions:

- **VOLUME (+/-):** Adjusts the audio volume level.
- **MODE:** Cycles through different audio modes or settings.
- **SRC (Source):** Selects the input source (e.g., CD, DVD, Radio, USB).

- **OFF:** Turns the AV receiver off.
- **MUTE:** Mutes or unmutes the audio.
- **MENU:** Accesses the main menu of the AV receiver.
- **TOP MENU:** Navigates to the top level of a DVD/Blu-ray menu.
- **Navigation Buttons (Up, Down, Left, Right):** Used to navigate through menus and selections.
- **ENTER:** Confirms a selection or enters a menu option.
- **AUDIO:** Cycles through available audio tracks or settings.
- **SUBTITLE:** Changes subtitle options for compatible media.
- **ANGLE:** Changes camera angles for compatible media.
- **RETURN:** Returns to the previous screen or menu.
- **Playback Controls (Stop, Play/Pause, Fast Rewind, Fast Forward, Skip Back, Skip Forward):** Standard controls for media playback.
- **ESC (Escape)** / **BAND:** Exits a menu or changes radio bands (AM/FM).
- **FOLDER** / **P.CH (Program Channel):** Navigates through folders or changes preset radio channels.

For detailed operation of specific functions, please refer to the user manual of your Pioneer AV receiver.

Troubleshooting

If you experience issues with your remote control, please try the following solutions:

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there is a clear line of sight between the remote's IR emitter and the receiver's IR sensor.
  - Make sure the remote is pointed directly at the receiver.
- **Limited range or intermittent response:**
  - Replace batteries.
  - Remove any obstructions between the remote and the receiver.
  - Ensure the remote is within the effective operating range (typically up to 7 meters or 23 feet).
- **Remote controls some functions but not others:**
  - Verify that your Pioneer AV receiver model is listed as compatible.
  - Some advanced functions may require specific settings on your AV receiver. Consult your receiver's manual.

If the problem persists after trying these steps, please contact customer support.

Specifications

Brand	JustFine
Compatible Devices	Pioneer AVHX3700BHS, AVH-200BT, AVHP3400BH, AVH-291BT, AVHX3500BHS, AVH-X391BHS, AVHX4700BS, AVH-X6800DVD, AVHP4450BT, AVH-X4800BS Car Audio System CD DVD RDS AV Receivers
Special Features	Infrared, Pre Programmed

Connectivity Technology	Infrared
Battery Type	AAA (2 required, not included)
Product Dimensions	11.5 x 4 x 3.5 cm; 41 g

Warranty and Support

This JustFine replacement remote control is sold with a**30-day quality warranty** and a money-back guarantee, offering hassle-free returns. If you encounter any issues or have questions regarding your remote control, please contact the seller directly through the platform where you made your purchase. Provide your order details for prompt assistance. For further information or support, please refer to the contact information provided by the seller.

© 2024 JustFine. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0936GJ2FL

More documents and user manuals: **https://manuals.plus/**