

[Manuals.plus](#) /

› [Tek Styz](#) /

› Tek Styz PRO Bluetooth 5.3 IPX7 Speaker User Manual (Model TS-1951)

Tek Styz TS-1951

Tek Styz PRO Bluetooth 5.3 IPX7 Speaker

USER MANUAL - MODEL TS-1951

1. Introduction

Thank you for choosing the Tek Styz PRO Bluetooth 5.3 IPX7 Speaker. This portable speaker is designed for robust performance and versatility, offering high-quality audio in various environments. Its IPX7 waterproof rating ensures durability against water exposure, making it suitable for both indoor and outdoor use. This manual provides essential information for setting up, operating, and maintaining your speaker.



Image 1.1: The Tek Styz PRO Bluetooth speaker demonstrating its IPX7 waterproof capability with water splashing over it.

Key Features:

- **Bluetooth 5.3 Connectivity:** For stable and efficient wireless audio streaming.
- **IPX7 Waterproof Rating:** Protected against immersion in water up to 1 meter for 30 minutes.
- **Extended Playtime:** Up to 13 hours of continuous audio playback on a single charge.
- **Built-in Microphone:** Enables hands-free calling.

- **Multi-Functional Playback:** Supports Bluetooth, USB, TF/SD card, FM radio, and line-in audio.
- **Dual Speaker Pairing (TWS):** Connect two speakers for stereo surround sound.



Image 1.2: The speaker in an outdoor setting, highlighting its IPX7 waterproof, dust, drop, and shock-resistant features, along with a 33-foot Bluetooth range.

2. Setup

Follow these steps to prepare your speaker for first use.

2.1 Package Contents

Ensure all items are present in the package:

- Tek Styz PRO Bluetooth Speaker (Model TS-1951)
- MicroUSB Charging Cable
- User Manual (this document)

Note: A USB wall adapter is not included. Please use a compatible USB adapter (e.g., from a mobile phone charger) for charging.

2.2 Charging the Speaker

1. Locate the MicroUSB charging port on the speaker. This port is typically protected by a rubber flap to maintain water resistance.
2. Connect the MicroUSB end of the charging cable to the speaker's charging port.
3. Connect the USB-A end of the charging cable to a compatible USB power source (e.g., a computer USB port, USB wall adapter, or power bank).
4. The charging indicator light will illuminate, typically red, to show that the speaker is charging.
5. Once fully charged, the indicator light will change or turn off (refer to the speaker's LED behavior for specifics). A full charge provides up to 13 hours of playtime.

Important: Ensure the rubber flap covering the charging port is securely closed when not charging to maintain the IPX7 waterproof rating.

2.3 Powering On/Off

- **To Power On:** Press and hold the **ON/OFF** button for approximately 2-3 seconds until you hear an audible prompt or see an indicator light.
- **To Power Off:** Press and hold the **ON/OFF** button again for approximately 2-3 seconds until you hear an audible prompt or the indicator light turns off.

3. Operating the Speaker

This section details how to use the various functions of your Tek Styz PRO speaker.



Image 3.1: Overview of the speaker's multi-functional playback options and control buttons.

3.1 Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode. The Bluetooth indicator light will typically flash rapidly.
2. On your mobile device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
3. Select "TS-1951" or a similar name from the list of found devices.
4. Once paired, the speaker will emit an audible confirmation, and the Bluetooth indicator light will typically stop flashing and remain solid.
5. The speaker will automatically attempt to reconnect to the last paired device when powered on.

3.2 Audio Playback Controls

- **Play/Pause:** Press the **Pause** button (often labeled with a play/pause icon) to play or pause audio.
- **Volume Up:** Press the **V+** button to increase volume. Hold to rapidly increase volume.
- **Volume Down:** Press the **V-** button to decrease volume. Hold to rapidly decrease volume.
- **Next Track:** Long press the **V+** button (or specific button if indicated on speaker).
- **Previous Track:** Long press the **V-** button (or specific button if indicated on speaker).

3.3 Hands-Free Calling

The speaker features a built-in microphone for hands-free calls when connected via Bluetooth to your smartphone.



Image 3.2: The speaker's integrated microphone allows for clear hands-free communication. Note: Voice isolation works in windy conditions, but the microphone does not function underwater.

- **Answer Call:** Press the **Play/Pause** button once when a call comes in.
- **End Call:** Press the **Play/Pause** button once during a call.
- **Reject Call:** Press and hold the **Play/Pause** button for 2 seconds.
- **Redial Last Number:** Double-press the **Play/Pause** button.

3.4 Multi-Functional Playback Modes

The speaker supports various audio input sources:

- **Bluetooth Mode:** Default wireless connection.
- **TF/SD Card Mode:** Insert a microSD card (TF card) with MP3 audio files into the TF/SD card slot. The speaker will automatically switch to this mode and begin playback.
- **USB Mode:** Insert a USB flash drive with MP3 audio files into the USB port. The speaker will automatically switch to this mode and begin playback.
- **FM Radio Mode:** Press the **MODE** button to cycle to FM radio. Use the **V+** and **V-** buttons to tune stations.
- **Line-In Mode:** Connect an audio device using a 3.5mm AUX cable (not included) to the speaker's AUX port (if available, otherwise use USB for digital audio). Press the **MODE** button to cycle to Line-In.

Press the **MODE** button repeatedly to switch between available playback modes.

3.5 Dual Speaker Pairing (TWS Function)

You can pair two Tek Styz PRO speakers together for a true wireless stereo (TWS) experience, providing enhanced sound separation and a wider soundstage.

DUAL/STEREO FUNCTION

TWO/2 Speakers can be paired together to create better 360° surround sound
All our speakers are compatible with all bluetooth-enabled devices!



Image 3.3: Diagram showing two speakers paired together for a stereo sound experience, connected to various devices.

1. Ensure both Tek Styz PRO speakers are powered on and not connected to any Bluetooth device.
2. On one of the speakers (this will be your primary speaker), press and hold the **MODE** button (or a dedicated TWS button if present) for a few seconds until you hear a pairing tone.
3. The two speakers will automatically search for and connect to each other. You will hear a confirmation tone once they are successfully paired in TWS mode.
4. Now, connect your mobile device to the primary speaker via Bluetooth as described in section 3.1. The audio will play through both speakers in stereo.

Note: TWS pairing typically needs to be re-established each time the speakers are powered off and on.

4. Maintenance

Proper care and maintenance will extend the lifespan of your speaker.

4.1 Water Resistance (IPX7)

The speaker is rated IPX7, meaning it can be immersed in water up to 1 meter (3 feet) for up to 30 minutes. This makes it suitable for use near pools, at the beach, or in rainy conditions.

- Always ensure the rubber flap covering the charging port and any other ports is securely closed before exposing the speaker to water.
- Do not intentionally submerge the speaker for extended periods or beyond the specified depth.
- After exposure to saltwater or chlorinated water, rinse the speaker with fresh water and dry thoroughly before charging or using.
- The microphone's voice isolation feature does not work underwater.

4.2 Cleaning

- Wipe the speaker with a soft, damp cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents, as these may damage the surface or internal

components.

- Ensure the speaker is completely dry before charging.

4.3 Storage

- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, charge the battery to approximately 50% every few months to maintain battery health.

5. Troubleshooting

If you encounter issues with your speaker, refer to the following common problems and solutions.

- **Speaker won't turn on:**
 - Ensure the battery is charged. Connect the speaker to a power source using the MicroUSB cable.
 - Press and hold the ON/OFF button for 2-3 seconds.
- **Cannot pair via Bluetooth:**
 - Ensure the speaker is in Bluetooth pairing mode (indicator light flashing).
 - Make sure Bluetooth is enabled on your device and it's within 33 feet (10 meters) of the speaker.
 - Turn off and on both the speaker and your device's Bluetooth.
 - Forget the speaker from your device's Bluetooth list and try pairing again.
 - Ensure no other devices are currently connected to the speaker.
- **No sound or low volume:**
 - Increase the volume on both the speaker and your connected device.
 - Ensure the speaker is properly paired and connected to your device.
 - Check if the audio source is playing correctly.
 - If using TF/SD card or USB, ensure the audio files are in a compatible format (e.g., MP3).
- **Poor sound quality:**
 - Move the speaker closer to your device to reduce interference.
 - Ensure there are no obstructions between the speaker and your device.
 - Check the audio source quality.
- **TWS pairing fails:**
 - Ensure both speakers are fully charged and not connected to any other Bluetooth device.
 - Try repeating the TWS pairing steps (Section 3.5).
 - Ensure both speakers are the same model for TWS compatibility.

6. Specifications

Feature	Specification
Model Name	TS-1951
Brand	Tek Styz
Connectivity Technology	Bluetooth 5.3, Wireless up to 33ft (10m)
Speaker Type	Portable Bluetooth Speaker

Feature	Specification
Waterproof Rating	IPX7
Power Source	Battery Powered (1 Lithium Ion battery, included)
Playtime	Up to 13 hours
Speaker Maximum Output Power	7 Watts
Frequency Response	48000 KHz
Impedance	4 Ohm
Product Dimensions	1.6"D x 4.1"W x 3.7"H
Item Weight	7 Ounces
Material	Stainless Steel, Plastic
UPC	647010061005

7. Warranty and Support

For warranty information and customer support, please refer to the documentation provided at the time of purchase or contact the seller directly. Tek Styz is committed to providing quality products and assistance.

For further assistance, please visit the official Tek Styz store or contact their customer service through the platform where the product was purchased.

© 2025 Tek Styz. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0936KMP3L>

More documents and user manuals: <https://manuals.plus/>