

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [ZoneFly](#) /

› [ZoneFly Air Fryer Replacement Power Cord User Manual](#)

## ZoneFly B0936MPWYK

# ZoneFly Air Fryer Replacement Power Cord User Manual

Model: B0936MPWYK

## INTRODUCTION

This user manual provides essential information for the safe and effective use of your ZoneFly Air Fryer Replacement Power Cord. This 3-prong heavy-duty cord is designed to replace old or worn-out power cables for various air fryer models, or to provide an extra cord for DIY projects. It meets UL safety standards for home and office use.

## SAFETY INFORMATION

Please read and understand all safety instructions before installing or using the replacement power cord. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always disconnect the appliance from the power source before attempting any installation or maintenance.
- Ensure the replacement cord's specifications (voltage, amperage, temperature rating) match or exceed the requirements of your appliance.
- This cord is designed for indoor use only. Do not expose to moisture or extreme temperatures.
- Do not use if the cord or plug is damaged. Inspect regularly for cuts, fraying, or exposed wires.
- Installation should be performed by a qualified individual if you are unsure about electrical wiring.
- Keep out of reach of children and pets.

## PRODUCT OVERVIEW

The ZoneFly Replacement Power Cord features a standard NEMA 5-15P male plug on one end and bare, stripped wires on the other, designed for direct wiring into compatible appliances.



Image: The ZoneFly replacement power cord, coiled with its 3-prong plug and bare wire ends, shown alongside a black Cosori air fryer, illustrating its intended use.





Image: A detailed view of the bare wire ends of the power cord, showing the white (neutral), green (ground), and black (live) insulated conductors ready for connection.

### Key Features:

- **Compatibility:** Designed for various air fryer brands including COSORI, Ultrean, COMFEE, Dash, Ninja, GoWISE, Chefman, NUWAVE BRIO, Cokunst Air Fryer, and Power-XL air fryer.
- **Heavy Duty Construction:** Features an 8-core copper material design for stable and reliable power delivery.
- **UL Safety Standards:** Meets safety requirements for household and office use.
- **Flexible and Durable:** Constructed with high-quality materials, tested for durability up to 5000 bends.

## SETUP AND INSTALLATION

---

This power cord is intended for replacement or DIY projects where the existing cord needs to be replaced or a new power connection is required. **Professional installation is recommended if you are not experienced with electrical wiring.**

1. **Safety First:** Ensure the appliance is completely unplugged from any power source before beginning.
2. **Access Wiring:** Carefully open the appliance to access the internal power cord connections. Refer to your appliance's specific service manual for instructions on accessing its wiring.
3. **Note Connections:** Before disconnecting the old cord, carefully note or photograph the wiring connections (typically black for live, white for neutral, green for ground).
4. **Remove Old Cord:** Disconnect the old power cord from the appliance's internal terminals.
5. **Connect New Cord:** Connect the bare wires of the ZoneFly replacement cord to the corresponding terminals within the appliance. Ensure a secure and proper connection for each wire (black to live, white to neutral, green to ground).
6. **Secure Wiring:** Ensure all connections are tight and insulated. Secure the cord within the appliance to prevent strain on the connections.
7. **Reassemble Appliance:** Carefully reassemble the appliance, ensuring no wires are pinched or exposed.
8. **Test:** Plug the appliance into a suitable power outlet and test its functionality.



Image: A central image of the power cord with arrows pointing to various air fryer models (COSORI, Ninja, Chefman, Instant Vortex, NuWave), illustrating the broad compatibility of the replacement cord.

## OPERATING INSTRUCTIONS

Once the ZoneFly Replacement Power Cord is correctly installed, the operation of your appliance will remain unchanged. The cord simply provides the necessary electrical connection.

- Ensure the power cord is fully inserted into a grounded electrical outlet.
- Do not overload the electrical circuit.
- Avoid placing the cord in high-traffic areas where it could be tripped over or damaged.
- Always grasp the plug, not the cord, when disconnecting from the outlet.

## MAINTENANCE

Proper maintenance ensures the longevity and safety of your power cord.

- **Regular Inspection:** Periodically inspect the entire length of the cord, the plug, and the connection points for any signs of damage, such as cuts, abrasions, kinks, or discoloration.
- **Cleaning:** If necessary, wipe the cord with a dry, soft cloth. Do not use liquid cleaners or immerse the cord in water. Ensure the cord is unplugged before cleaning.
- **Storage:** When not in use, store the cord in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cord to prevent internal wire damage.
- **Avoid Strain:** Do not pull, twist, or bend the cord excessively, especially near the plug or where it enters the appliance.



**1-Yr Limited Warranty**

A close-up photograph of a thick, black power cord coiled into several loops. The cord is shown from a low angle, creating a sense of depth and highlighting its flexibility and robust construction. The background is a plain, light-colored surface.

**Durable  
5000 bends**

Image: A close-up view of the coiled power cord, emphasizing its robust construction and flexibility, with text indicating "Durable 5000 bends" and "1-Yr Limited Warranty".

## TROUBLESHOOTING

If you encounter issues after installing the ZoneFly Replacement Power Cord, consider the following common troubleshooting steps:

- **Appliance Not Powering On:**

- Check if the cord is securely plugged into the wall outlet.
- Verify that the wall outlet is functional (test with another appliance).
- Ensure all internal wiring connections within the appliance are correct and secure (black to live, white to neutral, green to ground).
- Check the appliance's internal fuse or circuit breaker, if applicable.

- **Cord Overheating:**

- Ensure the appliance's power requirements do not exceed the cord's specifications (15 Amp / 125 Volt).
- Verify that the cord is not pinched or covered, which could lead to heat buildup.
- If overheating persists, discontinue use immediately and consult a qualified electrician.

- **Visible Damage to Cord:**

- If you notice any cuts, fraying, or exposed wires, discontinue use immediately. The cord must be replaced.

If troubleshooting steps do not resolve the issue, contact ZoneFly customer support or a qualified technician.

## SPECIFICATIONS

<b>Brand</b>	ZoneFly
<b>Model</b>	B0936MPWYK
<b>Load Rating</b>	15 Amp / 125 Volt (NEMA 5-15 plug rated for 15 Amp)
<b>Voltage Rating</b>	100V-250V
<b>Temperature Rating</b>	105°C
<b>Cable Type</b>	SJT, 300V, VW-1, 12AWG (12 gauge wire rated for 20 Amp)
<b>Connector Type</b>	NEMA 5-15P Male to Bare End (3-wire, 12/3)
<b>Color</b>	Black
<b>Item Weight</b>	6.2 ounces
<b>Package Dimensions</b>	8.43 x 4.21 x 1.54 inches
<b>First Available</b>	April 22, 2021

## WARRANTY AND SUPPORT

ZoneFly stands behind the quality of its products.

- **Warranty:** This product comes with a 180-day refund policy and a 24-month exchange warranty.
- **Customer Support:** For any questions, concerns, or warranty claims, please contact ZoneFly customer support. As a USA-based company, we are committed to providing prompt assistance.
- **Contact Information:** Please refer to the packaging or the ZoneFly official website for the most current contact details.



© 2024 ZoneFly. All rights reserved.