

[Manuals.plus](#) /

› [WOWOW](#) /

› WOWOW Widespread Brushed Nickel Bathroom Faucet (Model 2320500-AMUS) Instruction Manual

WOWOW 2320500-AMUS

WOWOW Widespread Brushed Nickel Bathroom Faucet (Model 2320500-AMUS) Instruction Manual

Your guide to installation, operation, and maintenance.

INTRODUCTION

Thank you for choosing the WOWOW Widespread Brushed Nickel Bathroom Faucet. This manual provides detailed instructions for the safe and efficient installation, operation, and maintenance of your new faucet. Please read all instructions carefully before beginning installation and retain this manual for future reference.



Image: The WOWOW Widespread Brushed Nickel Bathroom Faucet, Model 2320500-AMUS, featuring a high-arc spout and two lever handles.

WHAT'S INCLUDED

Verify that all components are present before beginning installation:

- Widespread Bathroom Faucet (Spout and two handles)
- Pop-up Drain Assembly
- Hot and Cold Water Supply Lines (23.6-inch, cUPC-certified)
- Quick Connect Hose (Y-shaped)
- Teflon Tape and Wrench
- Additional Aerators (1.2 GPM & 2.2 GPM)
- Pair of Gloves




Image: A visual representation of all parts included in the faucet package, including the faucet body, handles, drain, hoses, and tools.

SPECIFICATIONS

Feature	Detail
Brand	WOWOW
Model Name	2320500-AMUS

Recommended Uses	Bathroom
Mounting Type	Widespread Deck Mount
Finish Type	Brushed Nickel
Material	Brass
Number of Handles	2
Hole Count	3
Special Feature	360° Swivel Spout
Spout Height	3.6 Inches
Spout Reach	5.1 Inches
Item Weight	3.71 Pounds
Installation Type	Widespread Deck Mount

360° Swivel Faucet



PROVIDES SINK ACCESS IN DIFFERENT DIRECTIONS

Control Flow Rate and Temperature as You Wish

Image: Technical drawing illustrating the dimensions of the faucet, handles, and drain, along with hole size requirements.

SETUP AND INSTALLATION

Before you begin, ensure you have all necessary tools and that the water supply to your sink is turned off. It is recommended to wear the included gloves during installation.

1. **Prepare the Sink:** Remove your old faucet and clean the sink surface thoroughly. Ensure the three mounting holes are clear.
2. **Install Faucet Handles and Spout:** Insert the hot and cold water handles and the main spout into their respective holes on the sink deck. Secure them from underneath the sink using the provided washers and nuts.
3. **Connect Water Lines:** Attach the hot and cold water supply lines to the corresponding hot and cold inlets on the faucet handles. Use the provided Teflon tape on threaded connections to prevent leaks.
4. **Connect Quick Connect Hose:** Utilize the unique "Y" shaped quick connect hose to link the hot and cold water outlets from the handles to the main spout's inlet. This design allows for flexible spacing between the handles and spout.

5. **Install Pop-up Drain:** Insert the pop-up drain assembly into the sink drain hole. Secure it from underneath the sink, ensuring a watertight seal.
6. **Connect Drain to Plumbing:** Connect the bottom of the pop-up drain to your existing P-trap and drain pipe. Ensure all connections are tight to prevent leaks.
7. **Test for Leaks:** Once all connections are secure, slowly turn on the main water supply. Check all connections for any signs of leakage. Run both hot and cold water through the faucet to ensure proper function.

Your browser does not support the video tag.

Video: A customer demonstrates the installation process of a WOWOW Widespread Bathroom Faucet, including connecting the quick-connect hose and installing the pop-up drain. This video is provided by the seller.



Image: Detail of the hot and cold water supply lines, indicating their connection points.




Image: The Y-shaped quick connect hose, designed for easy and flexible installation of the widespread faucet.

OPERATING INSTRUCTIONS

- **Water Flow and Temperature Control:** The faucet features dual lever handles. Turn the left handle for hot water and the right handle for cold water. Adjust the handles to achieve your desired water temperature and flow rate.
- **360° Swivel Spout:** The high-arc spout can rotate 360 degrees, providing flexible access to all areas of your sink. Simply grasp the spout and gently pivot it to the desired position.
- **Pop-up Drain Operation:** The included pop-up drain is operated by pressing down on the drain stopper to close it and pressing again to open it.



Image: The faucet in operation, showing the water stream and the handles.



- 1 Installation instruction
- 2 Bathroom faucet with 1.2 GPM NEOPERL aerator. (Passed CEC certification. Comply with California Energy Commission)
- 3 Quick connect hose
- 4 A pair of gloves
- 5 Teflon tape and wrench
- 6 Additional 2.2 GPM aerator for high flow rates require in other areas.
- 7 Pop up drain stopper
- 8 Water supply hose x 2

Image: An illustration highlighting the 360° swivel function of the faucet spout, allowing for versatile sink access.

MAINTENANCE

Proper care will ensure the longevity and appearance of your WOWOW faucet.

- **Cleaning:** Clean the faucet regularly with a soft cloth and mild soap. Avoid abrasive cleaners, harsh chemicals, or polishes as these can damage the brushed nickel finish.
- **Aerator Maintenance:** The faucet comes with two aerators (1.2 GPM and 2.2 GPM). If water flow decreases or becomes erratic, the aerator may be clogged. Unscrew the aerator from the spout, clean any debris, and rinse thoroughly before reattaching. Replace with the alternative aerator if necessary.

- **Preventing Mineral Buildup:** Wipe the faucet dry after each use to prevent water spots and mineral buildup, especially in hard water areas.



Image: Detail of the faucet's removable aerator, which can be cleaned or replaced to maintain optimal water flow.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator; partially closed water supply valves.	Clean or replace the aerator. Ensure water supply valves are fully open.
Leaks from Faucet Base	Loose connections; damaged O-rings.	Check and tighten all connections. Inspect O-rings for damage and replace if necessary.
Water Temperature Issues	Incorrect hot/cold line connection; water heater issues.	Verify hot and cold lines are connected correctly. Check your water heater settings.
Drain Not Sealing	Improper drain assembly installation.	Re-install the pop-up drain assembly, ensuring all seals are correctly seated.

WARRANTY AND SUPPORT

The WOWOW Widespread Brushed Nickel Bathroom Faucet comes with a **5-year warranty**. For warranty claims, technical support, or any questions regarding your product, please contact WOWOW customer service through the retailer where you purchased the product or visit the official WOWOW store on Amazon: [WOWOW Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B093734X32>

More documents and user manuals: <https://manuals.plus/>