

- Manuals.plus /
- › MisterVac /
- › MisterVac Power Cable - Repair Cable for Masko K-IS-GE Wet and Dry Vacuum (Model 4054288280636)

MisterVac 4054288280636

MisterVac Power Cable - Repair Cable for Masko K-IS-GE Wet and Dry Vacuum

Model: 4054288280636

INTRODUCTION

This manual provides essential information for the safe and effective use of your MisterVac power cable. This 8-meter VDE H05RR-F replacement cable is designed for repair purposes and is compatible with Masko K-IS-GE wet and dry vacuum cleaners. Please read these instructions carefully before installation and use.

PRODUCT OVERVIEW



Image 1: MisterVac 8-meter black power cable. The cable features a European two-pin plug on one end, designed for standard wall outlets. The other end shows three exposed internal wires: blue (neutral), brown (live), and green/yellow (earth), ready for connection to an appliance.

The MisterVac power cable is a high-quality replacement component. It features a durable black outer sheath and a standard European plug. The opposite end is prepared with exposed wires for direct connection to an appliance requiring repair or replacement of its existing power cord.

Safety Instructions

Always observe the following safety precautions to prevent electric shock, fire, or injury:

- **Electrical Work:** Installation and repair should only be performed by qualified personnel. Incorrect wiring can lead to serious hazards.
- **Power Disconnection:** Always ensure the appliance is disconnected from the main power supply before attempting any repair or installation.
- **Cable Integrity:** Inspect the cable for any signs of damage (cuts, fraying, exposed wires) before and after installation. Do not use a damaged cable.
- **Proper Connection:** Ensure all wire connections are secure and correctly insulated according to local electrical codes.
- **Overload Protection:** Do not overload the cable. Ensure the appliance's power requirements do not exceed the cable's specifications.
- **Environmental Conditions:** Avoid exposing the cable to extreme temperatures, moisture, or corrosive substances.

Setup and Installation

This power cable is intended for repair and replacement. The following steps outline a general installation process. Specific appliance requirements may vary.

1. **Disconnect Power:** Unplug the appliance from the wall outlet.

2. **Access Wiring:** Open the appliance's housing to access the internal wiring where the power cable connects. Refer to the appliance's original service manual for specific instructions.
3. **Remove Old Cable:** Carefully disconnect and remove the old power cable, noting the connection points for each wire (live, neutral, earth).
4. **Prepare New Cable:** Ensure the exposed wires of the MisterVac cable are stripped to the appropriate length for connection terminals.
5. **Connect New Cable:** Connect the new cable's wires to the corresponding terminals within the appliance.
 - **Brown wire:** Connect to the Live (L) terminal.
 - **Blue wire:** Connect to the Neutral (N) terminal.
 - **Green/Yellow wire:** Connect to the Earth (E) or Ground terminal.
6. **Secure Connections:** Ensure all connections are tight and properly insulated. Use appropriate connectors or soldering as required by the appliance design.
7. **Reassemble:** Carefully reassemble the appliance housing, ensuring no wires are pinched.
8. **Test:** Before full operation, perform a safety check. Plug the appliance into a power outlet and test for proper function.

OPERATING INSTRUCTIONS

Once the MisterVac power cable is correctly installed and connected to your appliance, its operation is straightforward:

- **Plug In:** Insert the European two-pin plug firmly into a compatible wall socket.
- **Power On Appliance:** Operate your appliance as per its original instructions.
- **Unplug:** When not in use, or before performing any maintenance on the appliance, always unplug the power cable from the wall socket.

MAINTENANCE AND CARE

To ensure the longevity and safe operation of your MisterVac power cable:

- **Regular Inspection:** Periodically check the cable for any signs of wear, cuts, or damage, especially near the plug and where it enters the appliance.
- **Cleaning:** If necessary, wipe the cable with a dry or slightly damp cloth. Do not use harsh chemicals or immerse the cable in water. Ensure the cable is unplugged before cleaning.
- **Storage:** When not in use, coil the cable loosely. Avoid sharp bends or kinks that can damage the internal wires. Store in a dry place away from direct sunlight and extreme temperatures.
- **Avoid Stress:** Do not pull the cable to unplug it from the wall socket; always grasp the plug itself. Avoid placing heavy objects on the cable or running it through doorways where it might be pinched.

TROUBLESHOOTING

If you encounter issues after installing the MisterVac power cable, consider the following:

- **Appliance Not Powering On:**
 - Ensure the cable is fully plugged into the wall socket and the appliance.
 - Check the wall socket with another appliance to confirm it is live.
 - Verify all internal wire connections within the appliance are secure and correct (Live, Neutral, Earth).
 - Inspect the cable for visible damage.
- **Intermittent Power:**
 - This often indicates a loose connection. Recheck all internal wiring and the plug connection.
 - Look for signs of internal cable damage that might not be visible externally.

• **Overheating Cable/Plug:**

- Immediately unplug the cable.
- This could indicate an overload or a faulty connection. Ensure the appliance's power draw is within the cable's rating.
- Consult a qualified electrician.

If problems persist, discontinue use and consult a qualified technician or contact MisterVac support.

SPECIFICATIONS

Brand	MisterVac
Model Number	4054288280636
Cable Type	VDE H05RR-F
Conductor Material	Copper core
Wire Configuration	3G1.5 mm ² (3 cores, 1.5 mm ² cross-section each)
Length	Approximately 8 meters
Color	Black
Compatibility	Compatible with Masko K-IS-GE wet and dry vacuum cleaners (non-original Masko cable)

WARRANTY AND SUPPORT

For warranty information or technical support regarding your MisterVac power cable, please refer to the retailer's policy or contact MisterVac directly through their official website or customer service channels. Keep your purchase receipt as proof of purchase.

© 2023 MisterVac. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09373YXTK>

More documents and user manuals: <https://manuals.plus/>