

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Summer Infant](#) /
- › [Summer Infant Extra Tall & Wide Safety Gate \(Model BH33393Z\) Instruction Manual](#)

Summer Infant BH33393Z

Summer Infant Extra Tall & Wide Safety Gate (Model BH33393Z) Instruction Manual

For openings 29.5" - 53" wide, 38" tall

INTRODUCTION

This manual provides essential instructions for the safe installation, operation, and maintenance of your Summer Infant Extra Tall & Wide Safety Gate. Please read all instructions carefully before assembly and use. Keep this manual for future reference.

IMPORTANT SAFETY INFORMATION

WARNING:

- Always install and use the gate as directed. Incorrect installation can be dangerous.
- This gate is designed for use with children from 6 to 24 months of age. It can also be used for pets.
- Never use the gate to keep a child from accessing a pool or other body of water.
- Periodically check all fasteners to ensure they are tight and secure.
- Never leave children unattended.
- Stop using the gate if any components are damaged or missing.
- The gate will appear bent at first, but will be corrected upon proper installation.
- This gate will not fit openings of 33-33.5", 37-37.5", 41-41.5", 45-45.5", and 49-49.5".

SETUP AND INSTALLATION

The Summer Infant Extra Tall & Wide Safety Gate offers versatile installation options, including pressure mounting and hardware mounting. Choose the method appropriate for your location.

Gate Dimensions and Fit

- **Height:** 38 inches (including arch)
- **Width:** Adjustable from 29.5 inches to 53 inches.
- **Door Width:** 20 inches.

Important: Measure your opening carefully before installation to ensure proper fit. Refer to the extension guide below.




Figure 1: Gate dimensions. The gate is 38 inches tall and fits openings from 29.5 to 53 inches wide.

This image illustrates the overall height and adjustable width range of the Summer Infant Extra Tall & Wide Safety Gate. The gate stands 38 inches tall and can span openings between 29.5 and 53 inches.

Installation Options

- **Pressure Mount:** Ideal for doorways or hallways where drilling is not desired. No tools are required for this method.
- **Hardware Mount:** Recommended for secure installation at the top or bottom of stairs, on walls, or flat banisters. This method requires a drill, Phillips-head screwdriver, pencil, and measuring tape (not included).

Multiple Installation Options



Products shown for install reference. Actual gate may not be pictured.

Figure 2: Multiple installation options. The gate can be installed using a pressure mount system without tools or a hardware mount system requiring a drill for added security, especially at stairs.

This image displays the two primary installation methods: pressure mounting for tool-free setup in doorways and hallways, and hardware mounting for enhanced security at stairways, walls, or banisters, which requires a drill.

Gate Appearance During Installation

It is normal for the gate to appear slightly off-center or bent before it is fully installed and tightened. This is part of the design and will correct itself once the pressure or hardware mounts are properly secured.




Figure 3: Gate appearance before and after installation. The gate may appear bent or off-center prior to full installation, which is normal and will straighten once properly secured.

This diagram illustrates that the gate frame may initially appear bent or off-center. This is a normal characteristic of the gate's design and will be corrected as the pressure or hardware mounting system is fully tightened and installed.

Extension Guide

The gate includes extensions to accommodate various opening widths. Use the guide below to determine the correct configuration for your space.



Figure 4: Gate extension configurations. This diagram shows how to combine the main gate with small and large extension frames to fit openings from 29.5" to 53".

This image provides a visual guide for configuring the gate with its included extensions. It demonstrates how different combinations of the main gate and extension frames can be used to fit various opening widths, from 29.5 inches up to 53 inches.

OPERATING THE GATE

Opening the Gate

To open the gate, engage the latch and lift the door. This design allows for one-handed operation, which is convenient when carrying a child or other items.

note: the gate will appear off-center until it is properly installed



Figure 5: Operating the gate latch. Adults can open the door with one hand by engaging the latch and pulling up on the door.

This image shows a hand demonstrating how to open the gate. The user engages the latch mechanism and lifts the gate door, allowing for easy passage while maintaining security against children and pets.

Auto-Close and Hold-Open Features

- **Auto-Close:** If the door is opened less than 90 degrees, it will automatically swing shut and latch securely.
- **Hold-Open:** To keep the door open, swing it past 90 degrees. The door will remain in the open position until manually closed or swung back within the auto-close range.
- **Two-Way Swing:** When installed between rooms, the gate door opens in either direction.
- **Stairway Stopper:** If installed at the top of stairs, an included door stopper can be added to prevent the door from swinging outward over the stairs, enhancing safety.

Where can this gate be installed?

top or bottom of stairs


banister to banister
wall to banister
wall to wall
doorway

between rooms


wall to wall
doorway

Products shown for location reference.
Actual gate may not be pictured.

top of stairs



bottom of stairs



between rooms




Figure 6: Auto-close and hold-open functionality. The gate automatically closes when opened less than 90 degrees and stays open when swung past 90 degrees.

This image visually explains the gate's intelligent door mechanism. It shows that the gate will automatically close if opened less than 90 degrees, and it will remain open if swung beyond 90 degrees, providing convenience for continuous passage.

MAINTENANCE

- **Cleaning:** Wipe the gate with a damp cloth and mild soap. Do not use abrasive cleaners or harsh chemicals.
- **Inspection:** Regularly inspect the gate for any loose parts, damage, or wear. Ensure all mounting components are secure.
- **Tightening:** For pressure-mounted gates, periodically check and tighten the tension bolts to maintain a secure fit.

TROUBLESHOOTING

- **Gate appears bent:** This is normal prior to full installation. Ensure all mounting points are properly tightened. The frame will straighten as tension is applied.
- **Gate does not latch securely:** Check that the gate is installed within the recommended width range and that the mounting points are sufficiently tightened. Adjust the tension bolts as needed.

- **Gate slides or moves:** For pressure-mounted gates, tighten the tension bolts further. For hardware-mounted gates, ensure all screws are securely fastened.

SPECIFICATIONS

Feature	Detail
Brand	Summer Infant
Model Number	BH33393Z
Color	White
Material	Metal
Product Dimensions	1.75 x 29.5 x 38 inches (fits openings 29.5" - 53" W x 38" H)
Item Weight	19.98 pounds
Mounting Type	Pressure Mount / Hardware Mount
Age Range (Description)	Baby (6-24 months)
UPC	012914334133, 012914171738, 012914333839, 012914333938

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided with your product packaging or visit the official Summer Infant website.