

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Simple Houseware](#) /
- › [Simple Houseware 3-Tier Rolling Utility Cart \(Model CB-10D-R\) Instruction Manual](#)

## Simple Houseware CB-10D-R

# Simple Houseware 3-Tier Rolling Utility Cart Instruction Manual

Brand: Simple Houseware | Model: CB-10D-R

## 1. PRODUCT OVERVIEW

The Simple Houseware 3-Tier Rolling Utility Cart, Model CB-10D-R, is a versatile and sturdy storage solution designed for various indoor environments. This multifunctional cart features a durable metal frame construction and three spacious plastic baskets, providing ample space for organizing items. Equipped with heavy-duty 2-inch casters, two of which are lockable, the cart offers easy mobility and stability. An included hanging bucket further enhances its organizational capabilities for smaller items.



Figure 1: The Simple Houseware 3-Tier Rolling Utility Cart in red, highlighting its design and functionality.

## 2. SETUP AND ASSEMBLY

Assembly of the Simple Houseware 3-Tier Rolling Utility Cart is required and designed to be straightforward. All necessary tools and instructions are included to facilitate a quick setup.

### Assembly Steps:

1. Unpack all components and verify against the parts list provided in the packaging.
2. Attach the four heavy-duty 2-inch casters to the base frame. Ensure the two lockable casters are placed on the same side for convenient access.
3. Secure the vertical support rods to the base frame.
4. Slide the three plastic baskets onto the support rods, ensuring they are properly aligned and secured at each tier.
5. Attach the top handle to the upper section of the support rods.
6. Hook the hanging bucket onto the side of any basket as desired for additional storage.

7. Ensure all connections are tight and the cart is stable before use.

### 3. OPERATING INSTRUCTIONS

This rolling utility cart is designed for ease of use and adaptability across various settings.

#### Usage:

- **Mobility:** Utilize the four smooth-rolling casters to move the cart effortlessly between rooms or work areas.
- **Stability:** Engage the brakes on the two lockable casters to keep the cart securely in place when stationary.
- **Storage:** Place items in the three tiers. The raised edges of the baskets prevent items from falling out.
- **Small Item Organization:** Use the detachable hanging bucket for pens, tools, or other small accessories.

#### Versatile Applications:

The cart's design makes it suitable for numerous purposes, including:

- **Kitchen:** Store fruits, vegetables, spices, or small appliances.
- **Office:** Organize stationery, files, or craft supplies.
- **Bathroom:** Hold toiletries, towels, or cleaning supplies.
- **Garage/Workshop:** Keep tools, paints, or other supplies within reach.



Figure 2: The utility cart used in an office environment for organizing supplies.



Figure 3: The utility cart providing additional storage in a kitchen.



Figure 4: The utility cart used in a garage for tool and supply organization.

## 4. MAINTENANCE

To ensure the longevity and optimal performance of your Simple Houseware 3-Tier Rolling Utility Cart, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the cart with a damp cloth to remove dust and spills. For tougher stains, a mild soap solution can be used. Avoid abrasive cleaners that may damage the finish.
- **Caster Care:** Periodically check the casters for any accumulated debris (hair, lint, etc.) and clean them to maintain smooth rolling. Ensure the locking mechanism functions correctly.
- **Structural Integrity:** Regularly inspect all screws and connections to ensure they remain tight. Retighten if necessary to prevent wobbling and maintain stability.
- **Weight Limit:** Do not exceed the maximum recommended load of 55 pounds to prevent damage to the cart.

## 5. TROUBLESHOOTING

While the Simple Houseware 3-Tier Rolling Utility Cart is designed for durability, here are some common issues and their solutions:

- **Cart is Wobbly:** Check all assembly screws and ensure they are tightened securely. Uneven weight distribution can also cause wobbling; redistribute items evenly across the tiers.
- **Casters Not Rolling Smoothly:** Inspect the casters for any obstructions like hair or dirt. Clean them thoroughly. Ensure the locking mechanism is disengaged if you intend to roll the cart.
- **Baskets Not Sitting Evenly:** Verify that the baskets are correctly seated on the support rods and that the rods themselves are properly installed and tightened.

## 6. SPECIFICATIONS

Feature	Detail
Product Dimensions	11.2"D x 17"W x 31.38"H
Brand	Simple Houseware
Material	Metal, Plastic
Color	Red
Special Feature	Sturdy, Versatile
Number of Shelves	3
Recommended Uses	Indoor
Number of Wheels	4
Weight Limit	55 Pounds
Assembly Required	Yes
Caster Type	Swivel
Item Weight	7.09 pounds
Model Number	CB-10D-R
UPC	811244036393
Included Components	1 Hanging Bucket



Figure 5: Detailed dimensions of the 3-Tier Rolling Utility Cart.

## 7. WARRANTY AND SUPPORT

Specific warranty information and direct support contact details are not provided in the product data. Please refer to the retailer's return policy or the manufacturer's official website for further assistance.