

[Manuals.plus](#) /

› [TT FLEX](#) /

› Universal Dishwasher Drain Hose - 6 Ft Discharge Hose - Corrugated and Flexible Dishwasher Hose Drain Replacement with Clamp

TT FLEX HC-2DWD72

Universal Dishwasher Drain Hose Instruction Manual

Model: HC-2DWD72 | Brand: TT FLEX

1. PRODUCT OVERVIEW

The TT FLEX Universal Dishwasher Drain Hose is engineered for reliable and efficient drainage. This 6-foot hose is constructed from industrial-grade polypropylene, offering exceptional durability and flexibility. Its corrugated design prevents kinking, ensuring a smooth and uninterrupted flow of water. The hose comes with pre-packed universal fittings, designed to fit three common relief nozzle sizes, making it a versatile replacement for most dishwashers.



Image 1.1: The TT FLEX Universal Dishwasher Drain Hose, coiled, with two stainless steel clamps.



- **6FT long**
- **Industrial-grade polypropylene hose**
- **Thermo-plastic-rubber ends**
- **Stainless steel clamps**
- **Corrugated hose, more flexible and no kinking**

Image 1.2: Key features of the drain hose, including its 6FT length, industrial-grade polypropylene, thermo-plastic-rubber ends, stainless steel clamps, and corrugated design.

Product Overview Video

Your browser does not support the video tag.

Video 1.1: A brief overview of the TT FLEX Universal Dishwasher Drain Hose, highlighting its features and ease of use.

2. SETUP AND INSTALLATION

Installing the TT FLEX Universal Dishwasher Drain Hose is a straightforward process. Follow these steps to ensure a secure and leak-free connection:

1. **Determine Required Size:** The hose ends are pre-formed to fit 5/8 inch, 3/4 inch, and 1 inch inner diameter relief nozzles. Identify the correct size needed for both your dishwasher and sink/disposal connection.
2. **Trim to Fit:** If necessary, carefully trim the formed end of the hose to the desired size using a sharp utility knife or strong scissors. Only cut the sections marked for the specific diameter you need.
3. **Attach Clamp:** Slide one of the included steel clamps over the trimmed end of the hose.
4. **Connect to Dishwasher:** Firmly push the hose onto the dishwasher's drain outlet. Ensure it is fully seated.
5. **Secure Clamp:** Position the steel clamp over the connection point and tighten it as securely as possible using a screwdriver. This creates a tight seal to prevent leaks.
6. **Connect to Sink/Disposal:** Repeat steps 3-5 for the other end of the hose, connecting it to your sink's drain or garbage disposal inlet.
7. **Test for Leaks:** After installation, run a short dishwasher cycle and carefully inspect all connections for any signs of leaks.

Cut Appropriate Size You Need

suitable for most dishwasher



Image 2.1: Guide for trimming the hose ends to match 5/8, 3/4, or 1-inch connections.

Easy Installation



Image 2.2: Demonstrates the easy connection of the hose to a garbage disposal unit.

3. OPERATING

Once properly installed, the TT FLEX Universal Dishwasher Drain Hose operates automatically as part of your dishwasher's drainage system. Its corrugated design ensures smooth water flow and prevents kinking, which can obstruct drainage. No specific user interaction is required during operation beyond ensuring the hose remains free from obstructions and is not pinched or bent sharply.

4. MAINTENANCE

To ensure the longevity and optimal performance of your TT FLEX Universal Dishwasher Drain Hose, consider the following maintenance tips:

- **Regular Inspection:** Periodically check the entire length of the hose for any signs of wear, cracks, or

damage. Pay close attention to the connection points at both ends.

- **Check for Kinks/Pinches:** Ensure the hose is not kinked or pinched by other appliances or objects, which can restrict water flow and cause drainage issues.
- **Clean Connections:** If you notice any residue buildup around the connection points, gently clean them to maintain a secure seal.
- **Clamp Tightness:** Over time, clamps may loosen. Occasionally check and re-tighten the steel clamps at both ends to prevent leaks.

5. TROUBLESHOOTING

If you encounter issues with your dishwasher's drainage, consider the following troubleshooting steps related to the drain hose:

Issue: Water is not draining or draining slowly.

- **Check for Kinks:** Ensure the hose is not bent or kinked anywhere along its length. Straighten any bends to allow free flow.
- **Obstructions:** Verify there are no physical obstructions inside the hose or at the connection points.
- **Proper Trimming:** Confirm that the hose ends were trimmed to the correct size for your connections, allowing for optimal flow.

Issue: Leaks at connection points.

- **Tighten Clamps:** Ensure the steel clamps at both the dishwasher and sink/disposal ends are tightened securely.
- **Proper Seating:** Verify that the hose ends are fully pushed onto the respective nozzles.
- **Hose Damage:** Inspect the hose ends for any cracks or damage that might compromise the seal. If damaged, the hose may need replacement.

6. SPECIFICATIONS

Feature	Detail
Brand	TT FLEX
Model Number	HC-2DWD72
Material	Polypropylene, Steel
Color	Gray, Silver, Black
Product Dimensions	72"L x 0.8"W (6 feet length)

Feature	Detail
Item Weight	0.17 Kilograms (approx. 5.9 ounces)
Universal Fit Sizes	5/8 inch, 3/4 inch, 1 inch (inner diameter)
Included Accessories	Steel Clamps
UPC	763565096580



Image 6.1: Measurement of the hose's outer diameter, indicating 0.8 inches.

7. WARRANTY AND SUPPORT

The TT FLEX Universal Dishwasher Drain Hose comes with a **10-year warranty**, reflecting our commitment to quality and durability. This warranty covers defects in material and workmanship under normal use and

service.

For warranty claims, technical assistance, or any questions regarding your product, please contact TT FLEX customer service. Our support team is dedicated to providing prompt and helpful solutions.

Please retain your proof of purchase for warranty validation.