

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Glitzhome](#) /

› [Glitzhome 5 ft Pre-Lit Flocked Pine Artificial Christmas Porch Tree with Poinsettias and 150 Warm White Lights Instruction Manual](#)

Glitzhome GH60075

Glitzhome 5 ft Pre-Lit Flocked Pine Artificial Christmas Porch Tree Instruction Manual

Model: GH60075

IMPORTANT SAFETY INFORMATION

- Read all instructions before assembly and use.
- This product is intended for indoor or covered outdoor use only. Do not expose to direct rain or snow.
- Ensure the electrical outlet used for the lights is easily accessible and in good condition.
- Do not overload electrical outlets.
- Keep away from open flames and heat sources.
- Unplug the tree when not in use or before performing any maintenance.
- Do not modify the product or its electrical components.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly.

- 1 x Pre-Lit Flocked Pine Artificial Christmas Porch Tree with Poinsettias (GH60075)





Image: The complete Glitzhome 5 ft Pre-Lit Flocked Pine Artificial Christmas Porch Tree with Poinsettias, showcasing its full form and decorations.

SETUP INSTRUCTIONS

This product requires minimal assembly. Follow these steps to set up your tree.

- 1. Unpack the Tree:** Carefully remove the tree from its packaging. Ensure all protective materials are removed. The tree comes pre-assembled in its decorative urn base.
- 2. Position the Tree:** Place the tree on a flat, stable surface in your desired indoor or covered outdoor location. Ensure there is enough space around the tree for proper display.
- 3. Shape the Branches:** The tree branches may be compressed during shipping. Gently spread and shape the individual branches and branch tips to achieve a full and natural appearance. Start from the bottom and work your way up. Adjust the pre-attached poinsettias, berries, and holly leaves as needed.



Image: A close-up view of the tree's base and lower branches, illustrating the flocked texture and decorative elements.



Image: A detailed view of the flocked branches, warm white lights, and poinsettia decorations, showing the texture and arrangement.

OPERATING INSTRUCTIONS

The Glitzhome Porch Tree comes pre-lit with 150 warm white lights.

- Connect to Power:** Locate the electrical plug attached to the tree's light string. Plug it into a standard electrical outlet.
- Activate Lights:** The lights should illuminate immediately upon plugging in. There is no separate switch.
- Light Functionality:** The warm white lights are designed to remain lit even if a single bulb burns out, ensuring continuous illumination.
- Disconnect Power:** To turn off the lights, simply unplug the tree from the electrical outlet.

MAINTENANCE

Proper care will help maintain the appearance and longevity of your artificial tree.

- Cleaning:** To clean the tree, gently dust the branches and decorations with a soft, dry cloth or a feather

duster. Do not use liquid cleaners or abrasive materials.

- Storage:** When not in use, unplug the tree and carefully compress the branches. Store the tree in its original box or a suitable storage bag in a cool, dry place, away from direct sunlight and extreme temperatures.
- Light Bulb Replacement:** While the lights are designed to stay lit if one bulb fails, replacement bulbs may be included or can be obtained from the manufacturer if needed. Always unplug the tree before attempting to replace any bulbs.

TROUBLESHOOTING

Refer to the table below for common issues and their solutions.

Problem	Possible Cause	Solution
Lights do not turn on.	Tree is not plugged in or power outlet is not working.	Ensure the tree is securely plugged into a functional electrical outlet. Test the outlet with another device.
Some lights are out.	Individual bulb failure.	The lights are designed to remain lit even if a bulb burns out. If multiple sections are out, check for loose connections within the light string.
Tree appears sparse.	Branches are compressed from packaging.	Spend time fluffing and shaping each individual branch and tip to achieve a full appearance.

SPECIFICATIONS

Detailed product specifications for the Glitzhome 5 ft Pre-Lit Flocked Pine Artificial Christmas Porch Tree.

Model Number: GH60075

Height: 5 feet (60 inches)

Base Diameter: 26 inches

Material: Polyvinyl Chloride (PVC)

Light Type: Pre-Lit Warm White LED

Number of Lights: 150

Branch Tips: 343

Base Type: Decorative Urn Pot

Weight: Approximately 14 pounds

Assembly Required: No (shaping required)



5.00'

26.00 "

26.00 "

Image: A visual representation of the tree's dimensions, indicating a height of 5 feet and a base diameter of 26 inches.

WARRANTY AND SUPPORT


Glitzhome products are manufactured with quality and care. For specific warranty details, please refer to the documentation included with your purchase or contact Glitzhome customer support.

For technical assistance, missing parts, or any questions regarding your Glitzhome product, please contact our customer support team:

- **Website:** [Visit the Glitzhome Store on Amazon](#)
- **Contact Information:** Please refer to the Glitzhome official website or product packaging for the most current contact details.

© 2023 Glitzhome. All rights reserved.

Related Documents - GH60075

	<p>9ft Deluxe Pre-Lit Flocked Pine Artificial Christmas Tree Assembly Instructions</p> <p>Assembly and disassembly instructions for the Glitzhome 9ft Deluxe Pre-Lit Flocked Pine Artificial Christmas Tree with 650 Warm White Lights, including parts list, safety precautions, and storage tips.</p>
	<p>Glitzhome 7.5ft Pre-Lit Flocked Pencil Spruce Artificial Christmas Tree Assembly Instructions (Model 2014600093)</p> <p>Step-by-step assembly instructions for the Glitzhome 7.5ft Pre-Lit Flocked Pencil Spruce Artificial Christmas Tree with 350 Warm White Lights, model 2014600093. Includes disassembly, storage, and caution information.</p>
	<p>Glitzhome 6ft Pre-Lit Snow Flocked Fir Christmas Tree Assembly Instructions</p> <p>Assembly instructions for the Glitzhome 6ft Pre-Lit Snow Flocked Fir Christmas Tree with 300 Warm White Lights. Includes disassembly, storage, and step-by-step assembly guidance.</p>
	<p>Glitzhome 9ft Pre-Lit Flocked Spruce Artificial Christmas Tree Assembly Instructions</p> <p>Assembly and disassembly guide for the Glitzhome 9ft Pre-Lit Flocked Layered Spruce Artificial Christmas Tree with 500 Warm White Lights (Model 2014600099). Includes product specifications, parts list, step-by-step assembly, and safety precautions.</p>
	<p>Glitzhome 9ft Pre-Lit Pencil Green Pine Artificial Christmas Tree with 480 Warm White Lights - Assembly Instructions</p> <p>Assembly and setup guide for the Glitzhome 9ft Pre-Lit Pencil Green Pine Artificial Christmas Tree (Model 2014600092). Features 480 warm white lights and easy setup.</p>
	<p>Glitzhome 6' LED Christmas Tree Assembly Instructions - Multi-color/Warm White Light</p> <p>Detailed assembly instructions for the Glitzhome 6-foot LED Christmas Tree with multi-color and warm white lights, including parts list, step-by-step guide, disassembly, and storage tips.</p>

