

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [seenda](#) /

> [SEENDA 2.4G Wireless Backlit Keyboard User Manual](#)

seenda SEENDA 2.4G Wireless Backlit Keyboard (B093C55JV2)

SEENDA 2.4G Wireless Backlit Keyboard User Manual

Model: B093C55JV2

INTRODUCTION

Thank you for choosing the SEENDA 2.4G Wireless Backlit Keyboard. This manual provides detailed instructions for setting up, operating, and maintaining your keyboard to ensure optimal performance and longevity. Please read this manual carefully before use and retain it for future reference.

PACKAGE CONTENTS

Please check the package contents upon unboxing:

- SEENDA 2.4G Wireless Backlit Keyboard
- USB 2.4G Receiver
- USB Charging Cable
- User Manual

SETUP

- 1. Charge the Keyboard:** Before first use, fully charge the keyboard using the provided USB charging cable. Connect the cable to the keyboard's charging port and a USB power source (e.g., computer USB port, USB wall adapter). The charging indicator LED will show the charging status. A full charge takes approximately 2 hours.
- 2. Locate the USB Receiver:** The 2.4G USB receiver is typically stored in a compartment on the back or side of the keyboard for safekeeping. Carefully remove it.
- 3. Connect the Receiver:** Plug the USB 2.4G receiver into an available USB port on your computer, laptop, or Smart TV. The system should automatically detect and install the necessary drivers. No additional software installation is required.
- 4. Power On the Keyboard:** Locate the power switch on the keyboard (usually on the side or back) and slide it to the 'ON' position. The keyboard will automatically connect to the receiver.



Image: The SEENDA wireless keyboard connecting to a laptop via its USB receiver. The receiver is shown plugged into a USB port, establishing a wireless connection.



Image: A close-up view of the keyboard's side, highlighting the dedicated storage compartment for the USB receiver. This ensures the receiver is not lost when the keyboard is transported.

OPERATING INSTRUCTIONS

2.4G Wireless Connection

The keyboard utilizes 2.4 GHz wireless transmission technology, providing a stable and reliable connection up to 10 meters (33 feet) from the USB receiver. Ensure the receiver is within this range for optimal performance.



Image: The wireless keyboard positioned in front of a laptop, a desktop monitor, and a tablet, illustrating its broad compatibility with various devices including PCs, laptops, and tablets.

Backlight Control

The keyboard features a white LED backlight for improved visibility in low-light conditions. You can adjust the backlight brightness or turn it off:

- **Toggle Backlight On/Off:** Press the **Fn** key + **Bloc Scorr** (Scroll Lock) key to turn the backlight on or off.
- **Adjust Brightness:** Press the **Fn** key + **Pag ↑** (Page Up) to increase backlight brightness. Press the **Fn** key + **Pag ↓** (Page Down) to decrease backlight brightness. There are typically 3 levels of brightness.



Image: A visual guide showing the key combinations for controlling the keyboard backlight. It highlights the 'Fn + Bloc Scorr' keys for toggling the backlight and 'Fn + Pag ↑ / Pag ↓' for adjusting brightness levels.



Image: A split image demonstrating the keyboard's visibility in different lighting conditions. One side shows the keyboard with its white LED backlight active, suitable for night use, while the other shows it without backlight for daytime use.

Charging the Keyboard

The keyboard has a built-in 1600 mAh rechargeable battery. When the battery is low, the low battery indicator LED will illuminate. Connect the keyboard to a USB power source using the provided USB cable to recharge. A full charge provides approximately 90 hours of usage.



Image: The keyboard connected to a power source via its USB charging cable, indicating the charging process. The image highlights the charging port and the cable connection.

Special Function Keys (Fn Combinations)

The keyboard includes various function keys that can be accessed by pressing the **Fn** key in combination with other keys. These functions may include media control, volume adjustment, and other system shortcuts. Refer to the keycap legends for specific functions.

TASTIERA WIRELESS FULL SIZE



Image: A top-down view of the full-size Italian QWERTY keyboard layout, showing all keys including the numeric keypad and function keys. This image also provides dimensions of the keyboard.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the keyboard surface. For stubborn dirt, a slightly damp cloth can be used, ensuring no liquid enters the keyboard. Avoid harsh chemicals or abrasive cleaners.

- **Storage:** When not in use for extended periods, turn off the keyboard to conserve battery life. Store the USB receiver in its dedicated compartment to prevent loss.
- **Battery Care:** To prolong battery life, avoid fully discharging the keyboard frequently. Recharge it when the low battery indicator appears.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---------------------------------|---|--|
| Keyboard not responding | Keyboard is off; Low battery; USB receiver not connected or faulty; Out of range. | Ensure keyboard is on; Charge the keyboard; Re-plug the USB receiver into a different port; Move keyboard closer to receiver (within 10m). |
| Backlight not working | Backlight is off; Low battery. | Press Fn + Bloc Scorr to toggle backlight; Charge the keyboard. |
| Keys are sticky or unresponsive | Dirt or debris under keycap; Key mechanism issue. | Clean around the affected key with compressed air; If issue persists, contact customer support. |
| Connection drops frequently | Interference; Out of range; Low battery. | Move away from other wireless devices; Ensure keyboard is within 10m of receiver; Charge the keyboard. |

SPECIFICATIONS

- **Brand:** seenda
- **Model:** B093C55JV2
- **Connectivity:** 2.4G Wireless (USB Receiver)
- **Layout:** Italian QWERTY
- **Backlight:** White LED, 3 adjustable brightness levels
- **Battery:** 1600 mAh Rechargeable Lithium-ion
- **Charging Time:** Approximately 2 hours
- **Usage Time:** Up to 90 hours (with backlight off)
- **Operating Range:** Up to 10 meters (33 feet)
- **Key Type:** Scissor-foot design
- **Compatibility:** Windows PC, Laptops, Tablets, Smart TVs
- **Dimensions:** 44.5 x 13.6 x 4.7 cm (17.5 x 5.3 x 1.8 inches)
- **Weight:** 790 g (1.74 lbs)
- **Included Components:** Keyboard, USB Receiver, USB Charging Cable

TASTIERA WIRELESS FULL SIZE



Image: A diagram illustrating the precise dimensions of the SEENDA wireless keyboard, including length, width, and thickness, for reference.

WARRANTY AND SUPPORT

SEENDA products are designed for reliability and performance. For warranty information, technical support, or any questions regarding your product, please refer to the contact information provided with your purchase or visit the official SEENDA website. Please have your product model (B093C55JV2) and purchase date ready when contacting support.

