

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Braun](#) /

› Braun CareStyle 3 IS3132WH Steam Generator Iron User Manual

## Braun IS3132WH

# Braun CareStyle 3 IS3132WH Steam Generator Iron User Manual

Model: IS3132WH | Brand: Braun

## 1. INTRODUCTION

Welcome to the user manual for your Braun CareStyle 3 IS3132WH Steam Generator Iron. This appliance is designed to make your ironing experience more efficient and effective with its powerful steam output, compact design, and intelligent features. Please read this manual carefully before first use to ensure safe operation and optimal performance.

Key features of your CareStyle 3 IS3132WH include:

- **Powerful and Compact:** High steam performance with a compact design and a large 2-liter water tank.
- **iCare Mode:** Intelligent mode that protects your garments with a safe temperature for all fabric types.
- **Eco Mode:** Energy-saving mode for delicate fabrics without compromising results.
- **FreeGlide 3D Technology:** Unique rounded soleplate design ensures 360° glide over any fabric and obstacles like buttons and zippers.
- **Easy CalcClean System:** Protects the steam generator for extended lifespan and lasting performance, with a quick 2-minute descaling process.
- **Vertical Steaming:** Allows for convenient steaming of hanging garments and curtains.

## 2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the iron.
- Use the iron only for its intended use.
- To protect against a risk of electric shock, do not immerse the iron in water or other liquids.
- Always turn the iron OFF before plugging or unplugging from the outlet. Never yank cord to disconnect from outlet; instead, grasp plug and pull to disconnect.
- Do not allow cord to touch hot surfaces. Let iron cool completely before putting away. Loop cord loosely around iron when storing.
- The iron should always be turned to OFF before plugging or unplugging from outlet.
- Do not operate iron with a damaged cord or if the iron has been dropped or damaged. To avoid the risk of electric

shock, do not disassemble the iron. Contact a qualified service person for examination and repair. Incorrect reassembly can cause a risk of electric shock when the iron is used.

- Close supervision is necessary for any appliance being used by or near children. Do not leave the iron unattended while connected or on an ironing board.
- Burns can occur from touching hot metal parts, hot water, or steam. Use caution when you turn a steam iron upside down – there may be hot water in the reservoir.
- The iron must be used and rested on a stable surface.
- When placing the iron on its stand, ensure that the surface on which the stand is placed is stable.

### 3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Braun CareStyle 3 IS3132WH steam generator iron.



**Figure 3.1:** The Braun CareStyle 3 IS3132WH steam generator iron, showcasing its compact design with the iron resting securely on the base station.

## Interface iMode

**Il suffit d'appuyer sur un bouton pour sélectionner l'un des 4 modes et choisir celui qui vous convient le mieux.**



**Vapeur  
verticale**



**Vapeur  
maximale -  
Turbo**



**iCare  
protège  
tous les  
tissus**

**eco**

**Eco pour les  
tissus délicats**




**Figure 3.2:** Close-up of the iMode interface on the steam generator base, illustrating the four selectable modes: Vertical Steam, Turbo (Maximum Steam), iCare (protects all fabrics), and Eco (for delicate fabrics).

# BRAUN



**Figure 3.3:** Diagram showing the approximate dimensions of the Braun CareStyle 3 steam generator iron: 32 cm length, 19 cm width, and 27 cm height (with iron on base).

# Caractéristiques




**Puissance  
de 2400 W**



**Vapeur  
continue  
de 120 g/min**



**6 bar /  
400 g/min jet  
de vapeur**



**Longueur  
du cordon  
de 1,8 m**



Figure 3.4: Visual representation of key specifications: 2400W power, 120 g/min continuous steam, 6 bar pressure / 400 g/min steam shot, and 1.8m cord length.



Figure 3.5: Illustration highlighting the DoubleSteam technology, indicating powerful and consistent steam output from the soleplate.



**Figure 3.6:** Close-up of the Eloxal Plus soleplate, known for its excellent glide and scratch resistance.

## 4. SETUP AND FIRST USE

---

### 4.1 Unpacking

Carefully remove all packaging materials and labels from the appliance. Keep packaging for future storage or disposal.

### 4.2 Filling the Water Tank

1. Ensure the appliance is unplugged from the power outlet.
2. Remove the 2-liter detachable water tank from the base unit. The tank has a large opening for easy filling.
3. Fill the water tank with tap water up to the 'MAX' level indicator. The CareStyle 3 is suitable for tap water.
4. Replace the water tank securely into the base unit.

Puissant et compact

**Profitez des performances améliorées de la vapeur\* associées à une forme compacte et un réservoir XL.**



**Figure 4.1:** The large, removable 2-liter water tank, designed for easy refilling directly from the tap, allowing for extended ironing sessions.



**Figure 4.2:** Visual demonstration of detaching the 2-liter XL water tank from the steam generator base for convenient refilling.

### 4.3 Power Connection

Plug the power cord into a suitable grounded electrical outlet (240 Volts, 2400 Watts). The power indicator light will illuminate.

## 5. OPERATING INSTRUCTIONS

### 5.1 Powering On and Heating Up

Press the power button on the base unit. The iron will begin to heat up. Wait for the indicator light to stop flashing, indicating that the iron has reached the selected temperature and is ready for use.

### 5.2 Selecting Ironing Modes

The CareStyle 3 features an intuitive iMode interface with four distinct settings:

- **iCare Mode:** This intelligent mode automatically sets a safe temperature for all types of fabrics, providing smart textile protection. It is the default and recommended setting for most garments.
- **Eco Mode:** Ideal for delicate fabrics and for energy saving. This mode provides gentle steam and a lower temperature. The anti-drip system ensures no water leakage even at low temperatures.
- **Turbo Mode:** For the most resistant fabrics and stubborn creases. This mode delivers maximum steam performance and higher temperature for quick and effective ironing.
- **Vertical Steam:** Use this mode for refreshing hanging garments, drapes, or curtains. Hold the iron vertically and press the steam button.



**Figure 5.1:** A user demonstrating ironing with the Braun CareStyle 3, highlighting the ease of use with iCare and Eco modes for different fabric types.

### 5.3 Ironing with FreeGlide 3D Soleplate

The unique FreeGlide 3D Eloxal Plus soleplate is designed with a rounded, upward-curving shape, allowing for 360° glideability. This means you can iron backward over buttons, pockets, and zippers without snagging or creasing.

## Technologie FreeGlide 3D

**Ne laissez rien vous ralentir.  
Glissez en arrière sur tous les  
obstacles, tels que les boutons,  
les poches et les fermetures éclair.**



**Figure 5.2:** Visual representation of the FreeGlide 3D technology, showing the iron gliding effortlessly over obstacles like buttons, ensuring smooth movement in all directions.

Réservoir d'eau amovible de 2 l

Facile à retirer et à remplir.  
Jusqu'à 2,5 heures de repassage non-stop\*.



\*En réglage Eco

Figure 5.3: The Braun CareStyle 3 steam generator iron, demonstrating its compact form factor with the iron securely docked on the base unit, ready for use or storage.



Figure 5.4: Depiction of the Easy Lock system, which securely fastens the iron to the base for safe transport and storage.

## 6. CARE AND MAINTENANCE

## 6.1 Easy CalcClean System (Descaling)

The Easy CalcClean system is designed to protect your steam generator iron from limescale buildup, ensuring a longer lifespan and consistent steam performance. The appliance will indicate when descaling is needed.

1. Ensure the iron is cool and unplugged.
2. Place the CalcClean tray (if provided, or a suitable container) under the CalcClean valve.
3. Press and hold the CalcClean button for approximately 2 minutes until the process is complete. The appliance will automatically flush out scale particles.
4. Once complete, empty the CalcClean tray and rinse it.

Perform this process regularly as indicated by the appliance or based on your water hardness to maintain optimal performance.

## 6.2 Cleaning the Soleplate

To clean the Eloxal Plus soleplate, ensure the iron is cool and unplugged. Wipe the soleplate with a damp cloth and a non-abrasive liquid cleaner if necessary. Do not use abrasive scouring pads or harsh chemicals.

## 6.3 Storage

After use, allow the iron to cool completely. Empty any remaining water from the tank. Secure the iron to the base unit using the Easy Lock system. Store the appliance in a dry, safe place, away from direct sunlight and out of reach of children.

# 7. TROUBLESHOOTING

Before contacting customer service, please refer to the following common issues and their solutions:

Problem	Possible Cause	Solution
No steam is produced.	Water tank is empty or low. Iron not hot enough. CalcClean needed.	Refill water tank. Wait for iron to heat up completely. Perform CalcClean procedure.
Water leaks from the soleplate.	Temperature is too low for steam. Ironing horizontally when vertical steam is selected.	Increase temperature setting. Ensure correct mode for vertical steaming.
Iron does not heat up.	Not plugged in. Power button not pressed.	Check power connection. Press the power button on the base unit.
Steam performance is reduced.	Limescale buildup.	Perform the Easy CalcClean procedure.

# 8. TECHNICAL SPECIFICATIONS

Feature	Specification
Model Number	IS3132WH
Power	2400 Watts
Voltage	240 Volts

Feature	Specification
Continuous Steam Output	120 g/min
Steam Shot / Boost	400 g/min
Steam Pressure	6 bar
Water Tank Capacity	2 Liters (XL removable)
Soleplate Type	Eloxal Plus, FreeGlide 3D
Cord Length	1.8 meters
Product Dimensions (L x W x H)	4.34 x 25 x 33.5 cm
Item Weight	3.4 Kilograms
Color	White/Orange

## 9. WARRANTY AND SUPPORT

Your Braun CareStyle 3 IS3132WH steam generator iron is designed for durability and performance. In case of any issues, please refer to the troubleshooting section first.

This product is subject to a 30-day return policy from the date of purchase, as per standard Amazon terms. For specific warranty details and duration, please refer to the warranty card included with your product or visit the official Braun website.

For further assistance, technical support, or to inquire about spare parts, please contact Braun customer service through their official website or the contact information provided in your product packaging.