

[Manuals.plus](#) /

> [WEIJIA](#) /

> WEIJIA FP-11LP Large Pusher for Cuisinart FP-11 Food Processor User Manual

WEIJIA FP-11LP

WEIJIA FP-11LP Large Pusher User Manual

For Cuisinart FP-11 11-Cup Elemental Food Processors

1. INTRODUCTION

This manual provides instructions for the proper use and maintenance of the WEIJIA FP-11LP Large Pusher. This accessory is designed to replace the original large pusher for the Cuisinart FP-11 11-Cup Elemental Food Processor, ensuring efficient and safe operation when processing larger food items.

2. SAFETY INFORMATION

- Always ensure the food processor is turned off and unplugged before installing or removing the pusher or any other components.
- Keep hands and utensils away from moving blades during operation. Use the pusher only to guide food into the feed tube.
- Do not force food into the feed tube. The pusher is designed to fit snugly but should not require excessive force.
- Inspect the pusher for any damage before each use. Do not use if cracked or broken.
- This pusher is intended for use with the specified food processor model only. Using it with incompatible models may result in damage or injury.

3. COMPATIBILITY

The WEIJIA FP-11LP Large Pusher is specifically designed for use with the **Cuisinart FP-11 11-Cup Elemental Food Processor**. Verify your food processor model number to ensure proper fit and function.

4. SETUP AND INSTALLATION

1. Ensure your Cuisinart FP-11 food processor is assembled correctly with the work bowl and lid securely in place.
2. Locate the large feed tube opening on the food processor lid.
3. Gently insert the WEIJIA FP-11LP Large Pusher into the large feed tube opening. It should slide in smoothly without resistance.
4. The pusher is now ready for use to guide food into the processing blades.



Image 1: The WEIJIA FP-11LP Large Pusher. This clear plastic component is designed to fit into the feed tube of the Cuisinart FP-11 food processor, allowing users to safely push food towards the processing blades.

5. OPERATION

1. After installing the pusher and ensuring the food processor is ready for operation, place food items into the large feed tube.
2. Turn on the food processor.
3. Use the large pusher to gently guide the food down the feed tube towards the rotating blades. Apply even, steady pressure.
4. Do not apply excessive force, as this can damage the pusher or the food processor. Allow the blades to do the work.
5. Once all food has been processed, turn off the food processor and unplug it before removing the pusher or other components.

6. MAINTENANCE AND CLEANING

To ensure the longevity and hygiene of your WEIJIA FP-11LP Large Pusher, follow these cleaning instructions:

- **Hand Wash Only:** Wash the pusher with warm, soapy water immediately after each use.
- Use a soft sponge or cloth to clean all surfaces. Avoid abrasive cleaners or scouring pads, which can scratch the

plastic.

- Rinse thoroughly under running water to remove all soap residue.
- Allow the pusher to air dry completely before storing, or dry with a clean cloth.
- Do not place the pusher in a dishwasher, as high temperatures and harsh detergents can cause warping or damage.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Pusher does not fit into the feed tube.	Incorrect food processor model or improper alignment.	Verify your food processor is a Cuisinart FP-11. Ensure the pusher is aligned correctly with the feed tube opening. Do not force it.
Food gets stuck in the feed tube.	Food item is too large or pusher is not applied with steady pressure.	Cut food into smaller pieces if necessary. Apply steady, gentle pressure with the pusher. Do not overload the feed tube.
Pusher appears damaged (cracked, warped).	Excessive force during use or improper cleaning (e.g., dishwasher).	Discontinue use immediately. Replace the pusher. Always hand wash and avoid excessive force.

8. SPECIFICATIONS

Brand: WEIJIA

Model: FP-11LP

Compatibility: Cuisinart FP-11 11-Cup Elemental Food Processor

Material: Food-grade plastic

Care Instructions: Hand Wash Only

UPC: 642206153052

9. WARRANTY AND SUPPORT

For information regarding warranty coverage or product support, please refer to the original purchase documentation or contact the retailer where the WEIJIA FP-11LP Large Pusher was purchased. Keep your proof of purchase for warranty claims.

© 2023 WEIJIA. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B093FDD7X7>

More documents and user manuals: **<https://manuals.plus/>**