

[Manuals.plus](#) /

› [BSOD](#) /

› BSOD Mushroom Lamp Instruction Manual - Model M-1970S-SW

BSOD M-1970S-SW

BSOD Mushroom Lamp Instruction Manual

Model: M-1970S-SW

INTRODUCTION

This manual provides comprehensive instructions for the BSOD Mushroom Lamp, Model M-1970S-SW. This vintage-style table lamp features hand-blown striped glass and provides warm ambient lighting. Please read this manual thoroughly before use and retain it for future reference.



Image: The BSOD Mushroom Lamp illuminated on a bedside table, providing warm ambient light.

SETUP

Unboxing and Initial Setup

Carefully remove all components from the packaging. The lamp comes pre-assembled. The package includes the glass mushroom lamp and one E12 LED bulb.



Image: The BSOD Mushroom Lamp with the included E12 LED bulb ready for installation.

Bulb Installation

1. Ensure the lamp is unplugged from the power outlet before installing the bulb.
2. Gently screw the provided E12 LED bulb into the lamp's socket located inside the base. Do not overtighten.
3. Place the lamp on a stable, flat surface.
4. Plug the power cord into a standard 110V American outlet.



Image: Close-up view of the E12 bulb socket within the lamp base, showing where the bulb is inserted.

Video: A demonstration of unboxing the BSOD Mushroom Lamp and preparing it for use.

Video: A short demonstration of placing the mushroom lamp on a surface and turning it on.

OPERATING INSTRUCTIONS

Powering On/Off

The BSOD Mushroom Lamp is operated using a simple push-button switch located on the power cord. Press the button once to turn the lamp on, and press it again to turn the lamp off.



Image: The inline push-button switch on the power cord of the BSOD Mushroom Lamp.

Light Output

The included E12 LED bulb provides a warm white light effect, ideal for creating a cozy ambiance. The lamp is designed for a single light setting and does not feature dimming capabilities with the standard switch. For dimmable or color-changing options, a compatible smart E12 LED bulb (e.g., BSOD intelligent RGBWW candle light, B08N11773G) can be used.



Image: The BSOD Mushroom Lamp illuminated, showcasing its warm white light output.

MAINTENANCE

Cleaning

To clean the glass mushroom lamp, ensure it is unplugged from the power outlet and completely cool. Gently wipe the glass surface with a soft, dry, lint-free cloth. Do not use abrasive cleaners, solvents, or liquid sprays directly on the lamp, as this may damage the finish or electrical components.

Bulb Replacement

The lamp uses an E12 LED bulb. To replace the bulb:

1. Unplug the lamp from the power outlet.
2. Allow the bulb to cool completely if it has been recently in use.
3. Carefully unscrew the old E12 bulb from the socket.
4. Screw in a new E12 LED bulb. Ensure it is securely fastened but do not overtighten.
5. Plug the lamp back into the power outlet.

For smart lighting options, consider replacing the standard bulb with a compatible smart colorful dimmable ambient light bulb, such as the BSOD intelligent RGBWW candle light (ASIN: B08N11773G).

TROUBLESHOOTING

- **Lamp Does Not Turn On:**
 - Check if the power cord is securely plugged into a working 110V American standard outlet.
 - Verify the E12 LED bulb is correctly installed and not loose.
 - Test the bulb in another working fixture if possible, or try a new E12 LED bulb.
- **Light is Too Dim/Bright:**
 - The included bulb provides a fixed warm white light. For different brightness or color options, replace with a compatible smart dimmable E12 LED bulb.
- **Lamp Flickers:**
 - Ensure the bulb is screwed in tightly.
 - Try a different E12 LED bulb to rule out a faulty bulb.

SPECIFICATIONS

Feature	Specification
Brand	BSOD
Model Name	M-1970S-SW
Product Dimensions	6"D x 6"W x 7.5"H
Item Weight	2 Pounds
Material	Glass
Shade Color	Stripe White
Light Source Type	LED
Bulb Base	E12
Wattage	5 Watt-hours (Max Compatible: 75 Watt Hours)
Voltage	110 Volts (AC)
Brightness	600 Lumen
Color Temperature	2700 Kelvin (Warm White)
Control Method	Push Button Switch
Indoor/Outdoor Usage	Indoor Use Only

Feature	Specification
Included Components	Bulb

WARRANTY AND SUPPORT

The BSOD Mushroom Lamp comes with a One-Year Warranty Service. If you have any questions or encounter issues after receiving your product, please contact the manufacturer for support. Please refer to your purchase documentation for specific contact details.