

- Manuals.plus /
- › Fastrack /
- › Fastrack Wear Your Look Analog Watch NT6172SL04 User Manual

Fastrack NT6172SL04

Fastrack Wear Your Look Analog Watch NT6172SL04 User Manual

Model: NT6172SL04 | Brand: Fastrack

1. PRODUCT OVERVIEW

The Fastrack Wear Your Look Analog Watch NT6172SL04 is designed for women, featuring a sophisticated grey dial and a comfortable green leather strap. This watch combines functionality with a modern aesthetic, suitable for everyday wear.



Image 1.1: Front view of the Fastrack Wear Your Look Analog Watch.

Key Features:

- **Dynamic Layered Grey Dial:** A modern design with distinct semicircular date and circular day displays.
- **Unique Date and Day Layout:** Offers a visually interesting and functional way to track time.
- **Cool Grey and Green Palette:** A sophisticated combination with a touch of earthy charm.
- **Clean Strap Design:** The smooth green leather strap maintains a sleek and unified look.
- **Water Resistant Build:** Ideal for everyday wear and occasional splashes (30 meters).

2. SETUP AND INITIAL USE

2.1 Setting the Time

1. Locate the crown on the right side of the watch case.
2. Gently pull the crown outwards to the first or second click position (depending on the model, one click for date/day,

two clicks for time).

3. Rotate the crown to adjust the hour and minute hands to the correct time.
4. Once the time is set, push the crown back into its original position to start the watch movement.



Image 2.1: Side view of the watch, highlighting the crown.

2.2 Wearing the Watch

The watch features a green leather strap with a tang buckle. Adjust the strap to fit comfortably on your wrist, ensuring it is not too tight or too loose. A comfortable fit allows for proper air circulation and prevents skin irritation.



Image 2.2: Back view of the watch, showing the strap and buckle.

For optimal comfort, measure your wrist and compare it with the watch's dimensions. The watch has a case diameter of 37mm.



Image 2.3: Dial size guide for wrist measurement.

3. OPERATING THE WATCH

This Fastrack watch operates with a quartz movement, providing accurate timekeeping. The analog display features hour, minute, and second hands. The unique dial design includes semicircular date and circular day displays for additional functionality.

3.1 Reading the Time

The watch displays time using traditional hour, minute, and second hands on a grey dial with clear markers.

3.2 Date and Day Display

The watch incorporates distinct semicircular and circular sub-dials for displaying the date and day. These are automatically adjusted as the time progresses. If manual adjustment is needed (e.g., after a month with fewer than 31 days), refer to the crown setting instructions in Section 2.1.

4. MAINTENANCE AND CARE

4.1 Water Resistance

This watch is water resistant up to 30 meters (3 ATM). This means it is suitable for everyday use and can withstand splashes or brief immersion in water. It is not recommended for swimming, showering, or diving. Ensure the crown is fully pushed in before any contact with water.

4.2 Cleaning

- Wipe the watch case and crystal with a soft, dry cloth.
- For the leather strap, avoid prolonged exposure to water, direct sunlight, and harsh chemicals to prevent damage and discoloration. Clean with a slightly damp cloth and allow to air dry.

4.3 Battery

The watch is powered by one Lithium Polymer battery, which is included. When the watch stops running, it indicates the

battery needs replacement. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and water resistance.

5. TROUBLESHOOTING

5.1 Watch Not Running

- Ensure the crown is fully pushed in.
- If the watch still does not run, the battery may need replacement. Contact an authorized service center.

5.2 Time Inaccuracy

- Verify that the time was set correctly.
- Extreme temperatures or strong magnetic fields can affect quartz movement accuracy. Avoid exposing the watch to such conditions.
- If inaccuracy persists, the movement may require inspection by a professional.

6. SPECIFICATIONS

Brand	Fastrack
Model Number	NT6172SL04
Model Name	Wear Your Look
Display Type	Analog
Movement	Quartz
Water Resistance	30 Meters (3 ATM)
Case Material	Brass
Strap Material	Leather (Green)
Power Source	Battery Powered
Battery Type	1 Lithium Polymer (included)
Product Dimensions	14 x 7 x 10 cm; 200 g
Item Weight	200 g
Country of Origin	India

7. WARRANTY AND SUPPORT

This Fastrack watch comes with a manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included with your purchase or contact Fastrack customer support.

Manufacturer Contact Information:

Manufacturer: Titan Company Limited
Address: Sipcot Industrial Complex, Hosur, Tamil Nadu - 635129, India
Telephone: +91-(0)4344-664199

For further assistance, please visit the official Fastrack website or contact their customer service department.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B093GYJ6W4>

More documents and user manuals: <https://manuals.plus/>