

Fastrack NT6172SL03

Fastrack Wear Your Look Analog Watch User Manual

Model: NT6172SL03

INTRODUCTION

This manual provides essential instructions for the proper use and care of your Fastrack Wear Your Look Analog Watch, Model NT6172SL03. Please read this guide thoroughly to ensure optimal performance and longevity of your timepiece. This watch features a dynamic layered pink dial with unique semicircular date and circular day displays, clean silver accents, and a water-resistant build.

SETUP

Setting the Time and Date

1. **Pull out the Crown:** Gently pull the crown (the small knob on the side of the watch case) to position 2.
2. **Set the Time:** Rotate the crown clockwise or counter-clockwise to move the hour and minute hands to the desired time. Ensure you differentiate between AM and PM when setting the date, as the date changes around midnight.
3. **Set the Date and Day:** Your watch features a unique date and day display. Rotate the crown to adjust these. If your watch has a quick-set date/day function, you may be able to adjust it in position 1 (half-pulled out). Refer to the specific movement details if available.
4. **Push in the Crown:** Once the time, date, and day are set, push the crown back into position 1 (normal operating position) to start the watch movement.



Image: Side view of the watch, highlighting the crown used for setting time and date.

Adjusting the Strap

The watch comes with a leather strap and a buckle clasp. To adjust the fit:

1. **Open the Buckle:** Unfasten the buckle.
2. **Select a Hole:** Insert the pin of the buckle into the strap hole that provides a comfortable and secure fit on your wrist.
3. **Secure the Strap:** Thread the end of the strap through the keepers to hold it in place.



Image: The Fastrack watch worn on a wrist, demonstrating proper strap adjustment and fit.

OPERATING INSTRUCTIONS

Reading the Time

Your Fastrack Analog Watch displays time using traditional hour, minute, and second hands on a light pink dial with minimalist indices.



Image: Front view of the Fastrack Analog Watch, showcasing the pink dial and hands for time reading.

Water Resistance

This watch is water-resistant up to 30 meters (3 ATM). This means it is suitable for everyday use and can withstand splashes, rain, and brief immersion in water. It is *not* suitable for swimming, showering, or diving. Always ensure the crown is fully pushed in before any contact with water.

MAINTENANCE

Cleaning Your Watch

- Wipe the watch case and crystal with a soft, dry cloth.
- For the leather strap, avoid excessive moisture. If it gets wet, dry it gently with a soft cloth and allow it to air dry completely away from direct sunlight or heat.
- Do not use chemical cleaners, solvents, or abrasive materials, as these can damage the watch's finish or strap.

Battery Replacement

Your watch is powered by a quartz movement and requires a battery. When the watch stops or the second hand begins to skip, it indicates a low battery. Battery replacement should be performed by a

qualified watch technician to prevent damage to the movement and to ensure water resistance is maintained.

Storage

When not in use, store your watch in a cool, dry place, away from direct sunlight, extreme temperatures, and strong magnetic fields. Keeping it in its original box or a watch case is recommended.

TROUBLESHOOTING

- **Watch Not Running:**
 - Check if the crown is fully pushed in.
 - The battery may need replacement. Contact an authorized service center.
- **Incorrect Time/Date:**
 - Refer to the "Setting the Time and Date" section under Setup.
 - Ensure the crown is fully pushed in after setting.
- **Condensation Under Crystal:**
 - This may indicate moisture ingress. Immediately take the watch to an authorized service center to prevent further damage.

SPECIFICATIONS

Brand	Fastrack
Model Name	Wear Your Look
Model Number	NT6172SL03
Display Type	Analog
Movement Type	Quartz
Power Source Type	Battery Powered
Water Resistance Depth	30 Metres (3 ATM)
Clasp Type	Buckle
Band Material	Leather
Case Material	Metal
Crystal Material	Mineral Glass
Case Diameter	37 Millimetres
Band Width	18 Millimetres
Case Thickness	7.53 Millimetres

Band Length	24 Centimetres
Band Colour	Pink
Dial Colour	Light Pink
Item Weight	200 Grams
Country of Origin	India




Image: Visual guide illustrating the dial size of the Fastrack watch in comparison to common objects.

WARRANTY AND SUPPORT

Warranty Information

Your Fastrack watch comes with a **12-month manufacturer warranty** covering manufacturing defects. To avail warranty service, you must present your original purchase invoice at any authorized Titan Service Center. No separate warranty card is required.

Customer Support

For further details or service-related queries, please contact Fastrack/Titan customer support:

- **Toll-Free Number:** 1800-266-0123 (Available 10 AM to 7 PM, all days of the week)
- **Email:** customercare@titan.co.in
- **Manufacturer Address:** Titan Company Ltd, 3 Sipcot Industrial Complex, Hosur - 635126, Tamil Nadu, India.

Please have your purchase invoice ready when contacting support or visiting a service center.