

[Manuals.plus](#) /

› [Haus Projekt](#) /

› Haus Projekt Wall Bookcase for Children's Books, White/Wood - Model 01/003 Instruction Manual

Haus Projekt 01/003

Haus Projekt Wall Bookcase for Children's Books, White/Wood - Model 01/003 Instruction Manual

Model: 01/003 | Brand: Haus Projekt

1. INTRODUCTION AND OVERVIEW

This manual provides detailed instructions for the assembly, installation, and safe use of your Haus Projekt Wall Bookcase, Model 01/003. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

The Haus Projekt Wall Bookcase is a versatile storage unit designed to help organize books and smaller items. Its Scandinavian design complements various interior styles, making it suitable for children's rooms, living areas, kitchens, or bedrooms.



Image 1.1: The Haus Projekt Wall Bookcase, Model 01/003, displaying books and a small toy. This image illustrates the product's primary use as a children's bookshelf.

2. SAFETY INFORMATION

WARNING: Climbing on this product is prohibited.

- Ensure all wall mounting hardware is securely fastened to a suitable wall structure to prevent tipping.
- Adult assembly is required. Keep small parts away from children during assembly.
- Do not overload the shelves. Distribute weight evenly.

- Regularly check all fasteners to ensure they remain tight.

3. PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Bookcase side panels (2)
- Shelf panels (4)
- Pine rods (4)
- Assembly hardware (screws, wall anchors, etc.)
- Illustrated instruction manual




Image 3.1: A diagram illustrating the dimensions of the assembled bookcase, including overall height, width, depth, and individual shelf heights.

4. SETUP AND ASSEMBLY INSTRUCTIONS

This wooden children's bookcase comes flat-packed and requires adult assembly. Easy-to-follow illustrated instructions are included in the package. Wall mounting hardware is also provided.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Refer to the included illustrated instructions to identify each component (side panels, shelves, rods, screws).
3. **Assemble Shelves:** Attach the shelf panels to the side panels using the provided screws. Ensure the pre-drilled holes align correctly.
4. **Insert Rods:** Slide the pine rods into the designated holes on the front of each shelf. These rods act as a barrier to prevent items from falling.
5. **Wall Mounting:**
 - Choose a suitable wall location, ensuring it is free from electrical wires or plumbing.
 - Mark the desired mounting points on the wall using the bookcase as a guide.
 - Drill pilot holes at the marked locations.
 - Insert the appropriate wall anchors (provided) into the pilot holes.
 - Secure the bookcase to the wall using the provided screws, ensuring it is level and stable.

Note: Always use appropriate tools and follow the specific steps outlined in the included assembly guide for best results.

5. USAGE

The Haus Projekt Wall Bookcase is designed for versatile storage. It features four shelves, with three measuring 24 cm high and one larger shelf measuring 31 cm high, suitable for various items.

- **Children's Room:** Ideal for storing children's books, small toys, and decorative items. The gallery-style design allows book covers to be displayed, encouraging independent reading.
- **Living Room:** Can be used to display decorative objects, small plants, or media accessories.
- **Kitchen:** Suitable for organizing spices, small jars, or cookbooks.
- **Bedroom/Bathroom:** Useful for beauty products, accessories, or small towels.



Image 5.1: The bookcase repurposed in a kitchen setting, demonstrating its versatility for storing spices, oils, and cookbooks.



Image 5.2: A close-up view of one of the shelves, showing a plush toy resting against the pine rod, highlighting its use for children's items.

6. MAINTENANCE

- **Cleaning:** Wipe the bookcase with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Inspection:** Periodically check all screws and wall mounts to ensure they are tight and secure. Re-tighten if necessary.
- **Avoid Moisture:** Do not expose the bookcase to excessive moisture or direct sunlight, as this may cause warping or discoloration.

7. SPECIFICATIONS

Brand	Haus Projekt
-------	--------------

Model Number	01/003
Material	MDF Wood, Solid Pine Rods
Overall Dimensions (H x W x D)	118 cm x 50 cm x 12 cm
Shelf Dimensions (H x W x D)	3 shelves at 24 cm H x 50 cm W, 1 shelf at 31 cm H x 50 cm W
Number of Shelves	4
Mounting Type	Wall Mount
Style	Scandinavian

8. TROUBLESHOOTING

- **Bookcase feels wobbly after installation:** Ensure all wall mounting screws are securely tightened and that the wall anchors are properly installed. Verify that the wall surface is flat and sturdy.
- **Parts missing or damaged:** Do not proceed with assembly. Contact Haus Projekt customer support immediately for assistance.
- **Difficulty aligning holes during assembly:** Double-check that you are using the correct parts for each step and that they are oriented correctly. Sometimes, a slight adjustment or gentle pressure may be needed.

9. WARRANTY AND SUPPORT

Haus Projekt is committed to providing high-quality products. For information regarding warranty coverage, product support, or to report any issues, please visit the official Haus Projekt website or contact their customer service department.

You can often find support contact details on the product packaging or through the retailer where the item was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B093HHK5R3>

More documents and user manuals: <https://manuals.plus/>