

[Manuals.plus](#) /

› [JOYIN](#) /

› JOYIN 24 Pack 10-inch Mid Bubble Wands Assortment User Manual

JOYIN 13648

JOYIN 24 Pack 10-inch Mid Bubble Wands Assortment User Manual

Model: 13648

PRODUCT OVERVIEW

The JOYIN 24 Pack 10-inch Mid Bubble Wands Assortment provides a fun and engaging outdoor activity for children and adults. Each pack contains 24 bubble wands in 6 vibrant colors, pre-filled with 3 ounces of bubble solution. These wands are designed for easy handling and creating numerous bubbles, perfect for parties, summer play, and various outdoor events.



Image: A full set of JOYIN 10-inch Mid Bubble Wands, showcasing the variety of colors included in the 24-pack assortment.

SAFETY INFORMATION

Please read all safety instructions before use. This product is intended for children aged 3 years and up. Adult supervision is recommended during play.

- **Non-Toxic Solution:** The bubble solution is non-toxic and meets US toy standards. However, avoid ingestion. In case of accidental ingestion, rinse mouth with water.
- **Eye Contact:** If bubble solution comes into contact with eyes, rinse thoroughly with clean water for several minutes. If irritation persists, seek medical attention.
- **Choking Hazard:** Small parts may be present if wands are broken. Not suitable for children under 3 years due to potential choking hazards.
- **Outdoor Use:** Best used outdoors to prevent slippery surfaces from spilled solution.

SETUP

The JOYIN Bubble Wands are designed for immediate use with minimal setup required.

1. **Unpack:** Carefully remove the bubble wands from their packaging.
2. **Inspect:** Before first use, inspect each wand and its cap to ensure there are no leaks or damage.
3. **Open:** Twist the cap counter-clockwise to open the bubble wand. The bubble wand is attached to the cap.



Image: A young child demonstrating the use of a blue bubble wand, creating bubbles in an outdoor setting.

OPERATING INSTRUCTIONS

Follow these simple steps to create bubbles:

1. **Dip:** Ensure the bubble wand is fully immersed in the bubble solution inside the tube.
2. **Remove:** Slowly pull the wand out of the tube, allowing excess solution to drip back into the container. A thin film of solution should remain across the bubble loop.

3. **Blow or Wave:**

- **Blowing:** Gently blow through the bubble loop to create bubbles.
- **Waving:** For larger or more numerous bubbles, gently wave the wand through the air.

4. **Repeat:** Dip the wand back into the solution as needed to continue making bubbles.



Image: A child actively blowing bubbles with a pink bubble wand, demonstrating the product in use.

MAINTENANCE

Proper care will extend the life of your bubble wands.

- **Storage:** After use, securely twist the cap back onto the wand to prevent the bubble solution from drying out or leaking. Store in a cool, dry place away from direct sunlight.
- **Cleaning:** If the wands become dirty, wipe them with a damp cloth. Do not submerge the entire wand in water, especially the solution container.

- **Refilling:** While these wands come pre-filled, they can be refilled with standard bubble solution once empty. Ensure the solution is compatible and non-toxic.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No bubbles or very few bubbles.	Not enough solution on the wand. Solution is too old or diluted. Blowing too hard or too soft.	Dip the wand fully into the solution. Replace with fresh bubble solution. Adjust blowing technique; try gentle, steady breaths or waving the wand.
Solution leaking from the wand.	Cap not securely tightened. Wand or container is damaged.	Ensure the cap is twisted on tightly. If damaged, dispose of the wand and use another from the pack.
Bubbles pop too quickly.	Dry or windy conditions. Dust or debris on the wand.	Use in less windy conditions or humid environments. Gently wipe the wand clean before dipping.

SPECIFICATIONS

- **Product Name:** JOYIN 24 Pack 10-inch Mid Bubble Wands Assortment
- **Model Number:** 13648
- **Quantity:** 24 pieces per pack
- **Wand Length:** Approximately 10 inches (25.4 cm)
- **Solution Volume:** 3 ounces (approx. 88.7 ml) per wand
- **Colors:** Red, Orange, Yellow, Green, Purple, Blue (assorted)
- **Recommended Age:** 3 years and up
- **Material:** Child-safe, non-toxic plastic and bubble solution
- **Package Dimensions:** 10.75 x 7.36 x 4.96 inches
- **Item Weight:** 5.41 pounds (total package)



Image: Diagram showing the dimensions of a single bubble wand, highlighting its 10-inch length.

WARRANTY AND SUPPORT

JOYIN is committed to providing high-quality products and customer satisfaction. If you encounter any issues with your JOYIN 24 Pack 10-inch Mid Bubble Wands Assortment, please contact our customer support team.

- **Customer Service:** For support, please visit the official JOYIN store on Amazon or contact us through the Amazon platform.
- **Product Quality:** We ensure our products meet US toy standards and are safety tested. If a product does not meet your expectations, please reach out to us for assistance.

For more information, you can visit the [JOYIN Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question