

Audio Pro C10 MkII

Audio Pro Addon C10 MKII Wireless Speaker User Manual

MODEL: C10 MkII

Brand: Audio Pro

1. Introduction

The Audio Pro Addon C10 MKII is a versatile wireless speaker designed to deliver rich, detailed sound with high-fidelity audio performance. It supports multiple connectivity options including Bluetooth, WiFi, Chromecast, and AirPlay 2, making it suitable for various audio setups and multi-room systems. Its compact design and intuitive controls ensure a seamless listening experience.



Front view of the Audio Pro Addon C10 MKII Speaker.

This image displays the front of the Audio Pro Addon C10 MKII speaker, highlighting its main speaker grille and compact form factor.


2. Setup

To begin using your Audio Pro Addon C10 MKII speaker, ensure it is connected to a power source. For optimal functionality and access to all features, it is recommended to connect the speaker to your home WiFi network using the Audio Pro Control app.

2.1. Physical Connections

The speaker offers various physical input options on its rear panel, including RCA and 3.5mm auxiliary inputs for connecting external audio devices such as turntables (requires a built-in or external RIAA amplifier) or other media players.

Control Audio Pro units with the *Audio Pro Control* app for iOS and Android.




Rear panel with various input and output connections.

This image shows the rear panel of the speaker, detailing the available ports for power, RCA, 3.5mm auxiliary, and USB connections.

2.2. Wireless Setup and App Control

The Audio Pro Control app provides full control over your speaker, including initial setup, managing multi-room audio, and accessing streaming services. Download the app from your device's app store.

Save playlists and radio channels as presets for easy access.



The Audio Pro Control app interface.

This image illustrates the user interface of the Audio Pro Control app on a smartphone, showing speaker selection and settings.

2.3. Connecting a Turntable

You can connect a turntable to your Audio Pro speaker using cables or Bluetooth if available. When using cables, ensure your turntable has a built-in or external RIAA amplifier. If you use an Audio Pro speaker with WiFi, you can re-stream the turntable audio to other speakers in your multi-room setup.

This video demonstrates how to connect a turntable to your Audio Pro speaker, detailing the necessary cable connections and considerations for RIAA amplification.

3. Operating the Speaker

The Addon C10 MKII offers multiple ways to control your audio playback, including physical buttons on the speaker, a remote control, and the Audio Pro Control app.

3.1. Physical Controls

The top panel of the speaker features buttons for power, source selection (WiFi, Bluetooth, Aux, Line In), play/pause, volume control, and six preset buttons for quick access to your favorite music or radio stations.

Play from three different inputs.




WiFi



BLUETOOTH



LINE IN



RIAA-amp may be needed.

Top panel controls for the speaker.

This image provides a close-up of the speaker's top panel, showing the layout of the control buttons and the central volume knob.

3.2. Using Presets

Presets allow you to save shortcuts to your favorite music and audio content. Audio from any streaming service in the Audio Pro app can be set as a preset. You can access presets via the buttons on the speaker, Audio Pro remotes, or directly through the Audio Pro app.

This video illustrates how to save and use presets on your Audio Pro speaker, providing a quick way to access your preferred audio content.

3.3. Spotify Connect and AirPlay 2

The speaker supports Spotify Connect and AirPlay 2 for seamless streaming from compatible devices. These features allow you to control playback directly from your music apps.

This video provides a step-by-step guide on how to use Spotify Connect with your Audio Pro speaker.

This video explains how to use AirPlay for audio streaming to your Audio Pro speaker from Apple devices.

3.4. WiFi vs. Bluetooth

WiFi unlocks advanced features like multi-room audio and presets, offering higher fidelity and range. Bluetooth provides convenient direct connection for quick playback from nearby devices.

This video compares WiFi and Bluetooth connectivity options for Audio Pro speakers, highlighting their respective benefits.

4. Maintenance

To ensure the longevity and optimal performance of your Audio Pro Addon C10 MKII speaker, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the speaker's surfaces. Avoid abrasive cleaners or solvents, as they may damage the finish.
- **Fabric Cover:** The removable fabric cover can be gently cleaned with a lint roller or a soft brush to remove dust. For deeper cleaning, consult Audio Pro's official guidelines or a professional.
- **Placement:** Place the speaker on a stable, flat surface away from direct sunlight, heat sources, and excessive moisture. Ensure adequate ventilation around the unit.
- **Storage:** If storing the speaker for an extended period, disconnect it from power and store it in a cool, dry place.

5. Troubleshooting

If you encounter issues with your Audio Pro Addon C10 MKII speaker, refer to the following common troubleshooting steps:

- **No Sound:**
 - Check if the speaker is powered on and the volume is turned up.
 - Verify the correct input source is selected (WiFi, Bluetooth, Aux, Line In).
 - Ensure your source device (phone, tablet, computer) is playing audio and its volume is also up.
 - For wireless connections, check network stability and device pairing.
- **Connectivity Issues (WiFi/Bluetooth):**
 - Restart the speaker and your source device.
 - Ensure the speaker is within range of your WiFi router or Bluetooth device.
 - If using WiFi, check your network settings and ensure the speaker is connected to the correct network.
 - For Bluetooth, try unpairing and re-pairing the device.
- **Subwoofer Sleep Mode (when connected via RCA):**
 - Some subwoofers may enter a sleep mode if the input signal is too low or intermittent.
 - Ensure the volume output from the C10 MKII to the subwoofer is sufficient.
 - Check the subwoofer's settings for an 'always on' or 'auto-sense' mode. If available, setting it to

'always on' might resolve the issue.

- **Buttons Not Responding:**

- Perform a soft reset by unplugging the speaker from the power outlet for a few minutes, then plugging it back in.
- Ensure the buttons are clean and free from debris.

For more detailed troubleshooting or persistent issues, refer to the Audio Pro Control app's help section or visit the official Audio Pro support website.

6. Specifications

Feature	Specification
Model Name	Addon C10 MKII
Speaker Type	Wireless Multiroom
Connectivity Technology	Bluetooth, Wi-Fi
Speaker Maximum Output Power	80 Watts
Product Dimensions	7.09"D x 12.6"W x 6.54"H
Item Weight	8.8 pounds (4 Kilograms)
Subwoofer Diameter	5.25 Inches
Woofer Diameter	5.25 Inches
Tweeter Diameter	0.75 Inches
Control Method	App
Compatible Devices	Laptop, Tablet, Smartphone
Audio Output Mode	Stereo
First Available Date	April 28, 2021

7. Warranty and Support

Your Audio Pro Addon C10 MKII speaker comes with a manufacturer's warranty covering defects in materials and workmanship. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Audio Pro website.

For technical support, troubleshooting assistance, or service inquiries, please contact Audio Pro customer support through their official website or the Audio Pro Control app. Keep your proof of purchase handy when contacting support.