Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Logitech /
- > Logitech Rally Bar All-in-One Video Bar User Manual

Logitech 960-001308

Logitech Rally Bar All-in-One Video Bar User Manual

Model: 960-001308

1. Introduction

The Logitech Rally Bar is an advanced all-in-one video bar designed for medium and large meeting rooms. It integrates cinema-quality video, crystal-clear audio, and Al-driven performance to deliver a seamless and natural meeting experience. This manual provides comprehensive instructions for setting up, operating, and maintaining your Rally Bar, ensuring optimal performance for your video collaboration needs.

The Rally Bar is engineered for ease of use and robust functionality, making it an ideal solution for modern meeting environments. Its sustainable design incorporates 40% certified post-consumer recycled plastic in its plastic parts, excluding cables, PWA, and packaging.

2. WHAT'S IN THE BOX

Upon unboxing your Logitech Rally Bar, please verify that all the following components are included:

- UHD 4K camera
- · Al Viewfinder camera
- · Six beamforming microphones
- · Three speakers
- USB cable
- · User manual (this document)

3. SETUP GUIDE

The Logitech Rally Bar is designed for straightforward installation. Follow these steps to set up your device:

1. **Placement:** Position the Rally Bar centrally in your meeting room, ideally below or above your primary display. Ensure it has a clear line of sight to all meeting participants.



Figure 3.1: Front view of the Logitech Rally Bar on its stand.

- 2. **Connect to Power:** Connect the provided power adapter to the Rally Bar's power input port and then to a wall outlet.
- 3. **Connect to Display:** Use an HDMI cable (not included) to connect the Rally Bar's HDMI output port to your meeting room display.

4. Connect to Computer/Network:

- For USB Mode: Connect the provided USB cable from the Rally Bar to your meeting room computer (PC, laptop, or Mac). This enables plug-and-play functionality for most video conferencing applications.
- For Appliance Mode (Room Solution): Connect the Rally Bar to your network via an Ethernet cable for direct integration with supported platforms like Microsoft Teams Rooms or Zoom Rooms.



Figure 3.2: Rear view of the Rally Bar, highlighting connectivity ports.

5. **Initial Power On:** The Rally Bar will power on automatically once connected to power. Follow any onscreen prompts for initial setup.

4. OPERATING INSTRUCTIONS

The Logitech Rally Bar is designed for intuitive operation. Here's how to get started with your video conferences:

4.1. Platform Compatibility

The Rally Bar is certified for and works seamlessly with leading video conferencing platforms, including:

- Microsoft Teams
- Zoom
- · Google Meet
- And other platforms that support standard USB video and audio devices.

Simply select the Logitech Rally Bar as your camera, microphone, and speaker within your chosen video conferencing application settings.

4.2. Using the Remote Control

The included remote control provides convenient access to essential functions:

- Volume Control: Adjust speaker volume up or down.
- Mute Microphone: Mute or unmute the integrated microphones.
- Camera Pan/Tilt/Zoom (PTZ): Manually adjust the camera's view.
- Presets: Save and recall specific camera positions for quick access during meetings.




Figure 4.1: Logitech Rally Bar shown with its remote control.

4.3. Al Viewfinder and Framing

The Rally Bar features an Al Viewfinder that continuously scans the room to ensure all participants are framed optimally. This intelligent feature provides two main modes:

- Auto-Framing: Automatically adjusts the camera to keep all detected participants in view.
- **Speaker Tracking:** Focuses on the active speaker, dynamically shifting the view as different individuals speak.



Figure 4.2: Illustration of Rally Bar's Al framing and microphone coverage in a meeting space.

5. KEY FEATURES

The Logitech Rally Bar is packed with features designed to enhance your meeting experience:

- All-in-One Design: Combines camera, microphones, and speakers into a single, sleek device for simplified setup and reduced cable clutter.
- Cinema-Quality Video: Features a UHD 4K camera with motorized pan, tilt, and 15x optical + digital HD zoom, ensuring clear visuals even in large rooms.
- AI-Driven Performance: The AI Viewfinder and RightSense[™] technologies (including RightSight[™] for auto-framing and RightLight[™] for optimal lighting) provide intelligent camera control and image optimization.
- Crystal-Clear Audio: Equipped with six beamforming microphones and three low-distortion speakers, optimized by RightSound™ technology for outstanding conversational accuracy and noise suppression.
- Extended Microphone Range: Offers an expansive 15-foot mic pickup range, with the option to extend coverage for larger groups by adding up to four Rally Mic Pods (sold separately).
- Remote Management with Sync: Utilize Logitech Sync to monitor room health, deploy updates, and modify settings for your Rally Bar from a single cloud-based platform.
- Sustainable Design: Plastic parts in the Graphite version include 40% certified post-consumer recycled plastic, reflecting a commitment to environmental responsibility.

6. MAINTENANCE

To ensure the longevity and optimal performance of your Logitech Rally Bar, follow these maintenance guidelines:

- Cleaning: Gently wipe the exterior of the Rally Bar with a soft, dry, lint-free cloth. Do not use abrasive cleaners, solvents, or aerosol sprays. For the camera lens, use a lens cleaning cloth specifically designed for optics.
- **Firmware Updates:** Regularly check for and install firmware updates via Logitech Sync. Updates often include performance improvements, bug fixes, and new features.
- Cable Management: Ensure all cables are neatly organized and not under strain to prevent damage to the ports or cables themselves.
- Environmental Conditions: Operate the Rally Bar within recommended temperature and humidity ranges. Avoid exposing it to extreme temperatures, direct sunlight, or excessive moisture.

7. TROUBLESHOOTING

If you encounter issues with your Logitech Rally Bar, try the following troubleshooting steps:

· No Power:

- Verify the power cable is securely connected to the Rally Bar and the power outlet.
- Ensure the power outlet is functional.

• No Video/Audio in Meeting:

- Check USB and HDMI cable connections.
- In your video conferencing application, confirm that "Logitech Rally Bar" is selected as the camera, microphone, and speaker device.
- · Restart your computer and the Rally Bar.

• Poor Video Quality:

- Ensure adequate lighting in the room.
- Check your internet connection speed.
- · Clean the camera lens.

• Poor Audio Quality:

- Ensure microphones are not muted.
- Check for obstructions blocking the microphones or speakers.
- Adjust speaker volume.
- Minimize background noise in the room.

Al Framing Issues:

- Ensure the Al Viewfinder camera is not obstructed.
- Verify that auto-framing or speaker tracking is enabled in Logitech Sync or your video conferencing application settings.

For more detailed troubleshooting or persistent issues, please refer to the Logitech support website or contact customer service.

8. Specifications

Feature	Specification
Brand	Logitech
Series	RALLY BAR
Model Number	960-001308
Product Dimensions	39 x 8.25 x 8 inches
Item Weight	20.7 pounds
Color	Graphite
Rear Webcam Resolution	12 MP
Platform Compatibility	PC, Laptop, Mac
Microphone Pickup Range	15 feet (expandable with Mic Pods)
Zoom Capability	15x optical + digital HD zoom

9. WARRANTY AND SUPPORT

Logitech provides a standard limited hardware warranty for the Rally Bar. For specific warranty terms and conditions, please refer to the warranty information included with your product or visit the official Logitech support website.

For technical support, product registration, and access to drivers, firmware, and FAQs, please visit the Logitech Support website. You can also find contact information for customer service there.

Logitech Support Website: support.logi.com

Related Documents - 960-001308

