

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Moultrie](#) /

› [Moultrie 30-Gallon Deer Feeder Pro II Tripod Instruction Manual](#)

Moultrie MFG-13450

Moultrie 30-Gallon Deer Feeder Pro II Tripod

Model: MFG-13450

INTRODUCTION

The Moultrie 30-Gallon Deer Feeder Pro II Tripod is designed for efficient and reliable game feeding. This system features a durable polymer hopper, a Quick-Lock adapter for easy assembly, and a digital timer for precise feed scheduling. It is built to withstand outdoor conditions and provide consistent feed distribution for deer and other wildlife.

KEY FEATURES

- **Heavy-duty polymer hopper:** Holds more than 200 pounds of corn.
- **Fill height of 5.5 feet:** Allows for easy ground-level access.
- **Included Pro Classic II Feeder Kit:** Features a plastic spin plate, adjustable funnel, ABS plastic housing, feed-level estimator, battery indicator, and external power port.
- **Digital timer:** Programs up to 10 feed times per day, with durations from 1 to 60 seconds.
- **Quick-Lock adapter:** Designed to mount to any barrel or hopper.
- **Power Requirement:** Requires one (1) 6V Battery (Not Included).

SETUP

Assembly

The Moultrie 30-Gallon Deer Feeder Pro II Tripod is designed for straightforward assembly. Begin by securely attaching the tripod legs to the hopper system. Ensure all connections are tight and stable before proceeding.



Front view of the Moultrie 30-Gallon Deer Feeder Tripod Quick-Lock Hopper System, showcasing its black polymer hopper and sturdy tripod legs.

Battery Installation

Locate the battery compartment, typically within the feeder kit housing. Insert one (1) 6V battery (not included) ensuring correct polarity. Close the compartment securely.

Hopper Filling

Once assembled and positioned, open the top lid of the hopper. Carefully pour your desired feed (e.g., corn) into the hopper, ensuring it does not exceed the maximum capacity of 200 pounds. Close the lid securely to protect the feed from elements and pests.



A person opening the top lid of the Moultrie 30-Gallon Deer Feeder, illustrating easy access to the hopper for refilling.



A person pouring feed into the Moultrie 30-Gallon Deer Feeder's hopper, highlighting the convenient top-fill design.

OPERATING

Digital Timer Programming

The integrated digital timer allows for precise control over feeding schedules. Refer to the feeder kit's specific instructions for detailed programming steps. You can set up to 10 daily feed times, with each duration adjustable from 1 to 60 seconds. Utilize the battery indicator to monitor power levels.



Close-up view of hands adjusting the digital timer control panel of the Moultrie feeder, showing the display and control buttons.

MAINTENANCE

Cleaning

Regular cleaning of the hopper and spin plate is recommended to prevent clogs and ensure consistent feed flow. Use a damp cloth to wipe down exterior surfaces. For the spin plate and funnel, ensure no debris or old feed accumulates.

Battery Replacement

Replace the 6V battery when the battery indicator shows low power. Always use a fresh battery to ensure optimal performance and prevent interruptions in feeding schedules.

General Care

Periodically inspect the tripod legs and hopper for any signs of wear or damage. Ensure the Quick-Lock adapter remains securely fastened. Store the feeder in a dry, protected area when not in use for extended periods.

TROUBLESHOOTING

Feeder Not Dispensing

- Check battery level and replace if necessary.
- Inspect the spin plate and funnel for clogs from feed or debris.
- Verify timer settings are correctly programmed and active.

Inconsistent Feed Amounts

- Ensure the feed type is suitable for the feeder and not causing blockages.
- Adjust feed duration settings on the digital timer.
- Check for any obstructions around the spin plate.




SPECIFICATIONS


Feature	Detail
Brand	Moultrie
Model Name	30-Gallon Deer Feeder Pro II Tripod
Model Number	MFG-13450
Target Species	Deer
Material	Polymer (Hopper), Other (General)
Special Feature	Heavy Duty
Mounting Type	Freestanding
Product Dimensions (LxWxH)	18.5" x 24.25" x 66"
Power Source	Battery Powered (1x 6V Battery, not included)
Included Components	30-Gallon Deer Feeder Pro II Tripod
Capacity	200 Pounds
Color	Multi
UPC	053695134505

WARRANTY & SUPPORT

This Moultrie product comes with a **1-year warranty** from the date of purchase. For warranty claims, technical assistance, or any questions regarding your feeder, please contact Moultrie customer support directly. You can find contact information on the official Moultrie website or through your retailer.

For additional resources and product information, visit the official [Moultrie Store on Amazon](#).

	<p>Moultrie Directional Quick-Lock Feeder Kit Instructions</p> <p>Step-by-step instructions for configuring, testing, and assembling the Moultrie Directional Quick-Lock Feeder Kit, including battery installation, time settings, and mounting to various feeder types.</p>
	<p>Moultrie Programmable Digital Timer Quick-Lock Kits: Assembly and Configuration Instructions</p> <p>Comprehensive instructions for assembling and configuring the Moultrie Programmable Digital Timer Quick-Lock Kits, including battery installation, timer settings, and adapter assembly for various feeder types. Features detailed steps for barrel and hopper mounting.</p>
	<p>Moultrie Gravity Feeder Kit Installation Instructions</p> <p>Comprehensive guide for assembling and installing the Moultrie Gravity Feeder Kit (model MFG-13338). It covers hardware identification, parts list, step-by-step assembly for the feeder kit, integration with Moultrie Quick-Lock Hoppers and barrels, and final setup. Includes guidance on feed flow adjustment and weight limits.</p>
	<p>Moultrie Pro Hunter II Feeder Kit Assembly and Operation Instructions</p> <p>Comprehensive guide for setting up and using the Moultrie Pro Hunter II Feeder Kit. Covers battery installation, time and day settings, feed duration, motor speed, and assembly instructions for 30-gallon and 55-gallon barrels and hoppers.</p>
	<p>Moultrie Programmable Digital Timer Quick-Lock Kits: Assembly and Configuration Guide</p> <p>Detailed instructions for assembling and configuring Moultrie Programmable Digital Timer Quick-Lock Kits for various feeder barrels and hoppers. Includes battery installation, timer settings, and mounting procedures.</p>



Moultrie Standard Feeder Quick-Lock Hopper Assembly and Operation Guide

Detailed instructions for setting up and using the Moultrie Standard Quick-Lock Feeder. Covers battery installation, feeder configuration, timer settings, run duration, testing, and assembly of the hopper and legs.