

[Manuals.plus](#) /

> [Kinderplay](#) /

> Kinderplay Baby Doll Stroller Model KP0261R Instruction Manual

## Kinderplay KP0261R

# Kinderplay Baby Doll Stroller Model KP0261R Instruction Manual

Model: KP0261R

---

## 1. INTRODUCTION

---

Welcome to your Kinderplay Baby Doll Stroller, Model KP0261R. This manual provides essential information for the safe assembly, operation, and maintenance of your doll stroller. Please read these instructions carefully before use to ensure proper function and longevity of the product.



Image 1.1: Fully assembled Kinderplay Baby Doll Stroller Model KP0261R.

## 2. SAFETY INFORMATION

Please observe the following safety guidelines to prevent injury or damage:

- This stroller is a toy and is not suitable for children younger than 2 years old.
- This item is a toy and is not designed for carrying real babies, children, or pets.
- Adult assembly is required to ensure proper construction and prevent the item from collapsing during use.
- Remove all packaging materials, plastic bags, and small parts before giving the product to children.

(EN) Doll stroller. (DE) Puppenwagen. (PL) Wózek dla lalek. (IT) Passeggino per bambole. (FR) Poussette pour poupées. (ES) Cochecito para muñecas.

**(EN) Warning:** 1. This stroller is not suitable for children younger than 2 years old. 2. This item is a toy and is not suitable for carrying babies, children, or pets. 3. Assembly should be carried out by an adult to prevent the item from collapsing during use. 4. Please remove all package before giving this item to your children. **(DE) Warnung:** 1. Dieser Kinderwagen ist nicht für Kinder unter 2 Jahren geeignet. 2. Dieser Artikel ist ein Spielzeug und nicht zum Transport von Babys, Kindern oder Haustieren geeignet. 3. Der Zusammenbau sollte von einem Erwachsenen durchgeführt werden, um ein Zusammenklappen während der Benutzung zu verhindern. 4. Bitte entfernen Sie alle Verpackungen, bevor Sie diesen Artikel Ihren Kindern geben. **(PL) Ostrzeżenie:** 1. Ten wózek nie nadaje się dla dzieci młodszych niż 2 lata. 2. Ten przedmiot jest zabawką i nie nadaje się do przewożenia niemowląt, dzieci ani zwierząt. 3. Montaż powinien być przeprowadzony przez osobę dorosłą, aby zapobiec złożeniu się przedmiotu podczas użytkowania. 4. Proszę usunąć wszystkie opakowania przed przekazaniem tego przedmiotu dzieciom. **(IT) Avvertenza:** 1. Questo passeggino non è adatto a bambini di età inferiore ai 2 anni. 2. Questo oggetto è un giocattolo e non è adatto per trasportare neonati, bambini o animali domestici. 3. Il montaggio deve essere eseguito da un adulto per evitare che l'oggetto collassi durante l'uso. 4. Si prega di rimuovere tutti gli imballaggi prima di dare questo oggetto ai vostri bambini. **(FR) Avertissement :** 1. Cette poussette n'est pas adaptée aux enfants de moins de 2 ans. 2. Cet article est un jouet et n'est pas adapté pour transporter des bébés, des enfants ou des animaux. 3. Le montage doit être effectué par un adulte pour éviter que l'objet ne s'effondre pendant l'utilisation. 4. Veuillez retirer tous les emballages avant de donner cet article à vos enfants. **(ES) Advertencia:** 1. Este cochecito no es adecuado para niños menores de 2 años. 2. Este artículo es un juguete y no es apto para transportar bebés, niños o mascotas. 3. El ensamblaje debe ser realizado por un adulto para evitar que el artículo se colapse durante su uso. 4. Por favor, retire todo el embalaje antes de dar este artículo a sus hijos.

Item: KP0261R  
Batch: 20241017



**Manufactured by:** A&S Sp. z o.o.  
ul. Niepodległości 38, 67-400 Wschowa, Polska  
www.kinderplay.eu / kontakt@linkbaby.pl  
**Imported by:** A&S Sp. z o.o.  
ul. Niepodległości 38, 67-400 Wschowa, Polska  
www.kinderplay.eu / kontakt@linkbaby.pl  
Made in China



Image 2.1: Product warning label with safety instructions and manufacturer details.

### 3. PACKAGE CONTENTS

The Kinderplay Baby Doll Stroller Model KP0261R package includes the following components:

- Stroller frame (partially assembled)
- Stroller bassinet/seat fabric
- Adjustable handle
- Wheels (4)
- Storage bag
- Instruction leaflet



Image 3.1: Unboxed components of the Kinderplay Baby Doll Stroller.

## 4. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your Kinderplay Baby Doll Stroller. Adult assembly is required.

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all components listed in the "Package Contents" section are present.
2. **Attach Wheels:** Securely attach the four wheels to the designated points on the stroller frame. Ensure they click into place or are firmly fastened according to the included leaflet.

3. **Install Bassinet/Seat Fabric:** Place the fabric bassinet or seat onto the stroller frame, ensuring all attachment points (snaps, clips, or straps) are securely fastened.
4. **Adjust Handle:** The handle is designed to be adjustable. Position it to the desired height by engaging the adjustment mechanism.
5. **Attach Storage Bag:** Hook or clip the storage bag onto the handle or frame as intended for additional storage.

## 5. OPERATING INSTRUCTIONS

### 5.1. Adjusting the Handle Height

The stroller features an adjustable handle to accommodate different user heights. To adjust, locate the adjustment mechanism (typically a button or lever) on the handle. Engage the mechanism, move the handle to the desired height between 12.99 inches (33 cm) and 24.80 inches (63 cm), and then release the mechanism to lock the handle securely in place.



Image 5.1: Illustration of the adjustable handle height feature.

### 5.2. Placing a Doll

This stroller is designed for dolls up to 16.14 inches (41 cm) tall. Gently place your doll into the bassinet or

seat. Ensure the doll is seated securely within the stroller's fabric components.

## Compatible with 41 cm dolls



Image 5.2: Doll placed in the stroller, showing compatibility.

## 6. MAINTENANCE AND CARE

### 6.1. Cleaning

All fabric elements of the stroller can be removed and machine-washed at 30°C (86°F). Allow fabric to air dry completely before reattaching to the frame. The stroller frame and wheels can be wiped clean with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners.



## Easy to Clean & Maintain



Image 6.1: Visual representation of the stroller's easy-to-clean features.

### 6.2. Storage

Store the stroller in a clean, dry place away from direct sunlight and extreme temperatures when not in use. This will help preserve the fabric and frame integrity.

## 7. SPECIFICATIONS

Feature	Detail
Model Number	KP0261R
Brand	Kinderplay
Recommended Age	24 months - 6 years
Product Dimensions (L x W x H)	18.9 x 14.17 x 24.8 inches (48 x 36 x 63 cm)
Item Weight	5.48 pounds (2.49 kg)
Adjustable Handle Height	12.99 - 24.80 inches (33 - 63 cm)

Feature	Detail
Gondola Length	16.14 inches (41 cm)
Gondola Width	7.48 inches (19 cm)
Wheel Diameter	5.9 inches (15 cm)
Wheel Thickness	1.57 inches (4 cm)
Doll Compatibility	Up to 16.14 inches (41 cm)



Image 7.1: Detailed view of stroller components and features.

## 8. TROUBLESHOOTING

For any issues not covered in this manual, or if you encounter difficulties during assembly or operation, please contact Kinderplay customer support for assistance.

## 9. WARRANTY AND SUPPORT

Kinderplay products are manufactured to high-quality standards. For specific warranty information or customer support, please refer to the contact details provided on the product packaging or visit the official Kinderplay website.

You can also visit the Kinderplay store on Amazon for more products and information:[Kinderplay Store on Amazon](#).

---

© 2024 Kinderplay. All rights reserved.