

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SUPRA](#) /

› [SUPRA Elba Built-in Gas Cooktop and Range Hood Combo User Manual \(Models EXQUISIT & CM-60\)](#)

SUPRA EXQUISIT, CM-60

SUPRA Elba Built-in Gas Cooktop and Range Hood Combo User Manual

Models: EXQUISIT (Cooktop), CM-60 (Range Hood)

1. INTRODUCTION

This manual provides essential information for the safe and efficient installation, operation, and maintenance of your SUPRA Elba Built-in Gas Cooktop (Model EXQUISIT) and Wall-Mounted Range Hood (Model CM-60). Please read this manual thoroughly before using the appliances and retain it for future reference.

The SUPRA Elba combo is designed to offer a complete cooking solution, featuring a 4-burner gas cooktop with electronic ignition and a 60 cm stainless steel range hood with three extraction levels.

2. SAFETY INFORMATION

General Safety Precautions:

- Ensure proper ventilation when operating gas appliances.
- Do not store flammable materials near the cooktop or range hood.
- Keep children away from the appliances during operation.
- Always turn off the gas supply and disconnect power before cleaning or maintenance.
- Installation must be performed by a qualified technician in accordance with local regulations.
- Do not modify the appliance. Any unauthorized modifications may void the warranty and create safety hazards.

Gas Safety:

- Check for gas leaks regularly using a soapy water solution. Never use an open flame.
- If you smell gas, immediately turn off the main gas supply, open windows, and do not operate any electrical switches or appliances. Contact a qualified technician.

Electrical Safety:

- Ensure the appliance is properly grounded.
- Do not operate the range hood with a damaged power cord or plug.

3. PACKAGE CONTENTS

Upon unpacking, verify that all components are present and undamaged:

- SUPRA EXQUISIT 4-Burner Built-in Gas Cooktop
- SUPRA CM-60 Wall-Mounted Range Hood
- Cooktop Grates and Burner Caps
- Control Knobs
- Range Hood Filters (2 units)
- Installation Kit for Range Hood (includes dust cover)
- Gas Injectors for LP and Natural Gas conversion
- User Manual
- Warranty Policy

4. SETUP AND INSTALLATION

General Installation Guidelines:

- Ensure adequate clearance around both appliances as specified in the detailed installation diagrams.
- All gas and electrical connections must comply with local codes and regulations.

4.1 Cooktop Installation (Model EXQUISIT)

The SUPRA EXQUISIT cooktop is designed for built-in installation. The required cutout dimensions for installation are 56 cm (front) x 47 cm (depth). The cooktop itself measures 60 cm (front) x 51 cm (depth) x 11.5 cm (height) and weighs 12.3 kg.

Gas Type Conversion:

The cooktop is factory-configured for LP Gas. However, it includes injectors for easy conversion to Natural Gas. The injectors are simple to change by screwing and unscrewing them. Refer to the diagram below for visual guidance.



Parrilla configurada de fábrica
para funcionar con Gas L.P.
pero incluye espreas para un fácil
cambio a Gas Natural.



- Incluye espreas muy fáciles de cambiar (atornilla y desatornilla)
- Gas LP o Gas Natural ¡tú decides!

Consulte el manual de usuario para una mayor referencia.

Image: Diagram illustrating the gas conversion process for the SUPRA cooktop, showing LP and Natural Gas injectors.



Image: Dimensional drawing of the SUPRA 4-burner gas cooktop, indicating its length (60cm), width (49cm), and height (20cm).

4.2 Range Hood Installation (Model CM-60)

The CM-60 range hood is a wall-mounted, chimney-style unit. It measures 60 cm (front) x 48 cm (depth) x 50 cm (height) and weighs 7.27 kg. The installation kit, including a dust cover, is provided. Ensure the hood is mounted at the recommended height above the cooktop for optimal performance and safety.



Image: Front view of the SUPRA wall-mounted range hood (Model CM-60) with controls visible.



Image: Angled view of the SUPRA wall-mounted range hood (Model CM-60), highlighting its stainless steel finish and filters.



Image: Top-down view of the SUPRA wall-mounted range hood (Model CM-60), showing the chimney and overall design.

5. OPERATING INSTRUCTIONS

5.1 Operating the Gas Cooktop (Model EXQUISIT)

The EXQUISIT cooktop features four gas burners with electronic ignition, each having different thermal capacities. The burners are made of aluminum alloy with cast iron grates.

- **Ignition:** To ignite a burner, push down and turn the corresponding control knob counter-clockwise to the 'High' flame setting. The electronic ignition will spark. Hold the knob for a few seconds until the flame is stable.
- **Flame Adjustment:** Once ignited, adjust the flame size by turning the knob between 'High' and 'Low' settings.
- **Safety Valve:** Each burner is equipped with a safety valve that automatically cuts off the gas supply if the flame accidentally extinguishes.



Image: Top view of the SUPRA 4-burner gas cooktop (Model EXQUISIT), displaying the burner layout and control knobs.



Image: Angled view of the SUPRA 4-burner gas cooktop (Model EXQUISIT), showing the stainless steel surface and cast iron grates.

5.2 Operating the Range Hood (Model CM-60)

The CM-60 range hood features a mechanical control panel and offers three levels of extraction to effectively remove smoke

and odors from your kitchen.

- **Power On/Off:** Use the designated button on the mechanical panel to turn the hood on or off.
- **Speed Selection:** Select from the three extraction levels (Low, Medium, High) using the corresponding buttons to match your cooking needs.
- **Lighting:** The hood includes LED lighting. Use the light button to illuminate your cooking area.



Image: Main product image showing both the SUPRA gas cooktop and the wall-mounted range hood.

6. MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and optimal performance of your SUPRA appliances.

6.1 Cooktop Maintenance

- **Cleaning the Surface:** The cooktop features an enameled steel burner plate and stainless steel surface. For best care, use a damp microfiber cloth to clean spills and stains. Avoid abrasive cleaners that can scratch the surface.

- **Burner Components:** The control knobs are removable for easier cleaning. The burner caps and grates are made of cast iron and can be cleaned with warm soapy water. Ensure all parts are completely dry before reassembling.
- **Anti-Spill Gaskets:** The knobs and burners have anti-spill rubber gaskets to prevent liquids from entering the internal components. Clean these gently.

6.2 Range Hood Maintenance

- **Filter Cleaning:** The range hood includes two removable and washable stainless steel filters with aluminum frames. These filters trap grease and should be cleaned regularly (e.g., monthly, depending on usage) to maintain extraction efficiency. They can be washed by hand with warm soapy water or in a dishwasher.
- **Exterior Cleaning:** Clean the stainless steel exterior with a soft cloth and a non-abrasive stainless steel cleaner.

7. TROUBLESHOOTING

If you encounter any issues with your SUPRA Elba combo, please review the following common problems and solutions. If the problem persists, contact SUPRA customer support.

- **Cooktop Burner Not Igniting:** Check if the gas supply is open. Ensure the burner cap and ring are correctly positioned. Clean the ignition electrode if it appears dirty.
- **Weak or Irregular Flame:** Verify the gas pressure. Ensure the burner ports are not clogged.
- **Range Hood Not Operating:** Check if the power cord is securely plugged in. Verify the circuit breaker.
- **Poor Extraction Performance:** Clean or replace the grease filters. Ensure the exhaust duct is not blocked.

8. SPECIFICATIONS

Feature	Specification
Brand	SUPRA
Cooktop Model	EXQUISIT
Range Hood Model	CM-60
Color	Silver
Cooktop Dimensions (Front x Depth x Height)	60 cm x 51 cm x 11.5 cm
Cooktop Cutout Dimensions (Front x Depth)	56 cm x 47 cm
Cooktop Weight	12.3 kg
Range Hood Dimensions (Front x Depth x Height)	60 cm x 48 cm x 50 cm
Range Hood Weight	7.27 kg
Overall Product Dimensions	20 x 60 x 49 cm (packaged); 14 kg (total weight)
Cooktop Burners	4 (different thermal capacities)
Cooktop Ignition	Electronic ignition per burner
Cooktop Safety Feature	Safety valve on each burner
Range Hood Extraction Levels	3
Range Hood Extraction Capacity	627 m ³ /h

Feature	Specification
Range Hood Power	74 watts, 120 V~ 60 Hz
Material	Alloy Steel, Iron (Cooktop); Stainless Steel (Hood)
Special Features	Rust resistant, Removable filters (Hood)
Fuel Type	Gas (LP and Natural Gas convertible)

9. WARRANTY AND SUPPORT

Your SUPRA Elba Built-in Gas Cooktop and Range Hood Combo comes with a **12-month factory defect warranty** directly from SUPRA. This warranty covers manufacturing defects.

SUPRA maintains a specialized Warranty Department dedicated to providing support for service, maintenance, and spare parts for your SUPRA Elba cooktop and range hood. For any warranty claims, technical assistance, or to inquire about spare parts, please contact SUPRA customer service.

For more information and to explore other SUPRA products, visit the official SUPRA store on Amazon:[SUPRA Store](#)