

vidaXL 310543

vidaXL Double Chaise Lounge with Canopy

Instruction Manual - Model 310543

1. INTRODUCTION

Thank you for purchasing the vidaXL Double Chaise Lounge with Canopy. This manual provides essential information for the safe assembly, operation, and maintenance of your new outdoor furniture. Please read these instructions carefully before use and retain them for future reference.

2. SAFETY INFORMATION

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the chaise lounge on a soft, clean surface to prevent scratches.
- Tighten all screws and bolts securely. Periodically check and re-tighten fasteners to ensure stability.
- Do not exceed the maximum weight capacity (not specified, assume standard for two adults).
- Keep children and pets away from the assembly area.
- Avoid using abrasive cleaners or harsh chemicals on the frame or fabric.
- Position the chaise lounge on a flat, stable surface to prevent tipping.

3. PARTS LIST

Before beginning assembly, verify that all components are included in your package:

- Main frame sections (alloy steel)
- Textilene fabric seating and backrest sections
- Canopy frame and fabric
- Two small pillows

- Assembly hardware (screws, bolts, washers, nuts)
- Assembly tools (e.g., Allen key, wrench)

4. SETUP AND ASSEMBLY

Assembly is required for this product. Follow these general steps. Refer to the specific diagrams included in your product packaging for detailed instructions.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a protected surface.
2. **Assemble Main Frame:** Connect the various alloy steel frame sections using the provided hardware. Ensure all connections are firm but do not fully tighten bolts until the entire frame is assembled.
3. **Attach Seating Fabric:** Secure the Textilene fabric seating and backrest sections to the assembled frame. Ensure the fabric is taut and evenly distributed.
4. **Install Canopy:** Attach the canopy frame to the main structure, then secure the canopy fabric.
5. **Final Tightening:** Once all components are in place, progressively tighten all bolts and screws. Do not overtighten.
6. **Attach Pillows:** Place the two small pillows onto the backrest.



Figure 1: Assembled Double Chaise Lounge with Canopy, illustrating overall dimensions.



Figure 2: Detail of the chaise lounge leg and frame construction.

5. OPERATING INSTRUCTIONS

Using the Chaise Lounge

The vidaXL Double Chaise Lounge is designed for relaxation. Simply recline on the Textilene fabric surface. The integrated canopy provides shade from the sun.

Folding for Storage

This chaise lounge is designed to be foldable for easier storage. Consult your product's specific assembly diagrams for the exact folding mechanism. Typically, this involves releasing locking pins or mechanisms on the frame to allow it to collapse. Ensure the canopy is also folded or detached before collapsing the main frame.

6. MAINTENANCE

Cleaning

- **Frame:** Wipe the alloy steel frame with a damp cloth and mild soap. Rinse thoroughly and dry completely to prevent rust.

- **Textilene Fabric:** Clean the Textilene fabric with a soft brush or sponge, using mild soap and water. Rinse well and allow to air dry completely before storage. Do not use bleach or harsh detergents.
- **Canopy:** The canopy fabric can be spot cleaned with mild soap and water.

Storage

When not in use, especially during adverse weather conditions or off-season, it is recommended to store the chaise lounge in a dry, protected area. Utilize its foldable feature to minimize storage space. Covering the chaise lounge with a protective cover can also extend its lifespan.

7. TROUBLESHOOTING

- **Instability:** If the chaise lounge feels unstable, check that all bolts and screws are securely tightened. Ensure it is placed on a level surface.
- **Assembly Difficulties:** If you encounter issues during assembly, such as misaligned holes, refer to the detailed diagrams in your product packaging. Do not force parts together. Contact customer support if problems persist.
- **Fabric Wear/Damage:** Over time, Textilene fabric may show signs of wear. Regular cleaning and proper storage can help prolong its life. For significant damage, contact the manufacturer for replacement options.

8. SPECIFICATIONS

Brand	vidaXL
Model Number	310543
Color	Black
Material	Alloy Steel (frame), Textilene (fabric)
Dimensions (L x W x H)	190 x 137 x 158 cm (74.8 x 53.9 x 62.2 inches)
Item Weight	24.95 kg (55 lbs)
Special Features	Canopy, 2 Small Pillows, Foldable
Recommended Use	Relaxation, Outdoor/Indoor

9. WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about replacement parts, please contact vidaXL customer service directly or refer to the retailer's return policy. The retailer offers a 30-day refund/replacement policy from the date of purchase.

You can typically find contact information on the vidaXL official website or through your purchase documentation.

