

[Manuals.plus](#) /

› [Aivituvin](#) /

› Aivituvin Extra Large Chicken Coop Instruction Manual (Model B093VFPQZ5)

Aivituvin B093VFPQZ5

Aivituvin Extra Large Chicken Coop Instruction Manual

Model: B093VFPQZ5

1. PRODUCT OVERVIEW

This manual provides instructions for the Aivituvin Extra Large Chicken Coop, an outdoor wooden hen house designed for poultry. It features a spacious living area, multiple nesting boxes, perches, and a secure run.



Image: Fully assembled Aivituvin Extra Large Chicken Coop.

2. SETUP AND ASSEMBLY

The Aivituvin Extra Large Chicken Coop requires assembly. It is recommended to assemble the coop in its final desired location, as moving it after assembly may compromise the structural integrity of the run.

2.1 Pre-Assembly Checklist

- Verify all parts and hardware are present according to the packing list.
- Ensure you have a Phillips head screwdriver.
- Choose a level and secure location for the coop.

2.2 Assembly Tips

- Follow the provided step-by-step instructions carefully.
- Exercise caution during assembly, as the wood can be soft and may split if excessive force is applied.
- The coop features reinforced wooden corner strips for enhanced stability.
- The run panel extends under the nesting boxes to provide additional support and prevent sagging over time.



Image: Aivituvin chicken coop during or after assembly, showing its overall structure.

Your browser does not support the video tag.

Video: Official Aivituvn video demonstrating features and assembly aspects of the Extra Large Chicken Coop.


3. OPERATING INSTRUCTIONS

3.1 Capacity and Space

This chicken coop is designed to accommodate 10-15 chickens. However, actual capacity may vary based on the size and breed of your chickens. For larger breeds, a smaller flock size (e.g., 6-8 chickens) may be more appropriate to ensure adequate space and comfort.

3.2 Nesting Boxes and Perches

- The coop includes two large nesting boxes, each divided into three individual sections, providing a total of six nesting areas.
- Four perches are located inside the main house, and two additional perches are built into the run area, offering ample roosting space.
- A waterproof PVC curtain is installed above the nesting boxes to prevent leakage.



137" enlarge run provide 38.54ft² running space



Slide door for automatic door opener

Image: Interior view of the coop highlighting the six nesting box sections.



LARGE & COMFORTABLE SLEEPING AREA

Keep your pet safe and healthy

- 2 Ventilation windows. 4 Perches . 6 Nesting boxes




Image: Interior view of the sleeping area with perches and ventilation windows.

3.3 Access and Security

- The coop features nine access areas, including doors and hinged roofs, for convenient interaction with your flock and easy cleaning.
- Special custom locks are integrated to secure nesting boxes and prevent predator access.
- Galvanized wire walls and a series of locks on each access point ensure the safety of your poultry from predators.
- The chicken access door in the run is designed to support an automatic door opener (sold separately).
- A steel slide pole operates the sliding doors, allowing you to safely secure chickens within the coop.



EASY TO CLEAN

Reach every inch of this hutch with the help of a slide-out tray & multiple access points



9 ACCESS AREAS




Image: Exterior view highlighting the various access points of the chicken coop.

3.4 Ventilation

Three screened ventilation windows are located in the sleeping shelter to ensure proper airflow and a healthy environment for your chickens.

4. MAINTENANCE

4.1 Cleaning

- The coop is equipped with large, removable sliding trays for easy cleaning of droppings and bedding.
- Utilize the multiple access points to reach all areas of the coop for thorough cleaning and maintenance.

Your browser does not support the video tag.

Video: Official Aivituvin video demonstrating the removable sliding tray for easy cleaning.

5. TROUBLESHOOTING


- **Wood Splitting During Assembly:** Apply gentle and even pressure when driving screws. Pre-drilling small pilot holes can help prevent wood splitting, especially in softer wood sections.
- **Flimsy or Misaligned Tray:** Ensure the metal bottom interior tray is correctly seated within its

designated grooves. Adjust its position if it does not sit properly.

- **Gaps Allowing Cold Air:** In colder climates, inspect the coop for any gaps between panels. These can be sealed with weather stripping or non-toxic, pet-safe caulk to improve insulation.
- **Difficulty Moving Assembled Coop:** The coop, particularly the run, is designed for stationary use once assembled. Attempting to move it after assembly may cause structural damage. If relocation is necessary, partial disassembly may be required.
- **Coop Capacity Concerns:** While rated for 10-15 chickens, consider the actual size and breed of your birds. For larger breeds, a smaller flock will ensure adequate space. Observe your chickens for signs of overcrowding.

6. SPECIFICATIONS

Feature	Detail
Product Dimensions (L x W x H)	137" x 63" x 62"
Item Weight	225.5 Pounds
Material	Fir Wood
Color	Grey
Target Species	Chicken
Breed Recommendation	Large Breeds
Number of Levels	2
Number of Doors	3
Nesting Boxes	6 (2 boxes, 3 sections each)
Perches	6 (4 inside, 2 in run)
Special Feature	Lockable, Removable Tray



Large enclosure holds 8-10 chickens
(small-medium) for safe roaming



Specific warranty details for the Aivituvin Extra Large Chicken Coop are not provided in this manual. For information regarding product warranty, please contact the manufacturer directly or refer to the purchase documentation.

If you encounter any issues or have questions regarding the assembly, operation, or maintenance of your Aivituvn Extra Large Chicken Coop, please contact Aivituvn customer support or the seller from whom you purchased the product for assistance.

