

[Manuals.plus](#) /

› [Ambimall](#) /

› Ambimall 64-inch Floor Lamp (Model ABM-0430) Instruction Manual

Ambimall ABM-0430

Ambimall 64-inch Floor Lamp (Model ABM-0430) Instruction Manual

Brand: **Ambimall** | Model: **ABM-0430**

1. INTRODUCTION

Welcome to your new Ambimall 64-inch Floor Lamp. This manual provides essential information for safe assembly, operation, and maintenance of your floor lamp. Please read these instructions thoroughly before use and retain them for future reference.



Image: The Ambimall 64-inch Floor Lamp, featuring a beige cylindrical lampshade and a slender black pole, designed for minimalist spaces.

2. IMPORTANT SAFETY INSTRUCTIONS

- Ensure the lamp is unplugged before assembly, cleaning, or bulb replacement.
- Use only bulbs that comply with the specified wattage (maximum 60 Watts) and base type (E26 Medium).
- This lamp is designed for indoor use only. Do not expose to moisture or extreme temperatures.
- Place the lamp on a stable, level surface to prevent tipping.
- Keep the power cord away from heat sources, sharp edges, and moving parts.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Lamp Base (Iron)
- Lamp Pole Sections (multiple, to be screwed together)
- Lampshade (Linen, rolled)

- Lampshade Frame Rings
- 9W LED Bulb (E26 Medium base, 3 color temperatures)
- Pull Chain Switch



Image: Exploded view of the Ambimall floor lamp components, illustrating the base, segmented pole, rolled lampshade, and included LED bulb.

4. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your Ambimall floor lamp:

1. **Attach the Base:** Screw the first pole section into the lamp base firmly.
2. **Assemble the Pole:** Continue screwing the remaining pole sections together, ensuring each connection is secure.
3. **Prepare the Lampshade:** The lampshade comes rolled. Carefully unroll it and attach it to the provided wire frame rings. Secure the vertical seam with the integrated Velcro strip.
4. **Install the Lampshade:** Place the assembled lampshade onto the top of the lamp pole, securing it with the provided fasteners.
5. **Insert the Bulb:** Screw the included 9W LED bulb into the E26 Medium socket.

6. **Connect to Power:** Plug the lamp into a standard 120V electrical outlet.



Image: Visual guide for assembling the lamp, detailing the connection of the base, pole segments, and lampshade installation.

Assembly Video

Your browser does not support the video tag.

Video: A seller-provided video demonstrating the easy assembly process of the Ambimall floor lamp, including bulb installation.

5. OPERATING INSTRUCTIONS

Power On/Off

To turn the lamp on or off, gently pull the metal chain extending from the lamp socket.

Provides a minimalist and modern look in tight or small spaces



Image: Detail of the pull chain mechanism used to control the lamp's power.

Adjusting Color Temperature

The included 9W LED bulb features three adjustable color temperature settings: 3000K (Warm White), 4000K (Natural White), and 5000K (Daylight White). To cycle through these settings, pull the chain repeatedly. Each pull will switch to the next color temperature.

3 color temperatures bulb included



3000K
Warm White

4000K
Natural White

5000K
Daylight White

Image: Comparison of the lamp's output at 3000K (Warm White), 4000K (Natural White), and 5000K (Daylight White) color temperatures.

6. CARE AND MAINTENANCE

- **Cleaning:** Dust the lamp regularly with a soft, dry cloth. For the lampshade, a lint roller or a slightly damp cloth can be used for minor spots. Ensure the lamp is unplugged before cleaning.
- **Bulb Replacement:** When replacing the bulb, ensure the lamp is unplugged and the bulb has cooled. Use an E26 Medium base LED bulb, not exceeding 60 Watts.
- **Storage:** If storing the lamp, disassemble it and pack it in its original packaging to protect components.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	No power to the outlet. Bulb is loose or faulty.	Check if the outlet is working. Ensure the bulb is screwed in tightly. Replace the bulb if necessary.

Problem	Possible Cause	Solution
Light flickers.	Loose bulb connection. Incompatible bulb.	Tighten the bulb. Ensure the bulb meets specifications.
Lampshade is uneven.	Lampshade not properly secured to frame.	Adjust the lampshade on the frame rings and ensure Velcro is aligned.

8. SPECIFICATIONS

Feature	Detail
Model Number	ABM-0430
Product Dimensions	7.87"D x 5.12"W x 64.56"H
Item Weight	5 Pounds
Material	Iron (Base), Linen (Shade)
Finish Type	Matte
Shade Color	Beige
Light Source Type	LED
Bulb Base	E26 Medium
Wattage (Included Bulb)	9 Watts
Maximum Compatible Wattage	60 Watts
Color Temperature (Included Bulb)	3000K/5000K/4000K Adjustable
Light Output Maximum	900 Lumens
Switch Type	Pull Chain
Power Source	Corded Electric
Indoor/Outdoor Usage	Indoor
Assembly Required	Yes

9. WARRANTY AND SUPPORT

Warranty Information

For specific warranty details, please refer to the documentation provided with your purchase or contact Ambimall customer support. Extended protection plans may be available for purchase.

Customer Support

If you have any questions, require assistance, or need to report an issue, please visit the official [Ambimall Store on Amazon](#) or contact their customer service directly.

