

[Manuals.plus](#) /

› [Inateck](#) /

› Inateck Surface Pro Keyboard User Manual

Inateck KB02026-G-US

Inateck Surface Pro Keyboard User Manual

Model: KB02026-G-US

1. INTRODUCTION

Thank you for choosing the Inateck Surface Pro Keyboard. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your new keyboard. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.

This keyboard is specifically designed for Microsoft Surface Pro models, offering a laptop-like typing experience with advanced features.




Figure 1: Inateck Surface Pro Keyboard (KB02026-G-US)

2. COMPATIBILITY

The Inateck KB02026-G-US keyboard is compatible with the following Microsoft Surface Pro models:

- Surface Pro 7
- Surface Pro 7+
- Surface Pro 6
- Surface Pro 5
- Surface Pro 4

Important Note: This keyboard is **not** compatible with Surface Pro X and Surface Go models.

Compatible Devices



- ✓ Surface Pro 7+ 2021
- ✓ Surface Pro 7 2019
- ✓ Surface Pro 6 2018
- ✓ Surface Pro 5 2017
- ✓ Surface Pro 4 2015



- ✗ Surface Pro 8
- ✗ Surface Pro X
- ✗ Surface Go

Figure 2: Compatible Devices for Inateck KB02026-G-US Keyboard

3. SETUP GUIDE

3.1. Package Contents

Ensure all items are present in the package:

- Inateck Surface Pro Keyboard Cover (KB02026-G-US)

- USB-C Charging Cable
- User Manual (this document)

3.2. Charging the Keyboard

The keyboard features a built-in 750mAh rechargeable lithium battery. Before first use, or when the battery is low, charge the keyboard using a USB-C cable.

- Connect the USB-C end of the charging cable to the keyboard's charging port.
- Connect the other end of the cable to a USB power source (e.g., computer USB port, USB wall adapter).
- The charging indicator light will illuminate. Once fully charged, the light will change or turn off (refer to LED indicator section for specifics).

A full charge provides an ultra-long standby time of up to 180 days.

3.3. Attaching to Surface Pro

The keyboard attaches magnetically to your Surface Pro device, similar to the original Microsoft keyboard. It offers two different typing angles for enhanced comfort.

1. Align the magnetic connector of the keyboard with the corresponding port on the bottom edge of your Surface Pro.
2. The keyboard will snap into place magnetically.
3. For a flat typing angle, simply leave the keyboard flat.
4. For an elevated typing angle, fold the magnetic strip at the top of the keyboard (near the Surface Pro screen) upwards to create a slight incline.

Two Different Typing Angles

Bringing you more comfortable typing experience




Figure 3: Two Different Typing Angles

3.4. Bluetooth Pairing

The Inateck keyboard connects to your Surface Pro via Bluetooth 5.0.

1. Ensure the keyboard is charged and powered on.
2. On your Surface Pro, go to **Settings > Devices > Bluetooth & other devices**.
3. Turn on Bluetooth.

4. Select **Add Bluetooth or other device**.
5. Choose **Bluetooth**.
6. The Surface Pro will search for nearby Bluetooth devices. Select "Inateck KB02026" (or similar name) from the list.
7. Follow any on-screen prompts to complete the pairing process.
8. Once paired, the keyboard will automatically reconnect when in range and powered on.

4. OPERATING INSTRUCTIONS

4.1. Keyboard Layout and Special Keys

The keyboard features a standard QWERTY layout with additional function keys and independent shortcut keys for convenience.

- **Function Keys (F1-F12):** Perform standard functions.
- **Independent Shortcut Keys:** The front row of keys provides direct access to common functions without needing to press the Fn key. These include media controls (play/pause, volume), screen brightness, and a dedicated screenshot key.

One-Key Solution for more Demands

*Ultra-convenient
Independent Shortcut Keys*




Figure 4: Independent Shortcut Keys

4.2. Backlight Control

The keyboard features 7-color backlighting to suit various lighting conditions and personal preferences.

- Press the **Backlight Key** (often indicated by a light bulb icon) to cycle through different backlight colors.
- Press the **Brightness Keys** (often indicated by sun icons) to adjust the backlight brightness levels or turn the backlight off.




Figure 5: Keyboard with 7-Color Backlights


4.3. Touchpad Usage

The integrated touchpad is larger than many similar keyboards and includes a false touch proof function to prevent accidental inputs.

- **Basic Navigation:** Use one finger to move the cursor.
- **Click:** Press down on the touchpad or tap with one finger.

- **Right-Click:** Tap with two fingers or press the bottom-right corner of the touchpad.
- **Scrolling:** Use two fingers to scroll up or down.
- **Zoom:** Pinch in or out with two fingers.
- **Gesture Control:** The touchpad supports various multi-finger gestures for enhanced navigation and control within Windows 10.

Larger Touchpad



Prevent Mis-touch



Gesture Control



Figure 6: Touchpad Features (Larger Touchpad, Prevent Mis-touch, Gesture Control)

4.4. Smart Screen-off Feature

The keyboard is designed with a smart screen-off feature to conserve power and enhance user experience.

- When the keyboard is closed over the Surface Pro screen, the screen will automatically turn off.
- When the keyboard is opened, the Surface Pro screen will wake up.



Figure 7: Smart Screen-off Functionality

5. MAINTENANCE

To ensure the longevity and optimal performance of your Inateck keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a dry, knitted fabric to gently wipe the keyboard surface. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To preserve battery life, avoid fully discharging the battery frequently. Charge the keyboard regularly, especially if it will be stored for an extended period.
- **Handling:** Avoid dropping the keyboard or subjecting it to strong impacts. Do not attempt to disassemble the keyboard.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Keyboard does not connect via Bluetooth.	Keyboard battery is low or dead. Bluetooth is off on Surface Pro. Keyboard is not in pairing mode. Interference from other devices.	Charge the keyboard fully. Ensure Bluetooth is enabled on your Surface Pro. Refer to Section 3.4 for Bluetooth pairing instructions. Move closer to the Surface Pro and away from other wireless devices.
Keys are not responding or typing incorrectly.	Loose Bluetooth connection. Low battery. Software glitch.	Reconnect Bluetooth. Charge the keyboard. Restart your Surface Pro.
Touchpad is unresponsive or erratic.	False touch detection. Low battery. Software issue.	Ensure only intended fingers are on the touchpad. Charge the keyboard. Restart your Surface Pro.
Backlight is not working.	Backlight turned off or set to lowest brightness. Low battery.	Press the Backlight Key or Brightness Keys to adjust. Charge the keyboard.

7. SPECIFICATIONS

Feature	Detail
Brand	Inateck
Model Number	KB02026-G-US
Connectivity Technology	Bluetooth 5.0
Compatible Devices	Microsoft Surface Pro 4, 5, 6, 7, 7+
Operating System	Windows 10
Battery Capacity	750mAh Lithium Ion (built-in)
Standby Time	Up to 180 days

Feature	Detail
Backlight	7-color RGB backlighting
Number of Keys	78
Touchpad Dimensions	105mm x 57mm (larger than typical)
Item Weight	1.19 pounds (approx. 0.54 kg)
Product Dimensions (LxWxH)	11.61 x 8.46 x 0.35 inches (approx. 29.5 x 21.5 x 0.9 cm)
Color	Gray

8. PRODUCT VIDEO DEMONSTRATION

Watch the official product video for a visual guide on the Inateck Surface Pro Keyboard's features and usage.

Your browser does not support the video tag.

Video 1: Inateck Keyboard Cover for Surface Pro 7/7+/6/5/4/3. This video demonstrates the keyboard's design, compatibility, larger touchpad, mis-touch prevention, gesture control, 7-color backlighting, and independent shortcut keys.

9. WARRANTY INFORMATION

Inateck products come with a standard manufacturer's warranty. For detailed warranty terms and conditions, please refer to the warranty card included in your product packaging or visit the official Inateck website.

Please retain your proof of purchase for warranty claims.

10. CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your Inateck Surface Pro Keyboard, please contact Inateck Customer Support through the following channels:

- **Website:** Visit the official Inateck website for FAQs, drivers, and support resources.
- **Email:** Refer to your product packaging or the Inateck website for the customer service email address.
- **Online Store:** You can also visit the [Inateck Store on Amazon](#) for product information and support.

When contacting support, please have your product model number (KB02026-G-US) and purchase information ready.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question