

SHAKS S5b

SHAKS S5b Wireless Gamepad Controller Instruction Manual

Model: S5b | Brand: SHAKS

1. PRODUCT OVERVIEW

The SHAKS S5b is a versatile wireless gamepad controller designed for a wide range of gaming platforms. It offers ultra-low latency connectivity, dual haptic vibration, and extensive compatibility, enhancing your mobile and PC gaming experience.



Image: The SHAKS S5b gamepad with a smartphone securely mounted, ready for gaming.

2. PACKAGE CONTENTS

- SHAKS S5b Wireless Gamepad Controller
- USB Charging Cable
- Portable Carry Pouch
- Circle-type D-pad (replaceable)
- Instruction Manual (this document)



Image: The SHAKS S5b gamepad box, indicating typical packaging.

3. PRODUCT DIAGRAM



Image: Top view of the SHAKS S5b gamepad, highlighting the left and right control sections with joysticks, D-pad, and action buttons.



Image: Side view of the SHAKS S5b gamepad, illustrating the placement of the L1/R1 bumpers and L2/R2 triggers.



Image: The SHAKS S5b gamepad with red circles indicating the location of the dual haptic vibration motors within the grips.

4. SETUP AND CONNECTION

4.1. Power On/Off

To power on the gamepad, slide the mode select switch to your desired operating system (Android, Windows, iOS). To power off, slide the switch to the 'Off' position.

4.2. Bluetooth Pairing

1. Ensure the gamepad is powered off.
2. Select the correct operating system mode using the slide switch on the left side of the gamepad.
3. Press the Bluetooth (BT) key on the gamepad to initiate pairing mode. The LED indicators will flash.
4. On your device (phone, tablet, PC), go to Bluetooth settings and search for "SHAKS S5b" (or similar ID).
5. Select the gamepad to pair. Once successfully paired, the gamepad will vibrate, and the corresponding LED will remain solid.

Note: If switching between different devices or operating systems, you may need to delete previous pairings from your device's Bluetooth settings and re-pair.

Your browser does not support the video tag.

Video: A tutorial demonstrating the Bluetooth pairing process for SHAKS S2i, S3i, and S5b gamepads across different devices.

4.3. Wired Connection

For wired connection, power off the S5b. While pressing the Bluetooth key, connect the USB cable for power booting. iOS is not supported via wired connection.

5. OPERATING MODES AND COMPATIBILITY

The SHAKS S5b supports various operating systems and platforms:

- **Android:** Compatible with Android phones, Firestick, Fire TV, Chromecast, and Android TV Box.
- **Windows:** Compatible with Windows PC, Notebook, and Chromebook. No additional drivers are needed for Windows 10.
- **Mac OS:** Compatible with Mac PC (Catalina, Big Sur).
- **iOS:** Compatible with iPhone, iPad, and Apple TV.

The S5b is also compatible with advanced streaming platforms such as Stadia, X-Cloud, Geforce Now, Magenta Gaming, and GameBox.



Image: A circular diagram illustrating the SHAKS S5b's compatibility with Android, iOS, Windows, and Mac OS devices, including phones, tablets, laptops, and TVs.

6. SHAKS GAMEHUB APPLICATION

The SHAKS GameHub app (Android only) enhances your gaming experience with advanced customization and mapping features.

6.1. Download and Installation

Download the "SHAKS GameHub" application from the Google Play Store. Ensure you allow necessary permissions for the app to function correctly, especially "Draw over other apps" for mapping features.



Image: A screenshot showing the SHAKS GameHub application available for download on the Google Play Store.

6.2. Key Mapping and Customization (Android Only)

The GameHub app allows you to map touchscreen controls to gamepad buttons for games that do not natively support controllers. You can adjust speed, sensitivity, and calibration. Advanced features include:

- **Sniper Mode:** Adjust stick sensitivity for precise aiming.
- **Turbo Function:** Enable rapid-fire for specific buttons.
- **Mouse Function:** Use the joystick to navigate the screen like a mouse.
- **Self Key Testing:** Test each button and key for functionality.

Your browser does not support the video tag.

Video: A demonstration of how to use the SHAKS S5b for playing touch-only games through mapping, showcasing the in-app customization options.

Your browser does not support the video tag.

Video: A detailed guide on setting up the SHAKS S5b and using the SHAKS GameHub companion app for advanced features and mapping.

6.3. Firmware Update

The GameHub app allows for firmware updates (FoTA FW Upgrade) to ensure your gamepad always has the latest features and improvements.

6.4. Sleep Time and LED Brightness

Customize the gamepad's sleep timer and adjust LED brightness through the GameHub app settings.

7. TROUBLESHOOTING

7.1. Connection Issues

If you experience connection problems:

1. Press and hold the Bluetooth (BT) key on the gamepad for 6 seconds to delete the stored profile.
 2. On your device's Bluetooth settings, delete any previously paired SHAKS S5b profiles.
 3. Wait 3 minutes for the device's memory to refresh.
 4. Re-pair the gamepad following the Bluetooth Pairing instructions (Section 4.2).
-

8. SPECIFICATIONS

Model Number	S5b
Product Dimensions	5.31 x 3.54 x 1.38 inches
Item Weight	10.6 ounces
Batteries	1 Lithium Ion battery (included)
Battery Life	Up to 8 hours of uninterrupted gameplay on a 1-hour charge
Manufacturer	AKSys Co., Ltd.
Connectivity	Bluetooth, Wired (USB)
Latency	14ms range (powered by Qualcomm Technologies)

9. SAFETY INFORMATION

- Do not expose the device to extreme temperatures or humidity.
- Avoid dropping or subjecting the device to strong impacts.
- Keep out of reach of children.
- Do not attempt to disassemble or modify the device.
- Use only the provided charging cable or a certified equivalent.

10. WARRANTY AND SUPPORT

For warranty information, technical support, or any questions regarding your SHAKS S5b controller, please refer to the official SHAKS website or contact customer support through the Amazon Q&A section.

Your browser does not support the video tag.

Video: An introductory video demonstrating the features, connection methods, and application of the SHAKS S5b gamepad.