Ontel ONTEL - 735541104206

Ontel Beyond Bright Ultra LED Ultra-Bright Motion Activated Garage Light User Manual

Model: ONTEL - 735541104206
Brand: Ontel

Setup Operating Maintenance Troubleshooting Specifications Warranty Support

Introduction

This manual provides comprehensive instructions for the installation, operation, maintenance, and troubleshooting of your Ontel Beyond Bright Ultra LED Ultra-Bright Motion Activated Garage Light. Please read this manual thoroughly before use to ensure proper function and safety.



Figure 1: The Ontel Beyond Bright Ultra LED Garage Light, showcasing its three adjustable LED panels and integrated motion sensor.

Setup and Installation

The Beyond Bright Ultra LED Garage Light is designed for quick and easy installation into any standard light socket. No special tools or wiring are required.

1. **Power Off:** Before beginning installation, ensure the power to the light fixture is turned off at the circuit breaker to prevent electrical shock.
2. **Remove Old Bulb:** Carefully unscrew and remove the existing light bulb from the fixture.
3. **Install Beyond Bright:** Screw the Beyond Bright Ultra LED Garage Light into the standard light socket until it is securely fastened.
4. **Adjust Panels:** Once installed, adjust the three individual LED panels to direct light precisely where needed. The panels are designed to be customizable for optimal illumination.
5. **Restore Power:** Turn the power back on at the circuit breaker. The light should illuminate, and the motion sensor will become active.



Figure 2: Illustrates the simple screw-in installation and the adjustability of the LED panels.

This light is ideal for garages, basements, closets, attics, sheds, workshops, and hallways, providing ultra-bright, motion-activated illumination.

Operating Instructions

The Ontel Beyond Bright Ultra LED Garage Light features motion activation for convenience and energy efficiency. It provides 6,000 lumens of pure white light.

Motion Sensor Functionality

The integrated motion sensor automatically turns the light on when movement is detected within its range. The light will remain on as long as motion is present and will turn off after a period of inactivity. This feature helps conserve energy.



Figure 3: The light automatically activates upon detecting motion, providing illumination for tasks.

Switch Settings

The device may include a push-button switch with settings such as "Motion," "Off," and "On." Refer to the specific markings on your unit for exact functionality:

- **Motion:** Activates the motion sensor, turning the light on only when movement is detected.
- **Off:** Keeps the light turned off, regardless of motion.

- **On:** Keeps the light continuously on, bypassing the motion sensor.



Figure 4: Demonstrates the significant increase in brightness and coverage provided by the Beyond Bright light compared to standard lighting.

Maintenance

The Ontel Beyond Bright Ultra LED Garage Light is designed for long-lasting performance with minimal maintenance. The advanced LED technology is rated to last up to 30 years under normal usage conditions.

- **Cleaning:** To clean the light, ensure the power is off at the circuit breaker. Use a soft, dry cloth to wipe down the surfaces. Do not use abrasive cleaners or solvents, as these may damage the finish or electronic components.
- **Inspection:** Periodically inspect the light for any signs of damage, such as loose panels or cracks in the housing. If any damage is observed, discontinue use and contact customer support.

Troubleshooting

If you encounter issues with your Beyond Bright Ultra LED Garage Light, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	• No power to the fixture. • Light not screwed in properly. • Switch set to "Off" or "Motion" with no motion detected. • Defective unit.	• Check circuit breaker and wall switch. • Ensure the light is fully and securely screwed into the socket. • Adjust the switch to "On" or ensure motion is present if set to "Motion." • If issues persist, contact customer support.
Motion sensor not working or light stays on/off.	• Switch set to "On" or "Off" instead of "Motion." • Obstruction blocking the sensor. • Sensor malfunction.	• Verify the switch is set to "Motion." • Ensure the sensor is clear of any obstructions. • If the sensor continues to malfunction, contact customer support.
Light flickers or dims.	• Loose connection in the socket. • Voltage fluctuations. • Unit overheating (less common for LED).	• Ensure the light is tightly screwed into the socket. • Consult an electrician if voltage issues are suspected. • Ensure adequate ventilation around the light.
Physical damage (e.g., broken housing).	• Manufacturing defect or mishandling.	• Discontinue use. Contact customer support for warranty or replacement options.

Product Specifications

Feature	Detail
Model Number	ONTEL - 735541104206
Brand	Ontel
Color	White
Material	Metal, Plastic
Dimensions (L x W x H)	5.24 x 7.64 x 9.76 inches
Item Weight	16 ounces (1 pound)
Power Source	Corded Electric
Wattage	40 watts
Bulb Type	LED
Luminous Flux	6000 Lumen
Special Features	Motion Sensor, Adjustable Panels

Feature	Detail
Installation Method	Flush Mount (Screw-in)
UPC	735541104206

Warranty Information

The product comes with a manufacturer's warranty. For detailed information regarding the terms, conditions, and duration of the warranty, please refer to the documentation included with your purchase or visit the official Ontel website. Keep your proof of purchase for warranty claims.
Optional protection plans may also be available for purchase through retailers. These plans are separate from the manufacturer's warranty.

Customer Support and Resources

For further assistance, technical support, or to inquire about replacement parts, please contact Ontel customer service.

- **Official Brand Store:** Visit the Ontel Store on Amazon for product information and other offerings.
- **User Manual (PDF):** A downloadable PDF version of the user manual is availablehere.

© 2024 Ontel. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question