



Manuals.plus /

- › Spyra /
- › Spyra Two Electronic Water Gun Super Blaster User Manual

Spyra Spyratwo

Spyra Two Electronic Water Gun Super Blaster User Manual

Model: Spyratwo | Brand: Spyra

INTRODUCTION

Welcome to the user manual for your Spyra Two Electronic Water Gun Super Blaster. This manual provides essential information on setting up, operating, maintaining, and troubleshooting your device to ensure optimal performance and enjoyment. Please read this manual thoroughly before first use.



Image: The Spyra Two Electronic Water Gun, showcasing its sleek design and red color. This is the primary view of the product.

SETUP

Before using your Spyra Two, ensure it is properly prepared for operation.

1. **Initial Charge:** The Spyra Two features an integrated battery. For first use, it is recommended to fully charge the device. Connect the provided charging cable to the charging port on the water gun and to a suitable power source. The battery lasts for approximately 90 water recharge cycles, totaling around 2000 water blasts.
2. **First Fill:** To fill the water gun, simply dip the front nozzle into a clean water source. The device will automatically refill within approximately 12 seconds. Ensure the nozzle is fully submerged for efficient refilling.

THE FEATURES



SINGLE BLAST
TECHNOLOGY



AUTOMATIC REFILL



TACTICAL DISPLAY



POWER SHOT

[learn more](#)

Image: A detailed view of the Spyra Two's front section, highlighting the automatic refill mechanism. This shows where the water gun is submerged for refilling.

OPERATING INSTRUCTIONS

Learn how to effectively use your Spyra Two for maximum performance.

- **Standard Blasts:** To fire a single water blast, simply pull and release the trigger. The Spyra Two delivers 22 semi-automatic water blasts per charge, with an effective range of up to 9 meters (30 feet).
- **Power Shot:** For an extended range and more powerful blast, hold the trigger down for three seconds, then release. This activates the Power Shot, increasing the range to up to 14 meters (46 feet).
- **Refilling During Play:** When the water level is low, submerge the front of the water gun into a water source. The automatic refill system will quickly replenish the water tank in about 12 seconds.



Image: A user demonstrating the aiming posture with the Spyra Two water gun, illustrating how it is held during operation.



Image: Two individuals using Spyra Two water guns in an active scenario, one taking cover behind a tree, demonstrating the product in use during a water battle.

MAINTENANCE

Proper maintenance ensures the longevity and performance of your Spyra Two.

- **Cleaning:** After each use, especially if using water from natural sources, rinse the water gun with clean tap water to prevent mineral buildup or debris accumulation. Do not submerge the entire unit in water for cleaning.
- **Draining:** Before storing, ensure all water is drained from the reservoir. Fire the water gun until no more water comes out, then allow it to air dry.

- **Storage:** Store the Spyra Two in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For long-term storage, it is recommended to charge the battery to about 50% every few months to maintain battery health.

TROUBLESHOOTING

If you encounter issues with your Spyra Two, refer to the following common solutions.

- **Gun Not Firing:**
 - Check if the water tank is empty. Refill the water gun.
 - Ensure the battery is charged. Recharge the device if necessary.
- **Weak Blasts or Short Range:**
 - Verify the water tank is full.
 - Ensure the nozzle is clear of any obstructions.
 - Confirm the battery is sufficiently charged.
- **Refill Issues:**
 - Ensure the nozzle is fully submerged in water during refilling.
 - Check for any blockages in the refill intake.

If problems persist, please contact Spyra customer support.

SPECIFICATIONS

Feature	Detail
Model Number	Spyratwo
Brand	Spyra
Color	Red
Batteries Required	Yes (Integrated)
Manufacturer Recommended Age	14 months and up
Effective Range	9 meters (30 feet)
Power Shot Range	14 meters (46 feet)
Blasts Per Charge	22 semi-automatic blasts
Battery Life	Approx. 90 water recharge cycles (2000 blasts total)
Refill Time	Approx. 12 seconds
ASIN	B093ZNJ9PB

WARRANTY INFORMATION

Specific warranty details for the Spyra Two Electronic Water Gun are not provided in this manual. For

comprehensive warranty information, including terms, conditions, and registration, please refer to the official Spyra website or contact their customer service directly.

CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your Spyra Two, please visit the official Spyra website or contact their customer support team. Contact details and support resources are typically available on the manufacturer's official web presence.