



Manuals.plus /

- › Ant Esports /
- › Ant Esports MK1200 Mini Wired Mechanical Gaming Keyboard User Manual

Ant Esports MK1200 MINI

Ant Esports MK1200 Mini Wired Mechanical Gaming Keyboard User Manual

Model: MK1200 MINI

PRODUCT OVERVIEW

The Ant Esports MK1200 Mini is a compact 60% wired mechanical gaming keyboard designed for optimal performance and portability. It features RGB backlit lighting and Red mechanical switches, providing a responsive and tactile typing experience.



Image: Front view of the Ant Esports MK1200 Mini mechanical gaming keyboard with RGB backlighting active.

PACKAGE CONTENTS

Ensure all items are present in the package:

- Ant Esports MK1200 Mini Wired Mechanical Gaming Keyboard
- USB to Type-C Braided Cable (1.5m)
- User Manual



Image: The retail packaging of the Ant Esports MK1200 Mini keyboard, showing the product and branding.

SETUP INSTRUCTIONS

1. **Connect the Keyboard:** Insert the Type-C end of the provided braided cable into the Type-C port on the keyboard. Connect the USB-A end of the cable to an available USB port on your computer.
2. **Driver Installation:** The keyboard is plug-and-play. Your operating system (Windows, macOS, Linux) will automatically detect and install the necessary drivers. No additional software installation is required for basic functionality.
3. **Positioning:** Adjust the two-step height adjustment feet on the underside of the keyboard to your preferred typing angle.

COMPATIBILITY

IBM PC, Mac, Win XP/ 7/ 8/ 10, Linux.



1 YEAR WARRANTY



Image: A user's hands positioned on the Ant Esports MK1200 Mini keyboard, demonstrating its compact size during use.



60% FORM FACTOR KEYBOARD

1.5M Cable

Image: The Ant Esports MK1200 Mini keyboard integrated into a gaming desk setup, connected to a computer.

OPERATING INSTRUCTIONS

Basic Keyboard Functions

The Ant Esports MK1200 Mini features a 60% compact layout. Many functions are accessed via the **Fn** (Function) key in combination with other keys.

Function Key Combinations

| Combination | Function |
|------------------|---|
| Fn + Esc | ~ (Tilde) |
| Fn + 1-0 | F1-F10 |
| Fn + -_ | F11 |
| Fn + =+ | F12 |
| Fn + P | PrtSc (Print Screen) |
| Fn + [{ | Home |
| Fn +]} | End |
| Fn + ;: | PgUp (Page Up) |
| Fn + "" | PgDn (Page Down) |
| Fn + K | Ins (Insert) |
| Fn + L | Del (Delete) |
| Fn + M | Scroll Lock |
| Fn + <, | Pause |
| Fn + Right Shift | Arrow Keys Toggle (Right Shift becomes Up Arrow, Fn becomes Left Arrow, Ctrl becomes Down Arrow, Alt becomes Right Arrow) |
| Fn + W | Swap WASD and Arrow Keys |

Backlight Control

The keyboard features 17 backlit modes and 4 brightness levels.

- **Fn + \|**: Change Backlight Mode (17 modes available).
- **Fn + Enter**: Change Backlight Color.
- **Fn + Up Arrow**: Increase Backlight Brightness (4 levels).
- **Fn + Down Arrow**: Decrease Backlight Brightness (can turn off).
- **Fn + Left Arrow**: Decrease Backlight Speed.
- **Fn + Right Arrow**: Increase Backlight Speed.

BACKLIT GAMING KEYBOARD





Image: Close-up view of the Ant Esports MK1200 Mini keyboard highlighting the Red mechanical switches and RGB backlighting.

MAINTENANCE AND CARE

- **Cleaning:** Use a soft, dry cloth to wipe the keyboard surface. For deeper cleaning, use a can of compressed air to remove dust and debris from between the keycaps. Do not use liquid cleaners directly on the keyboard.
- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping the keyboard or placing heavy objects on it, as this can cause damage to the internal components or keycaps.
- **Spills:** In case of liquid spills, immediately disconnect the keyboard from your computer and allow it to dry completely before reconnecting.

TROUBLESHOOTING

- **Keyboard Not Responding:**

- Ensure the USB cable is securely connected to both the keyboard and the computer.
- Try connecting the keyboard to a different USB port on your computer.
- Test the keyboard on another computer to rule out a computer-specific issue.

- **Keys Not Registering or Double Pressing:**

- Clean the affected keycap and switch area using compressed air to remove any debris.
- Ensure the keycap is properly seated on the switch stem.

- **Backlight Not Working or Flickering:**

- Check backlight brightness settings using Fn + Up/Down Arrow.
- Try cycling through backlight modes using Fn + \|.
- Reconnect the keyboard to reset the lighting.

- **Arrow Keys or Function Keys Not Working as Expected:**

- Remember that many functions require the Fn key. Refer to the "Operating Instructions" section for specific key combinations.
- If WASD keys are acting as arrow keys, press Fn + W to toggle back to standard WASD functionality.

SPECIFICATIONS

| Feature | Detail |
|--------------------------------|---|
| Keyboard Type | Wired Mechanical Gaming Keyboard |
| Model | MK1200 MINI |
| Form Factor | 60% Compact |
| Switch Type | Red Mechanical Switches |
| Keystroke Lifespan | 50 Million Keystrokes |
| Backlight | RGB Backlit (17 modes, 4 brightness levels) |
| Anti-Ghosting | Full Anti-Ghosting |
| Connectivity | Wired (USB to Type-C) |
| Cable Length | 1.5 meters |
| Dimensions (LxWxH) | 29.3 x 10.3 x 3.7 cm |
| Weight | 390 g |
| Operating System Compatibility | Windows 10, Windows 8, Windows 7, Windows XP, Limited Mac OS, Linux |


WARRANTY AND SUPPORT

The Ant Esports MK1200 Mini Wired Mechanical Gaming Keyboard comes with a **1-year warranty** from the date of purchase.

For technical support, warranty claims, or further assistance, please contact Ant Esports customer service:

- **Website:** www.antesports.com
- **Online Support:** <https://bit.ly/3S6sIUw> (as indicated in the user manual image)


Please retain your purchase receipt for warranty validation.



WARRANTY
Ant Esports MK1200 Mini Wired Mechanical Backlit Gaming Keyboard comes with 1 year warranty.

Warranty Card


Customer Name : _____
Product Name : _____ Model No. : _____
Address : _____ Date of Purchase : _____
Dealer Name : _____ Phone No. : _____




CONNECT WITH US ON

ANT ESPORTS
www.antesports.com
support@antesports.com

*Notice: Any alteration of the clauses and contents and copies are invalid.



USER MANUAL & WARRANTY CARD



FC CE

TECHNICAL SPECIFICATIONS

| | |
|-----------------|------------------------------------|
| Keyboard Type | : 60% Form Factor |
| Connectivity | : Type-C to USB |
| Color | : Black |
| Layout | : 63 English (Mini) |
| Switch | : Red Switches |
| Keys Type | : 22 Anti Ghosting Mechanical Keys |
| Cable Type | : PVC Cable |
| Cable Length | : 1.5m |
| Working Voltage | : 5V |
| Working Current | : <150mA |
| Lifespan | : 50 Million Clicks |
| Weight | : 556g |
| Dimensions | : 292 x 104 x 36mm |

BASIC KEYBOARD FUNCTIONS

COMBINATION KEY : FUNCTIONS

| | |
|----------------|--|
| FN + ↑ | : Increase the light Brightness |
| FN + ↓ | : Decrease the light Brightness |
| FN + ← | : Decrease the light speed |
| FN + → | : Increase the light speed |
| FN + | : Light Modes Switch |
| FN + Win | : Windows Lock |
| FN + Space Bar | : Return backlight to the default Status |
| FN + Y | : Print Scr |
| FN + U | : Scroll Lock |
| FN + I | : Pause |
| FN + H | : Insert |
| FN + J | : Home |
| FN + K | : Page Up |
| FN + N | : DEL |
| FN + M | : END |
| FN + . | : Page Down |
| FN + Backspace | : DEL |
| FN + Ctrl | : ESC - + = Shift to ~F12 Y U I H J K N M Shift to Print Scr, Scroll Lock, Pause, Insert, Home, Page Up, DEL, END, Page Down |
| FN + W | : Shift between WQSD and T Y U I H J K N M |


BASIC KEYBOARD FUNCTIONS

COMBINATION KEY : FUNCTIONS

| | |
|----------------------|-------|
| FN + Esc | : - |
| FN + Right Shift+ESC | : - |
| FN + 1 | : F1 |
| FN + 2 | : F2 |
| FN + 3 | : F3 |
| FN + 4 | : F4 |
| FN + 5 | : F5 |
| FN + 6 | : F6 |
| FN + 7 | : F7 |
| FN + 8 | : F8 |
| FN + 9 | : F9 |
| FN + 0 | : F10 |
| FN + _ | : F11 |
| FN + = | : F12 |

HOW TO USE

Type-C Plug into keyboard, USB plug into PC, it can be used!



SAFETY INSTRUCTIONS

1. Keep the keyboard away from sharp object that could damage it.
2. Do not put heavy objects on the keyboard.
3. Do not put stretch, twist or apply force to the keyboard.
4. To clean the keyboard, gently wipe it using a moist cotton cloth.
5. Make sure the keyboard is turned off before cleaning. Do not use liquid cleanser.

IN THE BOX

Keyboard, Type-C to USB Cable, User Manual

Image: A page from the Ant Esports MK1200 Mini user manual, detailing technical specifications, basic functions, and warranty information.

