

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [HP](#) /

› [HP EliteDesk 705 G4 MT Desktop Instruction Manual](#)

## HP EliteDesk 705 G4 MT

# HP EliteDesk 705 G4 MT Desktop Instruction Manual

Model: EliteDesk 705 G4 MT

## INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your HP EliteDesk 705 G4 MT desktop computer. Please read these instructions carefully before using your device.

## SETUP GUIDE

### 1. Unpacking and Placement

Carefully remove the desktop from its packaging. Place the computer on a stable, flat surface with adequate ventilation. Ensure no vents are obstructed.

### 2. Connecting Peripherals

- **Monitor:** Connect your monitor to one of the DisplayPort (DP) outputs on the rear of the desktop.
- **Keyboard and Mouse:** Connect your USB keyboard and mouse to any available USB ports.
- **Network:** For wired internet access, connect an Ethernet cable to the RJ-45 port.
- **Audio:** Connect speakers or headphones to the audio output jack.

### 3. Power Connection

Connect the power cord to the power input on the rear of the desktop, then plug the other end into a grounded electrical outlet.

### 4. Initial Power On

Press the power button on the front of the desktop. The system will boot up. Follow any on-screen instructions for initial operating system setup.



Image: Front view of the HP EliteDesk 705 G4 MT desktop, highlighting the power button and accessible front ports.

## OPERATING INSTRUCTIONS

### Front Panel Overview

- **Power Button:** Turns the computer on or off.
- **USB Ports:** For connecting USB devices such as flash drives, external hard drives, or peripherals.
- **Headphone/Microphone Combo Jack:** For connecting headsets or separate headphones and microphones.

### Rear Panel Overview

- **DisplayPort (DP):** Connects to monitors for video output. This model features 3 DisplayPort outputs.
- **USB Ports:** Additional ports for connecting various USB devices. This model includes 4 USB 3.1 Gen1 and 6 USB 2.0 ports.
- **Ethernet (RJ-45) Port:** Connects to a wired network.
- **Power Connector:** Connects the power cord to the electrical outlet.



Image: Angled view of the HP EliteDesk 705 G4 MT desktop, illustrating the overall design and port locations.

## MAINTENANCE

### General Care

- Keep the desktop in a clean, dust-free environment.
- Ensure proper airflow around the computer to prevent overheating.
- Avoid placing liquids or food near the device.

### Cleaning

- Before cleaning, power off the computer and unplug it from the power outlet.
- Use a soft, lint-free cloth dampened with water or a mild cleaning solution to wipe exterior surfaces.
- Use compressed air to gently clear dust from vents and ports.
- Do not spray liquids directly onto the computer.

## TROUBLESHOOTING

### No Power

- Verify the power cord is securely connected to both the desktop and the electrical outlet.
- Ensure the power outlet is functional by testing it with another device.

## No Display on Monitor

- Check that the monitor is powered on and its video cable is securely connected to one of the DisplayPort outputs on the desktop.
- Ensure the correct input source is selected on your monitor.
- If using multiple monitors, try connecting only one at a time to isolate the issue.

## Slow Performance

- Close unnecessary applications running in the background.
- Ensure the operating system and drivers are up to date.
- Check for sufficient free space on the hard drive.
- Consider upgrading RAM or replacing the HDD with an SSD for improved performance, if applicable.

## SPECIFICATIONS

<b>Processor</b>	AMD A6-9500 (3.5GHz, up to 3.8 GHz, 2-Cores)
<b>Graphics</b>	AMD Radeon Graphics (Integrated)
<b>Memory (RAM)</b>	4GB DDR4 DIMM
<b>Storage</b>	500GB HDD
<b>Operating System</b>	Windows 10
<b>USB Ports</b>	4x USB 3.1 Gen1, 6x USB 2.0, 1x USB 3.1 Type-C Gen2
<b>Video Outputs</b>	3x DisplayPort (DP)
<b>Audio Ports</b>	1x Headphone/Microphone Combo Jack
<b>Network</b>	Ethernet LAN (RJ-45)
<b>Power Supply</b>	250W
<b>Dimensions (WxLxH)</b>	6.69 x 10.79 x 13.3 inches
<b>Weight</b>	11 pounds

## WARRANTY AND SUPPORT

### Warranty Information

This HP EliteDesk 705 G4 MT desktop is a renewed product and comes with a **90-day warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

## Technical Support

For technical assistance, driver downloads, or further support, please visit the official HP support website: [support.hp.com](https://support.hp.com). You may need your product model number (EliteDesk 705 G4 MT) and serial number for specific support.

© 2023 HP Inc. All rights reserved. Information in this document is subject to change without notice.